

AT12616: Getting Started with ATSAMD10D14A

SMART ARM-Based Microcontrollers

Objective

- Get started with the ATSAMD10D14A (Atmel[®] | SMART ARM[®] Cortex[®]-M0+ based SAM D10 series).
- Find the ATSAMD10D14A device related links in Atmel website (like documents, tools etc).
- Get started with Atmel Studio 6.2 (project creation and demo program (GPIO input / output configuration) development on a step by step basis). All these steps are also described in Atmel Studio help system.

Pre-requisites

- ATSAM D10 Xplained Mini Kit
- Atmel Studio 6.2 or later

Table of Contents

Ob	Objective				
Table of Contents					
1	Get	tting Started with ATSAMD10D14A	3		
	1.1	Introduction	3		
	1.2	ATSAMD10D14A Device Features			
	1.3 Cortex M0+ Core Features				
	1.4 Cortex M0+ Configuration for SAM D10 series devices				
	1.5 ATSAMD10D14A Block Diagram				
	1.6				
	1.7	1.7 SAMD10 Xplained Mini Kit			
	1.8	Atmel Studio			
		1.8.1 Atmel Studio Webpage	8		
		1.8.2 Atmel Studio Microsite	8		
	1.9	1.9 Connecting the ATSAMD10 Xplained Mini kit			
		1.9.1 Auto board identification of ATSAMD10 Xplained Mini Kit	9		
		1.9.2 Connect the ATSAMD10 Xplained Mini UART to the mEDBG COM Port			
	1.10 Programming and Debugging				
		1.10.1 Programming the ATSAMD10 Xplained Mini using mEDBG			
		1.10.2 Debugging the ATSAMD10 Xplained Mini using mEDBG	10		
2	Cre	eating an Example Application in Atmel Studio	11		
3	What's Next?				
4	Revision History				




1 Getting Started with ATSAMD10D14A

1.1 Introduction

The Atmel | SMART SAM D portfolio is architected beyond the core, using over two decades of Atmel microcontroller (MCU) experience to create unique, connected peripherals that work flawlessly with the ARM[®] Cortex[®]-M0+ CPU. These MCUs are easy-to-use and provide scalability and performance.

The SAM D10 and SAM D11 are the smallest ARM Cortex-M0+ devices available from Atmel, expanding our product offering down to 8kB of Flash, 4kB of SRAM and 14-pin packages. All packages use only 2 pins for power, and the reset pin can be configured to as a GPIO, maximizing the functionality available. To help simplify the design process and reduce the Bill of Materials, these new Atmel families also integrate additional functionality, including Full Speed crystal-less USB(in SAMD11), peripheral touch controller that requires no external components, Event System, ADC with gain stage, DMA, timers/counters for control applications, and several other new features. From the SAM D10 to the SAM D21, these devices are code- and pin-compatible making it easy for designers to migrate up and down the family.

SAMD10 and SAMD11 Device Details



Main Features and Functions in all devices:

ARM Cortex-M0+ CPU at 48 MHz, 1.62-3.6V operation*, -40°C – 85°C, 12-bit 350 ksps ADC, 1-ch 10-bit 350ksps DAC and analog comparators, 2x AC Peripheral Touch Controller*, 32-bit RTC with calendar mode, 2x 16-bit TC and 1x 24-bit TCC 6-ch Event system and 6-ch DMA controller with SleepWalking SERCOM supports USART/UART with autobaud, SPI, I²C up to 3.4MHz*, PMBus, SMBus, IrDA 96 MHz Fractional PLL, 1 Timer/Counter optimized for Control applications (TCC)



1.2 ATSAMD10D14A Device Features

- 2.14 CoreMark / MHz
- 45 DMIPS (0.9375 DMIPS per MHz)
- Flexible Clock System (8 clock sources)
- ± 2% Calibrated Internal RC oscillator
- Digital Frequency Locked Loop (DFLL48M)
- Capacitor less internal regulator
- Sleep Walking Peripherals (Asynchronous wakeup with event system)
- High Speed bus matrix for concurrrent (bus) accesses
- Dedicated flash area for EEPROM emulation
- Peripheral Touch Controller (PTC) Hardware Touch Acquistion
- Atmel® QTouch® library support

Note: For detailed information (like flash size, number of peripheral channels, module description etc) refer to the SAMD10 datasheet.

1.3 Cortex M0+ Core Features


- Von Neumann Architecture
- 2 Stage Pipelining
- Micro trace buffer (Instruction trace buffer for fast debug)
- Completely programmable in 'C' (even start-up code)
- Simple memory map (Linear Addressing)
- CMSIS (Cortex-M Software Interface Standard) Portable Code

1.4 Cortex M0+ Configuration for SAM D10 series devices

- Single I/O Access
- Little endian
- SysTick Timer
- Single Cycle 32 *32 Multiplier (Fast)
- 32 bit Instruction Width
- Vector Table Offset Register
- Halting Debug



1.5 ATSAMD10D14A Block Diagram



Note: For detailed information (like module description) refer to the SAMD10 datasheet.



1.6 ATSAMD10D14A Device Related Website Links

The ATSAMD10D14A product overview webpage (as shown below) is available at the following link http://www.atmel.com/devices/ATSAMD10D14A.aspx

Home > Products > Microcontrollers > SMART ARM-based MCUs > SAM D MCUs

ATSAMD10D14A



In 'Parameters' tab, we can find the configuration parameter details (like flash size, number of peripheral channels etc) for this device.

http://www.atmel.com/devices/ATSAMD10D14A.aspx?tab=parameters

In 'Documents' tab, we can find all the related documents (like datasheet, application notes) for this device http://www.atmel.com/devices/ATSAMD10D14A.aspx?tab=documents

In the above link under 'datasheet' section there are two documents

- Complete version (includes all peripheral descriptions and electrical characteristics)
- Summary version (includes Ordering Information, pin out, and Packaging Information)



The device related application notes (like getting started with SAMD10) and its associated firmware (if any) is also available in the above specified link.

In 'Applications' tab, we can find the recommended application areas for (not limited to) for this device http://www.atmel.com/devices/ATSAMD10D14A.aspx?tab=applications

In 'Tools' tab, we can find all the related tools (like IDE, debugger, evaluation kit) for this device http://www.atmel.com/devices/ATSAMD10D14A.aspx?tab=tools


If we click 'SAMD10 Xplained Mini' from the above link then we can view the SAMD10 Xplained Mini kit's overview webpage (as shown below)

http://www.atmel.com/tools/ATSAMD10-XMINI.aspx

1.7 SAMD10 Xplained Mini Kit

Home > Products > Microcontrollers > SMART ARM-based MCUs > SAM D MCUs

SAM D10 Xplained Mini



If we click on 'Buy Tool' from the above link then we can purchase the same kit from our Atmel Store http://store.atmel.com/PartDetail.aspx?q=p:10500413



In 'documents' tab from the above link we can find the kit related documents like (schematic, user guide). http://www.atmel.com/tools/ATSAMD10-XMINI.aspx?tab=documents

Note: For detailed information like header and connections refer to the ATSAMD10 Xplained Mini User Guide which is available at the above specified link.


1.8 Atmel Studio

1.8.1 Atmel Studio Webpage

The Atmel Studio installer (free IDP) is available at the following (as shown below) link http://www.atmel.com/tools/ATMELSTUDIO.aspx

1.8.2 Atmel Studio Microsite

To learn more about Atmel Studio refer to the following micro site link http://www.atmel.com/microsite/atmel_studio6/





In 'Software Library' tab, we can find the details about Atmel Software Framework (software drivers and libraries) http://www.atmel.com/microsite/atmel studio6/software.aspx

In 'Videos' tab we can find the getting started videos (like editor, creating a new C (gcc) project, debugging AVR applications, debugging ARM applications etc)

http://www.atmel.com/microsite/atmel_studio6/videos.aspx

1.9 **Connecting the ATSAMD10 Xplained Mini kit**


This section helps user to connect the ATSAMD10 Xplained Mini with Atmel Studio 6.2

- 1. Download and install Atmel Studio version 6.2 or later.
- 2. Launch Atmel Studio.
- 3. Connect the ATSAMD10 Xplained Mini to the USB port and it will be visible in Atmel Studio.

1.9.1 Auto board identification of ATSAMD10 Xplained Mini Kit


1. Once the ATSAMD10 Xplained Mini kit is connected to the PC, the Windows® Task bar will pop-up a message as shown in figure.

Figure: ATSAMD10 Xplained Mini Driver Installation



2. If the driver installation is proper, EDBG will be listed in the Device Manager as shown in figure.


Figure: Successful mEDBG Driver Installation





3. Open Atmel Studio 6.2, Go to 'View' -> 'Available Atmel Tools'. The EDBG should get listed in the tools as "EDBG" and the tool status should display as "Connected". This indicates that the tool is communicating properly with Atmel Studio.

Figure: mEDBG under Available Atmel Tools



1.9.2 Connect the ATSAMD10 Xplained Mini UART to the mEDBG COM Port

- 1. Connect the mEDBG USB to the PC.
- 2. Use the Device Manager to find the COM port number.
- 3. Default COM port settings are 9600 baud N 8 1. The COM port settings can be changed using the Device Manager.

1.10 Programming and Debugging

This section helps to program and debug the ATSAMD10 Xplained Mini kit using mEDBG.

1.10.1 Programming the ATSAMD10 Xplained Mini using mEDBG

- 1. Connect the mEDBG USB to the PC.
- 2. Go to Atmel Studio: Click Tools, select Device Programming, and select the connected mEDBG as Tool with Device = ATSAMD10D14AM and Interface = SWD, click Apply.
- 3. Select "Memories" and locate the source hex or elf file and then click Program.

1.10.2 Debugging the ATSAMD10 Xplained Mini using mEDBG


- 1. Start Atmel Studio.
- 2. Connect the mEDBG USB to the PC.
- 3. Open your project.
- 4. In the Project menu select the project properties page, select the Tools tab and select mEDBG as debugger and SWD as interface.
- 5. In the Debug menu click Start Debugging and Break.
- 6. A debug session is started with a break in main, debugging can start.



2 Creating an Example Application in Atmel Studio


1. After connecting the board, to create a new project in Atmel Studio go to 'File' -> 'New' and click on 'Project...' (as shown in figure 2-1)

Figure 2-1: Creating New Project in Atmel Studio




2. The New Project wizard will display as shown in figure 2-2 and select "GCC C executable Project" template and name the project as appropriately and click "OK" to get the device selection wizard.

Figure 2-2: New Project Wizard



The Device Selection wizard will display as shown in figure 2-3 and select the ATSAMD10D14AM device from SAM D device family then click OK.

Figure 2-3 Device Selection Wizard





4. The new project and .c file will be created as shown in figure 2-4.


Add the following code snippet (LED Control using push button) in .c file.

5. Code Explanation:

- DIRSET register is used to set the port pin as output.
- IN register is used to read the port pin status.
- OUTSET register is used to drive the output pin as high
- OUTCLR register is used to drive the output pin as low
- In the above example code we use PA25 (Button) as input and PA09 (LED) as output.
- We are controlling the LED based on the push button status.
- As long the button is in pressed state (1) then the LED will not glow (1).
- If we release the button (0) then the LED will glow (0 default).




Figure 2-4: Project Window



6. In order to debug this project, configure the Tool and Interface in the Project properties. To open the project properties, go to 'Project' menu -> 'Properties'. In the project properties, go to "Tool" tab -> Under the Selected Debugger/Programmer, select the tool as "mEDBG" and interface as "SWD" as shown in figure 2-5 Tool and Interface Settings.

Figure 2-5: Tool and Interface Settings





- 7. To program and execute the application, we have two options.
 - a. We can start a debug session on the board, where we will be able to break the code execution and follow the application flow.
 - b. We can program the generated hex file into the controller and execute the application. In this case we will program the code with no debugging, so we select the green arrow for "Start without Debugging".

Both these options can be done on ATSAMD10 Xplained Mini as shown in figure 2-6 and figure 2-7.

Figure 2-6: Start without Debugging





Figure 2-7: Start Debugging and Break





3 What's Next?

Atmel Studio videos

http://www.atmel.com/microsite/atmel_studio6/videos.aspx

Atmel Studio online help

http://www.atmel.com/webdoc/atmelstudio/

Atmel Studio offline help (After installing Atmel Studio)

In Atmel Studio
Help -> View Help (Ctrl+F1) -> Atmel Studio

- ASF (Atmel Software framework) Getting Started and ASF Reference manual http://www.atmel.com/tools/AVRSOFTWAREFRAMEWORK.aspx?tab=documents
- ASF online documentation

http://asf.atmel.com/docs/latest/

Technical documentation for various products

http://www.atmel.com/webdoc/

Atmel Gallery

https://gallery.atmel.com/

Production Selection Guide

Atmel MCU Selector on http://www.atmel.com/

Ordering Samples

https://secure.atmel.com/forms/secure/verifylogin.aspx?target_url=samplestore

Buying evaluation board & kits

http://store.atmel.com/

Technical Documentation

http://www.atmel.com/design-support/documentation/default.aspx

Knowledge Base and Technical Support/Design Support

http://www.atmel.com/design-support/

Collaborative workspace

http://spaces.atmel.com

AT91 SAM community

http://www.at91.com /



4 Revision History

Doc. Rev.	Date	Comments
42421A	03/2015	Initial document release

















Atmel Corporation

1600 Technology Drive, San Jose, CA 95110 USA

T: (+1)(408) 441.0311

F: (+1)(408) 436.4200

www.atmel.com

© 2015 Atmel Corporation. / Rev.:Atmel-42421A-MCU- Getting Started with ATSAMD10D14A -Application-Note_032015.

Atmel®, Atmel logo and combinations thereof, Enabling Unlimited Possibilities®, and others are registered trademarks or trademarks of Atmel Corporation in U.S. and other countries. ÅRM®, ARM Connected® logo, and others are the registered trademarks or trademarks of ARM Ltd. Windows® is a registered trademark of Microsoft Corporation in U.S. and or other countries. Other terms and product names may be trademarks of others.

DISCLAIMER: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN THE ATMEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATMEL WEBSITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life

SAFETY-CRITICAL, MILITARY, AND AUTOMOTIVE APPLICATIONS DISCLAIMER: Atmel products are not designed for and will not be used in connection with any applications where the failure of such products would reasonably be expected to result in significant personal injury or death ("Safety-Critical Applications") without an Atmel officer's specific written consent. Safety-Critical Applications include, without limitation, life support devices and systems, equipment or systems for the operation of nuclear facilities and weapons systems. Atmel products are not designed nor intended for use in military or aerospace applications or environments unless specifically designated by Atmel as military-grade. Atmel products are not designed nor intended for use in automotive applications unless specifically designated by Atmel as automotive-grade.

