

Core Independent Ultrasonic Distance Measurement with the tinyAVR® 1-series

Introduction

Author: Elizabeth Roy, Microchip Technology Inc.

This application note describes a core independent method of measuring distance using an AVR[®] device and an ultrasonic transceiver. Many peripherals are configured to work together to perform measurements and present a result, independent of the CPU. The implementation is centered around the AVR Configurable Custom Logic (CCL) module and takes advantage of timer/counter Pulse Width Modulation (PWM) generation and uses timer/counter waveform generation for synchronized masking signals used for the transmit and receive lines of the ultrasonic transducer. The Analog Comparator (AC) and Digital-to-Analog Converter (DAC) are used to handle reception of the attenuated reflected signal. Timer capture is used to measure the ultrasonic burst's "time of flight" in order to measure proximity to a barrier.

Features

- Ultrasonic transceiver used for transmitting and receiving reflected bursts
- Core Independent operation using CCL module
- Timer/Counter Type D (TCD) used for synchronized masking signals
- Compact code size
- Ultrasonic Distance Measurement Field Engagement Board available

Table of Contents

Int	troduction	1			
Fe	eatures	1			
1.	Relevant Devices				
	1.2. tinyAVR 1-series				
2.	Ultrasonic Sensors				
	Measuring Distance with an Ultrasonic Transceiver Limitations of Ultrasonic Distance Measurement				
3.	Implementation				
	 3.1. Detecting the Attenuated Reflected Signal 3.2. Synchronized Transmit and Receive Masking Signals with Timer/Counter Type D 				
4.	Range Finder Field Engagement Board with ATtiny817	13			
5.	Hardware Considerations	14			
6.	Get Source Code from Atmel START				
7.	Revision History	16			
Th	ne Microchip Web Site	17			
Сι	ustomer Change Notification Service	17			
Сι	ustomer Support	17			
Mi	icrochip Devices Code Protection Feature	17			
Le	egal Notice	18			
Tra	ademarks	18			
Qι	uality Management System Certified by DNV	19			
W	orldwide Sales and Service	20			

1. Relevant Devices


This chapter lists the relevant devices for this document.

1.1 tinyAVR® 0-series

The figure below shows the tinyAVR 0-series, laying out pin count variants and memory sizes:

- Vertical migration is possible without code modification, as these devices are fully pin- and feature compatible.
- · Horizontal migration to the left reduces the pin count and, therefore, the available features.

Figure 1-1. tinyAVR® 0-series Overview



Devices with different Flash memory size typically also have different SRAM and EEPROM.

1.2 tinyAVR 1-series

The following figure shows the tinyAVR 1-series devices, laying out pin count variants and memory sizes:

- Vertical migration upwards is possible without code modification, as these devices are pin compatible and provide the same or more features. Downward migration may require code modification due to fewer available instances of some peripherals.
- Horizontal migration to the left reduces the pin count and, therefore, the available features.

Relevant Devices

Flash Legend: 48 KB devices common data sheet 32 KB ATtiny3216 ATtiny3217 16 KB ATtiny1616 ATtiny1614 ATtiny1617 8 KB ATtiny814 ATtiny816 ATtiny817 4 KB ATtiny412 ATtiny414 ATtiny416 ATtiny417 2 KB ATtiny212 ATtiny214 **▶** Pins 20 24 8

Figure 1-2. tinyAVR® 1-series Overview


Devices with different Flash memory size typically also have different SRAM and EEPROM.

1.3 megaAVR® 0-series

The figure below shows the megaAVR 0-series devices, laying out pin count variants and memory sizes:

- Vertical migration is possible without code modification, as these devices are fully pin and feature compatible.
- Horizontal migration to the left reduces the pin count and, therefore, the available features.

Figure 1-3. megaAVR® 0-series Overview



Devices with different Flash memory size typically also have different SRAM and EEPROM.


2. Ultrasonic Sensors

Ultrasonic transceivers are able to convert an electrical signal to an ultrasonic burst and receive the resulting reflected wave when directed at a barrier. Several property comparisons can be made between the transmitted and received bursts in order to determine different factors. For example, the time between transmitting a burst and receiving the reflected wave, termed "time of flight", can be used to determine distance, or if the distance is known, a material can be uniquely identified by calculating its sound attenuation coefficient. If directed at a moving object, the Doppler shift (frequency alteration due to velocity) between the transmitted and received bursts can be measured and used to determine speed. Other deductions are possible. However, these summarize the most common.

2.1 Measuring Distance with an Ultrasonic Transceiver

In this application note, an ultrasonic transceiver is used to measure the distance to a barrier, calculated from the "time of flight" between a transmitted ultrasonic burst and receiving its reflection. This process can also be referred to as "echo ranging". The first figure below illustrates the principle. The burst produced by the transceiver bounces off the barrier object and returns to be received after a time interval. The variation in distance traveled is proportional to the measured time interval, related by a factor of the speed of sound.

Figure 2-1. Ultrasonic Distance Measurement Principle



The signals transmitted and received by an ultrasonic transducer can be visually inspected via an oscilloscope. An example is depicted in the figure below. The dotted orange lines indicate the measurable "time of flight" mentioned above. It can be seen that the reflected wave is significantly attenuated; this should be kept in mind during application design in order to detect the received signal as soon as possible.





Figure 2-2. Ultrasonic Transducer "Time of Flight" Oscilloscope Screen Capture

2.2 Limitations of Ultrasonic Distance Measurement

Situational Limitations

While measuring distance using an ultrasonic transceiver is quite effective, there are some situational requirements. Ideally, the barrier, the distance to which is to be measured, should be a solid, flat surface perpendicular to the ultrasonic beam. It should have a sufficiently different acoustic attenuation to that of air so that enough of the ultrasonic burst is reflected in order to be received by the transducer. It should also be within the operational range of the ultrasonic transceiver. The figure below (*Ineffective Ultrasonic Distance Measurement Situations*) depicts some situational limitations of ultrasonic distance measurement. In sub-figure A, the distance to the barrier is too far away and the reflected signal is too attenuated to be effectively received. Sub-figure B shows the barrier too close, meaning the transceiver is still in Transmission mode when the reflected signal should be received. In sub-figure C, the object is too small, and not enough of the ultrasonic burst is reflected. Sub-figure D shows the effect of an angle not perpendicular to the ultrasonic beam so that it is reflected away from the transceiver. In sub-figure E, the object is too soft and has an attenuation coefficient similar to that of air, so the ultrasonic beam is absorbed rather than reflected.

Figure 2-3. Ineffective Ultrasonic Distance Measurement Situations



Environmental Limitations

Additionally, ultrasonic distance measurement is highly affected by temperature and humidity, which changes the speed of sound in air. This, in turn, will contribute to large variations in measurements taken for the same distance, introducing substantial errors. Air currents can also contribute to error, in that they can act as invisible barriers that will reflect ultrasonic bursts.

It is possible to account for errors introduced by changing temperature to a certain degree. This can be done by taking a temperature measurement at the same time as a "time of flight" measurement and considering both in the distance calculation.

3. Implementation

The functionality of the Core Independent Ultrasonic Distance Measurement application is centered around the Configurable Custom Logic (CCL) module. It enables input MUXing to two Lookup-Tables (LUTs) with configurable logic. In this application, one LUT is used to control the transmit line of the ultrasonic transducer, and the other is used to filter the receive line. "Time of flight" can be measured by feeding both LUT outputs into a sequential control block, specifically an SR latch. The result is that the output of the latch indicates "time of flight". This setup can be seen in the figure below.

LUT0 Input 1 Input 0 LUT0 out (receive mask) TCD Out A (receive line) AC Out LUT0 out Reflected Signal Low = time of flight TCD Capture >>> Transmitted Signal Input 1 Input 0 LUT1 out (transmit mask) TCD Out B 0 0 0 Input 0 (PWM) TCA Out >> 0 IUT1

Figure 3-1. Ultrasonic Distance Measurement using Configurable Custom Logic Peripheral

The corresponding timing functionality is depicted in the figure below. The first three lines correspond to control of the ultrasonic transducer transmit line:

- Signal (1) is the output from timer/counter type A, which is set up to produce an approximate 40 kHz PWM
- Signal (2) is a mask produced by timer counter type D, set up to be low when an ultrasonic burst should be emitted, and the rest of the time high
- These two signals are the inputs to LUT1, the output of which (1 & !2) is connected to the transmit line of the ultrasonic transducer

The result is a specifically timed ultrasonic transmission at the PWM frequency. The initial edge of the output will also "reset" the SR latch, and start the timer/counter type D capture counter (the beginning of "time of flight").

The next three lines correspond to the control of the ultrasonic transducer receive line:

- Signal (3) is a mask produced by timer counter type D, set up to be low when the receive line is enabled, and high when transmitting. The transmission will be picked up by the receive line of the ultrasonic transducer and needs to be masked because it will be erroneously detected as the reflected signal. It extends slightly past the transmission length to account for resonance. Because both masking signals (2 and 3) are produced by the same timer, they are synchronized and therefore the transmission is effectively masked from the receive line.
- Signal (4) represents the activity on the receive line, after being processed by the analog comparator

• These two signals are the inputs to LUT0, the output of which (!3 & 4) represents the filtered receive line, only containing pulse reflections

When the reflected signal is detected by the analog comparator, the first edge will "set" the SR latch, and timer counter type D capture will occur, thereby effectively measuring "time of flight" (SR Latch line in the figure).




Figure 3-2. Ultrasonic Distance Measurement Timing Diagram

3.1 Detecting the Attenuated Reflected Signal

As can be seen in figure Oscilloscope Screen Capture Indicating Reflected Signal Attenuation below here, the reflected signal is significantly attenuated compared to the transmitted PWM signal. To handle this, the receive line of the transducer is fed into the analog comparator, which has a compare value set just below the Idle state voltage (half of the supply voltage to the transducer). This value is very specifically generated by the Digital-to-Analog Converter (DAC) module. The result will be as indicated in figure Functionality of the Analog Comparator in Detecting the Attenuated Reflected Signal. This procedure enables the reflected signal to be detected as soon as it arrives, despite its attenuation.





Figure 3-3. Oscilloscope Screen Capture Indicating Reflected Signal Attenuation

Figure 3-4. Functionality of the Analog Comparator in Detecting the Attenuated Reflected Signal




The DAC is set up to produce this value just below the idle voltage of the ultrasonic transducer. The DAC output value has to be configured to be close enough so that the reflected signal is detected as soon as it arrives despite its attenuation, but not so close that the AC picks up noise. To aid with filtering noise, the hysteresis setting of the AC can be enabled; this means the DAC value can be slightly closer to the idle voltage of the transducer, thereby increasing the accuracy of the distance measurements.

3.2 Synchronized Transmit and Receive Masking Signals with Timer/Counter Type D

In order to effectively mask the PWM transmission from the receive line, correct synchronization of the transmit and receive masking signals is necessary. This is possible by using the "One Ramp" Waveform

Generation mode of Timer/Counter Type D (for more information, refer to the device data sheet). As can be seen in the figure below, the compare values can be configured to generate two synchronized outputs able to be used as masks to control transmission and reception utilizing the transducer.

Figure 3-5. Generation of Synchronized Transmit and Receive Masking Signals using TCD One Ramp Mode



The different compare values have the following roles and should be customized according to the hardware being used:

- The CMPASET value is set to '0', indicating that the receive line should be disabled from the beginning of a measurement cycle (when an ultrasonic burst is being transmitted)
- The CMPBSET value indicates the length of a transmission. Decreasing this value will decrease
 both the minimum and maximum ranges. Increasing this value will increase the range to a certain
 point, however, once there is a part of the reflected burst with no attenuation, no advantage is
 gained from increasing transmission time.
- The CMPACLR value indicates when the receive line is enabled. This value should be customized
 according to the hardware being used, and the situational requirements. It should be long enough
 that resonance due to nonoptimal hardware is considered, and short enough that the reflected burst
 is not masked along with the transmission signal.
- The CMPBCLR value defines the length of a measurement cycle. This should be long enough that
 all reflected signals have been sufficiently attenuated (some signals can bounce back and forth
 between the sensor and the barrier several times). Decreasing this value will also decrease the
 resolution of measurement calculations (for example, CMPBCLR = 0xFFF gives a distance
 measurement resolution of one cm).

4. Range Finder Field Engagement Board with ATtiny817

The Range Finder Field Engagement Board is functional hardware employing the implementation described in this application note. It is depicted in the figure below. Its firmware employs the peripheral setup described in this application note and includes an OLED driver to display the results onscreen. The hardware also includes an RGB LED to indicate proximity on a color scale and a temperature sensor in order to account for error introduced by temperature variation, however, this functionality is not implemented in the current firmware version. More information can be found in the "Ultrasonic Range Finder with ATtiny817 Hardware User's Guide" (DS40001902).

Figure 4-1. Range Finder Field Engagement Board



5. Hardware Considerations

If a custom hardware design is being used, there are some additional components which need to be considered. Depending on the characteristics of the ultrasonic transducer being used, there may be a need for additional circuitry between the AVR device and the transmit and receive lines of the sensor. For instance, the pins on the AVR may not have sufficient drive capability to initiate an ultrasonic transmission, meaning that a push-pull amplifier would be needed between the output pin of the AVR and the TX line of the transducer. Additionally, the transducer RX line signal will need some level of amplification and filtering before it can be effectively received by the AVR analog comparator. The design of these elements will depend on the application. For reference, see the *Ultrasonic Distance Measurement Field Engagement Board* schematic.

6. Get Source Code from Atmel | START

The example code is available through Atmel | START, which is a web-based tool that enables configuration of application code through a Graphical User Interface (GUI). The code can be downloaded for both Atmel Studio and IAR Embedded Workbench[®] via the direct example code-link below or the *Browse examples* button on the Atmel | START front page.

Atmel | START web page: http://microchip.com/start

Example Code

AVR42779 Ultrasonic Distance Measurement

http://start.atmel.com/#example/Atmel:cip_ultrasonic_distance:
 1.0.0::Application:AVR42779_Ultrasonic_Distance_Measurement:

Click *User guide* in Atmel | START for details and information about example projects. The *User guide* button can be found in the example browser, and by clicking the project name in the dashboard view within the Atmel | START project configurator.

Atmel Studio

Download the code as an .atzip file for Atmel Studio from the example browser in Atmel | START, by clicking *Download selected example*. To download the file from within Atmel | START, click *Export project* followed by *Download pack*.

Double click the downloaded .atzip file and the project will be imported to Atmel Studio 7.0.

IAR Embedded Workbench

For information on how to import the project in IAR Embedded Workbench, open the Atmel | START User Guide, select *Using Atmel Start Output in External Tools*, and *IAR Embedded Workbench*. A link to the Atmel | START User Guide can be found by clicking *Help* from the Atmel | START front page or *Help And Support* within the project configurator, both located in the upper right corner of the page.

6.1 Code Configuration

The example code implements the setup described in this application note. It enables output either to an OLED display or via UART. This can be configured using the OUTPUT_USED hash-define at the top of the main file. It is designed for use with the Ultrasonic Distance Measurement Field Engagement Board, but can also be used with custom hardware.

7. Revision History

Doc. Rev.	Date	Comments
С	10/2018	 Updated megaAVR® 0-series family device Added author Minor editorial updates
В	02/2018	Chapter "Relevant Devices" has been updated to include also tinyAVR® 0-series and megaAVR® 0-series.
A	09/2017	 Converted to Microchip format and replaced the Atmel document number 42779B Added "Relevant Devices" and "Get source code from Atmel START" topic
42779B	11/2016	Two images are updated: Ultrasonic Distance Measurement using Configurable Custom Logic Peripheral Range Finder Field Engagement Board
42779A	10/2016	Initial document release

The Microchip Web Site

Microchip provides online support via our web site at http://www.microchip.com/. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- Product Support Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- General Technical Support Frequently Asked Questions (FAQ), technical support requests, online discussion groups, Microchip consultant program member listing
- Business of Microchip Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

Customer Change Notification Service

Microchip's customer notification service helps keep customers current on Microchip products. Subscribers will receive e-mail notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, access the Microchip web site at http://www.microchip.com/. Under "Support", click on "Customer Change Notification" and follow the registration instructions.

Customer Support

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or Field Application Engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: http://www.microchip.com/support

Microchip Devices Code Protection Feature

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of
 these methods, to our knowledge, require using the Microchip products in a manner outside the
 operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is
 engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.

 Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Legal Notice

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

Trademarks

The Microchip name and logo, the Microchip logo, AnyRate, AVR, AVR logo, AVR Freaks, BitCloud, chipKIT, chipKIT logo, CryptoMemory, CryptoRF, dsPIC, FlashFlex, flexPWR, Heldo, JukeBlox, KeeLoq, Kleer, LANCheck, LINK MD, maXStylus, maXTouch, MediaLB, megaAVR, MOST, MOST logo, MPLAB, OptoLyzer, PIC, picoPower, PICSTART, PIC32 logo, Prochip Designer, QTouch, SAM-BA, SpyNIC, SST, SST Logo, SuperFlash, tinyAVR, UNI/O, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

ClockWorks, The Embedded Control Solutions Company, EtherSynch, Hyper Speed Control, HyperLight Load, IntelliMOS, mTouch, Precision Edge, and Quiet-Wire are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, Anyln, AnyOut, BodyCom, CodeGuard, CryptoAuthentication, CryptoAutomotive, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, EtherGREEN, In-Circuit Serial Programming, ICSP, INICnet, Inter-Chip Connectivity, JitterBlocker, KleerNet, KleerNet logo, memBrain, Mindi, MiWi, motorBench, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, PowerSmart, PureSilicon, QMatrix, REAL ICE, Ripple Blocker, SAM-ICE, Serial Quad I/O, SMART-I.S., SQI, SuperSwitcher, SuperSwitcher II, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2018, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-5224-3678-2

Quality Management System Certified by DNV

ISO/TS 16949

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



Worldwide Sales and Service

AMERICAS	ASIA/PACIFIC	ASIA/PACIFIC	EUROPE
Corporate Office	Australia - Sydney	India - Bangalore	Austria - Wels
2355 West Chandler Blvd.	Tel: 61-2-9868-6733	Tel: 91-80-3090-4444	Tel: 43-7242-2244-39
Chandler, AZ 85224-6199	China - Beijing	India - New Delhi	Fax: 43-7242-2244-393
Tel: 480-792-7200	Tel: 86-10-8569-7000	Tel: 91-11-4160-8631	Denmark - Copenhagen
Fax: 480-792-7277	China - Chengdu	India - Pune	Tel: 45-4450-2828
echnical Support:	Tel: 86-28-8665-5511	Tel: 91-20-4121-0141	Fax: 45-4485-2829
nttp://www.microchip.com/	China - Chongqing	Japan - Osaka	Finland - Espoo
support	Tel: 86-23-8980-9588	Tel: 81-6-6152-7160	Tel: 358-9-4520-820
Veb Address:	China - Dongguan	Japan - Tokyo	France - Paris
www.microchip.com	Tel: 86-769-8702-9880	Tel: 81-3-6880- 3770	Tel: 33-1-69-53-63-20
Atlanta	China - Guangzhou	Korea - Daegu	Fax: 33-1-69-30-90-79
Ouluth, GA	Tel: 86-20-8755-8029	Tel: 82-53-744-4301	Germany - Garching
el: 678-957-9614	China - Hangzhou	Korea - Seoul	Tel: 49-8931-9700
ax: 678-957-1455	Tel: 86-571-8792-8115	Tel: 82-2-554-7200	Germany - Haan
ustin, TX	China - Hong Kong SAR	Malaysia - Kuala Lumpur	Tel: 49-2129-3766400
el: 512-257-3370	Tel: 852-2943-5100	Tel: 60-3-7651-7906	Germany - Heilbronn
Soston	China - Nanjing	Malaysia - Penang	Tel: 49-7131-67-3636
Vestborough, MA	Tel: 86-25-8473-2460	Tel: 60-4-227-8870	Germany - Karlsruhe
el: 774-760-0087	China - Qingdao	Philippines - Manila	Tel: 49-721-625370
ax: 774-760-0088	Tel: 86-532-8502-7355	Tel: 63-2-634-9065	Germany - Munich
Chicago	China - Shanghai	Singapore	Tel: 49-89-627-144-0
asca, IL	Tel: 86-21-3326-8000	Tel: 65-6334-8870	Fax: 49-89-627-144-44
el: 630-285-0071	China - Shenyang	Taiwan - Hsin Chu	Germany - Rosenheim
ax: 630-285-0075	Tel: 86-24-2334-2829	Tel: 886-3-577-8366	Tel: 49-8031-354-560
allas	China - Shenzhen	Taiwan - Kaohsiung	Israel - Ra'anana
ddison, TX	Tel: 86-755-8864-2200	Tel: 886-7-213-7830	Tel: 972-9-744-7705
el: 972-818-7423	China - Suzhou	Taiwan - Taipei	Italy - Milan
ax: 972-818-2924	Tel: 86-186-6233-1526	Tel: 886-2-2508-8600	Tel: 39-0331-742611
etroit	China - Wuhan	Thailand - Bangkok	Fax: 39-0331-466781
lovi, MI	Tel: 86-27-5980-5300	Tel: 66-2-694-1351	Italy - Padova
el: 248-848-4000	China - Xian	Vietnam - Ho Chi Minh	Tel: 39-049-7625286
louston, TX	Tel: 86-29-8833-7252	Tel: 84-28-5448-2100	Netherlands - Drunen
el: 281-894-5983	China - Xiamen		Tel: 31-416-690399
ndianapolis	Tel: 86-592-2388138		Fax: 31-416-690340
loblesville, IN	China - Zhuhai		Norway - Trondheim
el: 317-773-8323	Tel: 86-756-3210040		Tel: 47-72884388
ax: 317-773-5453			Poland - Warsaw
el: 317-536-2380			Tel: 48-22-3325737
os Angeles			Romania - Bucharest
Mission Viejo, CA			Tel: 40-21-407-87-50
el: 949-462-9523			Spain - Madrid
ax: 949-462-9608			Tel: 34-91-708-08-90
el: 951-273-7800			Fax: 34-91-708-08-91
Raleigh, NC			Sweden - Gothenberg
el: 919-844-7510			Tel: 46-31-704-60-40
lew York, NY			Sweden - Stockholm
el: 631-435-6000			Tel: 46-8-5090-4654
an Jose, CA			UK - Wokingham
el: 408-735-9110			Tel: 44-118-921-5800
el: 408-436-4270			Fax: 44-118-921-5820
anada - Toronto			
el: 905-695-1980			
ax: 905-695-2078			