

# **Using Event System on ATtiny817**

## Introduction

The event system is a set of features that allows peripherals to interact without intervention from the CPU. It enables the possibility for a change of state in one peripheral to automatically trigger actions in other peripherals. Several peripheral modules can generate events, often on the same conditions as interrupt requests. These events are routed through the event routing system to the event users, where certain actions can be triggered by the event. It is designed to provide short and predictable response times between peripherals, allowing for autonomous peripheral control and interaction, and also for synchronized timing of actions in several peripheral modules. It is a powerful tool for reducing the complexity, size, and execution time of the software.

### **Features**

- Flexible Routing of Peripheral Events:
  - Up to four asynchronous event channels and two synchronous event channels available
  - Up to ten asynchronous user channels and two synchronous user channels available
- Ability to Control Peripherals Independent of CPU

## **Table of Contents**

| Int                 | rodu                  | ction                                    | 1  |  |  |
|---------------------|-----------------------|--|----|--|--|
| Fe                  | ature                 | PS                                       | 1  |  |  |
| 1.                  | Event System Overview |  |    |  |  |
|                     | 1.1.                  | What is an Event?                        | 4  |  |  |
|                     | 1.2.                  | Event Generator                          | 4  |  |  |
|                     | 1.3.                  | Event Routing Network                    | 4  |  |  |
|                     | 1.4.                  | Event User                               | 4  |  |  |
|                     | 1.5.                  | Software Event                           | 4  |  |  |
|                     | 1.6.                  | Events and Sleep Modes                   | 5  |  |  |
| 2.                  | Example               |  |    |  |  |
|                     | 2.1.                  | Input Capture                            | 6  |  |  |
|                     |                       | 2.1.1. Configuration                     | 6  |  |  |
|                     | 2.2.                  | ADC Conversion on Timer/Counter Overflow | 6  |  |  |
|                     |                       | 2.2.1. Configuration                     | 6  |  |  |
| 3.                  | Get                   | Source Code from Atmel   START           | 7  |  |  |
| 4. Revision History |                       |  |    |  |  |
| Th                  | e Mic                 | crochip Web Site                         | 9  |  |  |
| Cu                  | stom                  | er Change Notification Service           | 9  |  |  |
| Cu                  | stom                  | er Support                               | 9  |  |  |
| Mi                  | croch                 | nip Devices Code Protection Feature      | 9  |  |  |
| Le                  | gal N                 | lotice                                   | 10 |  |  |
| Tra                 | adem                  | arks                                     | 10 |  |  |
| Qι                  | ality                 | Management System Certified by DNV       | 11 |  |  |
| Wo                  | orldw                 | ide Sales and Service                    | 12 |  |  |

## 1. Event System Overview

The event system can be divided into three distinct parts:

- Event Generators
- The Event Routing Network
- Event Users

The system block diagram is illustrated below and each module will be described in the following sections.

Figure 1-1. Block Diagram





Figure 1-2. Example of Event Source, Generator, User, and Action

Event Generator Event User



### 1.1 What is an Event?

An event, as used in this document, is an indication that a change of state within a peripheral has occurred. A peripheral capable of generating events is called an event generator. One event generator may be able to generate events on several changes within the peripheral. Each of these is an individual event source. As an example, a timer/counter module is an event generator with several event sources, since it can generate events on overflow and compare/capture.

### 1.2 Event Generator

An event generator is a peripheral module having one or more event sources. There is generally a strong correlation between the available event sources and the available interrupt belonging to a peripheral module. An event generator is feeding all its event sources to the event routing system, and is not aware of which event source is being used by other modules.

A channel path can be either asynchronous or synchronous to the main clock. The mode must be selected based on the requirements of the application.

For ATtiny817, there are four asynchronous event channels (registers ASYNCCH0, ASYNCCH1, ASYNCCH2, ASYNCCH3) and two synchronous channels (registers SYNCCH0, SYNCCH1), which are used to configure the event source.

Only one trigger from an event generator peripheral can be routed on each channel, but multiple channels can use the same generator source. Multiple peripherals can use events from the same channel.

## 1.3 Event Routing Network

The Event Routing Network handles the routing of events from the event generator to the event user. The Event Routing Network consists of six event channels. Every event source from every event generator is connected to the inputs of each of the event channels.

### 1.4 Event User

An event user is a peripheral module that can make use of an event to trigger an action, referred to as an event action. An event user selects the event source to react to by selecting an event channel. The actual event source is determined by the multiplexer setting in the selected event channel. There are ten asynchronous user channels and two synchronous user channels, corresponding to register ASYNCUSERn and SYNCUSERn (n refers to the channel number).

### 1.5 Software Event

It is possible to generate either events from software. The generated events are injected directly in the event channels. The event channel does not need to have an event source associated with it to use the manual event generation possibilities. If an event source is associated with the event channel, the manually generated event has priority and will override the peripheral event.

In a Software Event, the CPU can override an event channel line by writing to the respective strobe register location. The write to the strobe register will invert the current value on the event channel for one system clock cycle.

## 1.6 Events and Sleep Modes

The event system is operative in Active mode and Standby Sleep mode. In all other sleep modes, peripheral modules will not be able to communicate using the event system.

## 2. Example

The example shows how to use the event system, including two event configurations, covering both asynchronous and synchronous events. It has instructions on how to set up each part of the system. The example project is available at Atmel® | START.

## 2.1 Input Capture

Any event source can be used to trigger an input capture on TCB. This can be used to timestamp events.

### 2.1.1 Configuration

This example shows how to configure TCB for input capture, triggered by a change on the input of the I/O port pin, PC5.

- Configure TCB with the desired frequency and period
- Configure asynchronous event channel 2 to use the PC5 event as event input
- Select asynchronous user channel 0 to use asynchronous event channel 2 as event input channel
- Set event action for TCB to "Input Capture Event" and enable TCB
- Configure PC5 as input

TCB will now perform an input capture every time there is a falling edge on the input of PC5.

### 2.2 ADC Conversion on Timer/Counter Overflow

The ADC can be configured to do a conversion on any event. In this example, a timer/counter overflow event is used. This can be very useful when the timer/counter is used for PWM generation, as the ADC sampling can be synchronized to the PWM.

## 2.2.1 Configuration

This example shows how to configure a conversion of ADC0 on an overflow of TCA, using synchronous event channel 0.

- Configure TCA with the desired frequency and period
- Select TCA overflow event as an event source for synchronous event channel 0
- Configure asynchronous user channel 1 (ADC0) to use synchronous event channel 0 as event input
- Configure the ADC0 for an ADC conversion triggered by an event

#### 3. **Get Source Code from Atmel | START**

The example code is available through Atmel | START, which is a web-based tool that enables configuration of application code through a Graphical User Interface (GUI). The code can be downloaded for both Atmel Studio 7.0 and IAR Embedded Workbench® via the direct example code-link(s) below, or the BROWSE EXAMPLES button on the Atmel | START front page.

Atmel | START web page: http://start.atmel.com/

### **Example Code**

http://start.atmel.com/#example/Atmel%3Aavr42815 using event system on attiny817%3A0.0.1%3A %3AApplication%3AAVR42815\_-\_Using\_ATtiny817\_Event\_System%3A

Press User guide in Atmel | START for details and information about example projects. The User guide button can be found in the example browser, and by clicking the project name in the dashboard view within the Atmel | START project configurator.

#### **Atmel Studio**

Download the code as an .atzip file for Atmel Studio from the example browser in Atmel | START, by clicking DOWNLOAD SELECTED EXAMPLE. To download the file from within Atmel | START, click EXPORT PROJECT followed by DOWNLOAD PACK.

Double-click the downloaded .atzip file and the project will be imported to Atmel Studio 7.0.

#### IAR Embedded Workbench

For information on how to import the project in IAR Embedded Workbench, open the Atmel | START User guide, select Using Atmel Start Output in External Tools, and IAR Embedded Workbench. A link to the Atmel | START user guide can be found by clicking About from the Atmel | START front page or Help And Support within the project configurator, both located in the upper right corner of the page.

DS00002400A-page 7 **Application Note** © 2017 Microchip Technology Inc.

# 4. Revision History

| Doc. Rev. | Date    | Comments   |
|-----------|---------|--|
| A         | 07/2017 | Initial document release.<br>Microchip DS00002400A<br>replaces Atmel 42815A. |

## The Microchip Web Site

Microchip provides online support via our web site at <a href="http://www.microchip.com/">http://www.microchip.com/</a>. This web site is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the web site contains the following information:

- Product Support Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- General Technical Support Frequently Asked Questions (FAQ), technical support requests, online discussion groups, Microchip consultant program member listing
- Business of Microchip Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

## **Customer Change Notification Service**

Microchip's customer notification service helps keep customers current on Microchip products. Subscribers will receive e-mail notification whenever there are changes, updates, revisions or errata related to a specified product family or development tool of interest.

To register, access the Microchip web site at <a href="http://www.microchip.com/">http://www.microchip.com/</a>. Under "Support", click on "Customer Change Notification" and follow the registration instructions.

## **Customer Support**

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or Field Application Engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the web site at: http://www.microchip.com/support

## Microchip Devices Code Protection Feature

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.

 Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

## **Legal Notice**

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

### **Trademarks**

The Microchip name and logo, the Microchip logo, dsPIC, FlashFlex, flexPWR, JukeBlox, KEELOQ, KEELOQ logo, Kleer, LANCheck, MediaLB, MOST, MOST logo, MPLAB, OptoLyzer, PIC, PICSTART, PIC32 logo, RightTouch, SpyNIC, SST, SST Logo, SuperFlash and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

The Embedded Control Solutions Company and mTouch are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, BodyCom, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, ECAN, In-Circuit Serial Programming, ICSP, Inter-Chip Connectivity, KleerNet, KleerNet logo, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICtail, RightTouch logo, REAL ICE, SQI, Serial Quad I/O, Total Endurance, TSHARC, USBCheck, VariSense, ViewSpan, WiperLock, Wireless DNA, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2015, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

ISBN: 978-1-5224-1951-8

## **Quality Management System Certified by DNV**

### ISO/TS 16949

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



# **Worldwide Sales and Service**

| AMERICAS                  | ASIA/PACIFIC               | ASIA/PACIFIC            | EUROPE                |
|---------------------------|----------------------------|-------------------------|-----------------------|
| Corporate Office          | Asia Pacific Office        | China - Xiamen          | Austria - Wels        |
| 2355 West Chandler Blvd.  | Suites 3707-14, 37th Floor | Tel: 86-592-2388138     | Tel: 43-7242-2244-39  |
| Chandler, AZ 85224-6199   | Tower 6, The Gateway       | Fax: 86-592-2388130     | Fax: 43-7242-2244-393 |
| Tel: 480-792-7200         | Harbour City, Kowloon      | China - Zhuhai          | Denmark - Copenhagen  |
| Fax: 480-792-7277         | Hong Kong                  | Tel: 86-756-3210040     | Tel: 45-4450-2828     |
| Technical Support:        | Tel: 852-2943-5100         | Fax: 86-756-3210049     | Fax: 45-4485-2829     |
| http://www.microchip.com/ | Fax: 852-2401-3431         | India - Bangalore       | Finland - Espoo       |
| support                   | Australia - Sydney         | Tel: 91-80-3090-4444    | Tel: 358-9-4520-820   |
| Web Address:              | Tel: 61-2-9868-6733        | Fax: 91-80-3090-4123    | France - Paris        |
| www.microchip.com         | Fax: 61-2-9868-6755        | India - New Delhi       | Tel: 33-1-69-53-63-20 |
| Atlanta                   | China - Beijing            | Tel: 91-11-4160-8631    | Fax: 33-1-69-30-90-79 |
| Duluth, GA                | Tel: 86-10-8569-7000       | Fax: 91-11-4160-8632    | France - Saint Cloud  |
| Tel: 678-957-9614         | Fax: 86-10-8528-2104       | India - Pune            | Tel: 33-1-30-60-70-00 |
| Fax: 678-957-1455         | China - Chengdu            | Tel: 91-20-3019-1500    | Germany - Garching    |
| Austin, TX                | Tel: 86-28-8665-5511       | Japan - Osaka           | Tel: 49-8931-9700     |
| Tel: 512-257-3370         | Fax: 86-28-8665-7889       | Tel: 81-6-6152-7160     | Germany - Haan        |
| Boston                    | China - Chongqing          | Fax: 81-6-6152-9310     | Tel: 49-2129-3766400  |
| Westborough, MA           | Tel: 86-23-8980-9588       | Japan - Tokyo           | Germany - Heilbronn   |
| Tel: 774-760-0087         | Fax: 86-23-8980-9500       | Tel: 81-3-6880- 3770    | Tel: 49-7131-67-3636  |
| Fax: 774-760-0088         | China - Dongguan           | Fax: 81-3-6880-3771     | Germany - Karlsruhe   |
| Chicago                   | Tel: 86-769-8702-9880      | Korea - Daegu           | Tel: 49-721-625370    |
| Itasca, IL                | China - Guangzhou          | Tel: 82-53-744-4301     | Germany - Munich      |
| Tel: 630-285-0071         | Tel: 86-20-8755-8029       | Fax: 82-53-744-4302     | Tel: 49-89-627-144-0  |
| Fax: 630-285-0075         | China - Hangzhou           | Korea - Seoul           | Fax: 49-89-627-144-44 |
| Dallas                    | Tel: 86-571-8792-8115      | Tel: 82-2-554-7200      | Germany - Rosenheim   |
| Addison, TX               | Fax: 86-571-8792-8116      | Fax: 82-2-558-5932 or   | Tel: 49-8031-354-560  |
| Tel: 972-818-7423         | China - Hong Kong SAR      | 82-2-558-5934           | Israel - Ra'anana     |
| Fax: 972-818-2924         | Tel: 852-2943-5100         | Malaysia - Kuala Lumpur | Tel: 972-9-744-7705   |
| Detroit                   | Fax: 852-2401-3431         | Tel: 60-3-6201-9857     | Italy - Milan         |
| Novi, MI                  | China - Nanjing            | Fax: 60-3-6201-9859     | Tel: 39-0331-742611   |
| Tel: 248-848-4000         | Tel: 86-25-8473-2460       | Malaysia - Penang       | Fax: 39-0331-466781   |
| Houston, TX               | Fax: 86-25-8473-2470       | Tel: 60-4-227-8870      | Italy - Padova        |
| Tel: 281-894-5983         | China - Qingdao            | Fax: 60-4-227-4068      | Tel: 39-049-7625286   |
| Indianapolis              | Tel: 86-532-8502-7355      | Philippines - Manila    | Netherlands - Drunen  |
| Noblesville, IN           | Fax: 86-532-8502-7205      | Tel: 63-2-634-9065      | Tel: 31-416-690399    |
| Tel: 317-773-8323         | China - Shanghai           | Fax: 63-2-634-9069      | Fax: 31-416-690340    |
| Fax: 317-773-5453         | Tel: 86-21-3326-8000       | Singapore               | Norway - Trondheim    |
| Tel: 317-536-2380         | Fax: 86-21-3326-8021       | Tel: 65-6334-8870       | Tel: 47-7289-7561     |
| Los Angeles               | China - Shenyang           | Fax: 65-6334-8850       | Poland - Warsaw       |
| Mission Viejo, CA         | Tel: 86-24-2334-2829       | Taiwan - Hsin Chu       | Tel: 48-22-3325737    |
| Tel: 949-462-9523         | Fax: 86-24-2334-2393       | Tel: 886-3-5778-366     | Romania - Bucharest   |
| Fax: 949-462-9608         | China - Shenzhen           | Fax: 886-3-5770-955     | Tel: 40-21-407-87-50  |
| Tel: 951-273-7800         | Tel: 86-755-8864-2200      | Taiwan - Kaohsiung      | Spain - Madrid        |
| Raleigh, NC               | Fax: 86-755-8203-1760      | Tel: 886-7-213-7830     | Tel: 34-91-708-08-90  |
| Tel: 919-844-7510         | China - Wuhan              | Taiwan - Taipei         | Fax: 34-91-708-08-91  |
| New York, NY              | Tel: 86-27-5980-5300       | Tel: 886-2-2508-8600    | Sweden - Gothenberg   |
| Tel: 631-435-6000         | Fax: 86-27-5980-5118       | Fax: 886-2-2508-0102    | Tel: 46-31-704-60-40  |
| San Jose, CA              | China - Xian               | Thailand - Bangkok      | Sweden - Stockholm    |
| Tel: 408-735-9110         | Tel: 86-29-8833-7252       | Tel: 66-2-694-1351      | Tel: 46-8-5090-4654   |
| Tel: 408-436-4270         | Fax: 86-29-8833-7256       | Fax: 66-2-694-1350      | UK - Wokingham        |
| Canada - Toronto          |                            |                         | Tel: 44-118-921-5800  |
| Tel: 905-695-1980         |                            |                         | Fax: 44-118-921-5820  |
| Fax: 905-695-2078         |                            |                         |                       |