

# **TB3066**

# **MCP2200 HID Interface Command Description**

Author: Bogdan Bolocan

Microchip Technology Inc.

#### INTRODUCTION

This technical brief details the MCP2200 HID commands in order to help users understand the functions and operation when developing custom host applications.

MCP2200 is an USB composite device that provides two different interfaces to the host machine:

- Communication Device Class (CDC) compatible
- Human Interface Device (HID)

The CDC interface follows the USB 2.0 specifications. The information on this interface is not covered by this document.

The HID interface of the MCP2200 is used for the additional functionalities of the devices, such as GPIO, EEPROM or special features manipulation.

#### HID INTERFACE DETAILS

# **HID Interface Overview**

For the user interested in building their own application using the HID interface of the MCP2200 device, here are the main features of this interface to remember during the design stage:

- 16 bytes long HID reports generated to read/write data from/to MCP2200
- Configuration, EEPROM and GPIO commands (see MCP2200 Commands section for details)
- All commands except READ\_EE and READ\_ALL use only one way communication, with respect to the host. The host needs to send only the 16 bytes HID report.
- For READ\_EE and READ\_ALL commands, the host sends a HID report of 16 bytes and then receives a 16 bytes HID report from the MCP2200.

The transmission order of HID reports is shown in Table 1:

TABLE 1: HID REPORTS ORDER

Index number	Description	
0	= First sent/received USB report byte	
1	<ul> <li>Second sent/received USB report byte</li> </ul>	
2	•	
3	•	
•	•	
•	•	
•	•	
•	•	
•	•	
15	= Last sent/received USB report byte	

GPIO details on the bitmap values are presented throughout the document. Table 2 shows the details of an 8 bits long bitmap. All of the MCP2200 commands below that modify the GPIO port follow this bit mapping.

TABLE 2: GPIO BITMAP ASSIGNMENTS

bit 7							bit 0
(MSB)							(LSB)
GP7	GP6	GP5	GP4	GP3	GP2	GP1	GP0

#### MCP2200 Commands

A set of HID accessible commands includes:

- SET\_CLEAR\_OUTPUTS
- CONFIGURE
- READ\_EE
- WRITE EE
- READ\_ALL

#### SET\_CLEAR\_OUTPUTS

The SET\_CLEAR\_OUTPUTS command is used for GPIO functionality to establish certain values to those GPIO pins that are not assigned to their alternative dedicated function. If one of these special functions is assigned (e.g., Tx/Rx LED enabling, SSPND pin or USBCFG pin), the corresponding GPIO pin will not be affected by this command.

TABLE 3: SET\_CLEAR\_OUTPUTS COMMAND DETAILS

Index	Value	Description
0	0x08	SET_CLEAR_OUT command opcode
1		Don't care
2		Don't care
3		Don't care
4		Don't care
5		Don't care
6		Don't care
7		Don't care
8		Don't care
9		Don't care
10		Don't care
11	Set_bmap <sup>(1)</sup>	Bitmap for setting the corresponding GPIOs
12	Clear_bmap <sup>(2)</sup>	Bitmap for clearing the corresponding GPIOs
13	_	Don't care
14		Don't care
15		Don't care

Note 1: A bitmap value where the bits set to '1' sets the corresponding GPIO pins to logic '1'.

**2:** A bitmap value where the bits set to '1' clears the corresponding GPIO pins to logic '0'.

Note: Care must be taken when setting the values. If a bit is set in both Set\_bmap and Clear\_bmap fields, the assigned GPIO will end up with a value of '0'. When the SET\_CLEAR\_OUTPUTS command is executed, the first step is to set the GPIOs to '1' for the bits already set as '1' in the Set\_bmap field. The second step is to

clear to '0' the GPIOs for the correspond-

ing bits that are set to '1' in Clear\_bmap.

The mapping convention in Table 2 applies for both Set\_bmap and Clear\_bmap bytes.

#### CONFIGURE

This command is used to establish the configuration parameters that are stored in NVRAM, used by the MCP2200 after exiting the Reset mode.

TABLE 4: CONFIGURE COMMAND DETAILS

	, , , , , , , , , , , , , , , , , , , ,			
Index	Value	Description		
0	0x10	CONFIGURE command		
		opcode		
1		Don't care		
2		Don't care		
3		Don't care		
4	IO_bmap	GPIO bitmap for pin		
		assignment (input/output)		
5	Config_Alt	Alternative configuration pin		
	_Pins	settings		
6	IO_Default	Default GPIO value bitmap		
	_Val_bmap			
7	Config_Alt	Alternative function options		
	_Options			
8	Baud_H	High byte of the default baud		
		rate setting		
9	Baud_L	Low byte of the default baud		
		rate setting		
10		Don't care		
11		Don't care		
12		Don't care		
13		Don't care		
14		Don't care		
15		Don't care		

#### IO bmap

The IO\_bmap bits are defined as follows:

- 1 = input
- 0 = output

The mapping convention in Table 2 also applies for this IO\_bmap byte.

# Config\_Alt\_Pins

This is a bitmap value that sets certain GPIO pins to their alternative function (see Table 5).

#### TABLE 5: ALTERNATIVE PIN ASSIGNMENTS

bit 7 (MSB)							bit 0 (LSB)
SSPND	USBCFG	х	х	RxLED	TxLED	х	х

#### **SSPND**

- When this bit is set to '1', GP0 is designated to use its alternative function and signals the USB suspend events. When this bit is set to '1', all the GPIO related operations (setting/clearing the output value) will have no effect.
- When this bit is cleared to '0', GP0 behaves like a normal GPIO (input or output).

#### **USBCFG**

- When this bit is set to '1', GP1 is designated to use its alternative function and signals when the USB host successfully configures the MCP2200. An embedded system can use the value of this alternative function pin to determine when the host is able to load the appropriate drivers for MCP2200 and start the communication. When this bit is set to '1', all the GPIO related operations (setting/clearing the output value) will have no effect.
- When this bit is cleared to '0', GP1 behaves like a normal GPIO (input or output).

#### **RxLED**

- When this bit is set to '1', GP6 is designated to use its alternative function and signals when the MCP2200 UART received data is sent to the host. When this bit is set to '1', all the GPIO related operations (setting/clearing the output value) will have no effect.
- When this bit is cleared to '0', GP6 behaves like a normal GPIO (input or output).

#### **TxLED**

- When this bit is set to '1', GP7 is designated to
  use its alternative function and signals when the
  MCP2200 UART transmitted data is sent through
  the UART TX pin. When this bit is set to '1' all the
  GPIO related operations (setting/clearing the
  output value) will have no effect.
- When this bit is cleared to '0', GP7 behaves like a normal GPIO (input or output).

#### IO Default Val bmap

This bitmap value sets the default output value (at Reset) for the pins configured as GPIO outputs. The IO\_Default\_Val\_bmap bits are defined as follows:

- 1 = input
- 0 = output

The effect of this setting applies only to those GPIOs set as outputs that do not have their alternative function active.

**Note:** This setting has no effect when the respective pin is configured as input, or its alternative function.

The mapping convention in Table 2 also applies for the IO\_Default\_Val\_bmap byte.

## Config\_Alt\_Options

This bitmap value sets/clears some of the special functionalities provided by the MCP2200 device.

## TABLE 6: ALTERNATIVE PIN ASSIGNMENTS OPTIONS

bit 7							bit 0
(MSB)							(LSB)
RxTGL	TxTGL	LEDX	х	х	х	INVERT	HW_FLOW

#### **RXTGL**

 Modifies the behavior of the RxLED function (GP6). Refer to Table 7 for details.

#### **TXTGL**

 Modifies the behavior of the TxLED function (GP7). Refer to Table 7 for details.

#### **LEDX**

 This bit works together with the RXTGL and TXTGL bits in order to establish the behavior of the Rx and Tx LED

Table 7 details the configuration options for the Rx or Tx LEDs. In order for these settings to be applied to either Tx or Rx LEDs, GP7/GP6 must be configured for their alternative function in the Config\_Alt\_Pins bitmap value.

TABLE 7: LED CONFIGURATION OPTIONS

TXTGL or RXTGL	LEDX	Remarks
0	0	Blink fast (100 ms)
0	1	Blink slow (200 ms)
1	Don't care	Toggle LED

#### **INVERT**

• Setting this bit to '1' inverts the logic of the Tx, Rx, RTS and CTS pins. Normally, to be able to interface with the digital logic levels UART signals (e.g., direct connection to a microcontroller), this bit has to be '0'. The inversion of this bit can be very useful in order to simplify the direct connection with RS-232 signals (with a logical '1' signaled as a negative voltage and '0' as a positive voltage).

#### HW\_FLOW

 This bit controls the activation/deactivation of the hardware flow control methods using the RTS and CTS pins. When this bit is set to '1', the MCP2200 uses hardware flow control, and the RTS and CTS pins are used as flow control pins. When this bit is cleared to '0', the MCP2200 device will not use any hardware flow control.

#### Baud\_H and Baud\_L

These two bytes are used to establish the default Reset baud rate that is set in the MCP2200 device. The baud rate value is calculated as follows:

### **EQUATION 1:**

$$Baud\_rate\_divisor = \frac{12000000}{desired\_baud\_rate} - 1$$

The Baud\_rate\_divisor value represented on 16 bits is then split in 2 bytes. The user must load the Baud\_H and Baud\_L with the highest order byte, and the lower order byte respectively.

# READ\_EE

The READ\_EE command is used to read a single EEPROM memory location (1 byte) out of a total of 256 bytes of the user's EEPROM. The MCP2200 device has 256 bytes integrated EEPROM to be used for user's own purposes. Tables 8 and 9 show the details for both commands and response.

TABLE 8: READ\_EE COMMAND DETAILS

Index	Value	Description
0	0x20	READ_EE command opcode
1	EEP_Addr	Address of the EEPROM location to be read
2		Don't care
3		Don't care
4		Don't care
5		Don't care
6		Don't care
7		Don't care
8		Don't care
9		Don't care
10		Don't care
11		Don't care
12		Don't care
13		Don't care
14		Don't care
15		Don't care

TABLE 9: READ\_EE RESPONSE DETAILS

Index	Value	Description
0	0x20	READ_EE command opcode
1	EEP_Addr	Address of the EEPROM location read
2		Don't care
3	EEP_Val	Value of the requested EEPROM location
4		Don't care
5		Don't care
6		Don't care
7		Don't care
8		Don't care
9		Don't care
10		Don't care
11		Don't care
12		Don't care
13		Don't care
14		Don't care
15		Don't care

#### **EEP Addr**

This byte holds the EEPROM address to be read. When checking the Response HID Report (Table 9), this byte mirrors the EEPROM address from the preceding command report (Table 8).

# EEP\_Val

This is the value of the EEPROM location addressed by the  $\mathtt{EEP\_Addr}$ .

# WRITE\_EE

The WRITE\_EE command is used to write a single EEPROM location (1 byte) out of a total of 256 bytes of user EEPROM, present in the MCP2200 device.

TABLE 10: WRITE\_EE COMMAND DETAILS

	_				
Index	Value	Description			
0	0x40	WRITE_EE command opcode			
1	EEP_Addr	Address of the EEPROM location to write to			
2	EEP_Val	The data byte to be written at the specified EEPROM location			
3		Don't care			
4		Don't care			
5		Don't care			
6		Don't care			
7		Don't care			
8		Don't care			
9		Don't care			
10		Don't care			
11		Don't care			
12		Don't care			
13		Don't care			
14		Don't care			
15		Don't care			

# EEP\_Addr

This byte holds the EEPROM address to be written.

# EEP\_Val

This is the desired value to be written in the EEPROM memory location addressed by EEP\_Addr.

This command does not offer a response HID report. In order to verify the correct behavior of this command, the user must issue a READ\_EE command, check the latter HID report response and compare the read-back value against the one written in the first place by the WRITE\_EE command.

# READ\_ALL

This command is used to retrieve the MCP2200's NVRAM parameters.

TABLE 11: COMMAND DETAILS FOR READ ALL

Index	Value	Description
0	0x80	READ_ALL command opcode
1		Don't care
2		Don't care
3		Don't care
4		Don't care
5		Don't care
6		Don't care
7		Don't care
8		Don't care
9		Don't care
10		Don't care
11		Don't care
12		Don't care
13		Don't care
14		Don't care
15		Don't care

TABLE 12: READ\_ALL RESPONSE DETAILS

Index	Value	Description
0	0x80	READ_ALL command opcode
1	EEP_Addr	Current EEPROM location
2		Don't care
3	EEP_Val	Current value of the EEPROM location specified by EEP_Addr
4	IO_bmap	GPIO bitmap for pin assignment (input/output)
5	Config_Alt_ Pins	Alternative configuration pin settings
6	IO_Default_ Val_bmap	Default GPIO value bitmap
7	Config_Alt_ Options	Alternative function options
8	Baud_H	High byte of the default baud rate setting
9	Baud_L	Low byte of the default baud rate setting

TABLE 12: READ\_ALL RESPONSE DETAILS (CONTINUED)

Index	Value	Description
10	IO_Port_Val _bmap	Bitmap of the GPIO port values
11	bmap	Don't care
12		Don't care
13		Don't care
14		Don't care
15		Don't care

#### **EEP Addr**

This is the current EEPROM address.

#### **EEP Val**

This is the current value of the EEPROM address ( $\texttt{EEP\_Addr}$ ).

#### IO\_bmap

This is the current GPIO input/output designation (see IO\_bmap in the CONFIGURE section).

# Config\_Alt\_Pins

This is the current GPIO alternative function designation ((see Config\_Alt\_Pins in the CONFIGURE section).

## IO\_Default\_Val\_bmap

This is the default (at Reset) GPIO value, that has effect only on the GPIO output designated pins (see IO\_Default\_Val\_bmap in the CONFIGURE section).

# Config\_Alt\_Options

This is the current alternative functions options (see Config\_Alt\_Options in the CONFIGURE section).

#### Baud H and Baud L

This is the default (at Reset) baud rate value. It is not required to change this default baud rate for communication changes. The host can change the communication baud rate through the CDC interface (e.g., from a terminal application at the time of communication parameters selection). This default baud rate may be useful when the MCP2200's USB side is connected to a feature-limited USB host that does not have the option to send the communication parameters through the CDC interface (see Baud\_H and Baud\_L in the CONFIGURE section).

# IO\_Port\_Val\_bmap

This is the current value of the entire GPIO port. The value of this byte also includes the values of the alternative function pins as well as the value of the GPIO pins at the moment the READ\_ALL command is executed.

# **TB3066**

NOTES:

### Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the
  intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

#### **Trademarks**

The Microchip name and logo, the Microchip logo, dsPIC, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, PIC<sup>32</sup> logo, rfPIC and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rfLAB, Select Mode, Total Endurance, TSHARC, UniWinDriver, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2011, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

Printed on recycled paper.

ISBN: 978-1-60932-932-7

QUALITY MANAGEMENT SYSTEM

CERTIFIED BY DNV

ISO/TS 16949:2002

Microchip received ISO/TS-16949:2002 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



# **Worldwide Sales and Service**

#### **AMERICAS**

Corporate Office

2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200

Fax: 480-792-7277 Technical Support:

http://www.microchip.com/

support

Web Address: www.microchip.com

Atlanta

Duluth, GA Tel: 678-957-9614

Fax: 678-957-1455

**Boston** 

Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL

Tel: 630-285-0071 Fax: 630-285-0075

Cleveland

Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

**Dallas** 

Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Indianapolis

Noblesville, IN Tel: 317-773-8323 Fax: 317-773-5453

Los Angeles

Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara

Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto

Mississauga, Ontario,

Canada

Tel: 905-673-0699 Fax: 905-673-6509

#### ASIA/PACIFIC

**Asia Pacific Office** 

Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong

Tel: 852-2401-1200 Fax: 852-2401-3431

Australia - Sydney

Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

China - Beijing

Tel: 86-10-8528-2100 Fax: 86-10-8528-2104

China - Chengdu

Tel: 86-28-8665-5511 Fax: 86-28-8665-7889

China - Chongqing

Tel: 86-23-8980-9588 Fax: 86-23-8980-9500

China - Hong Kong SAR

Tel: 852-2401-1200 Fax: 852-2401-3431

China - Nanjing

Tel: 86-25-8473-2460 Fax: 86-25-8473-2470

China - Qingdao

Tel: 86-532-8502-7355 Fax: 86-532-8502-7205

China - Shanghai

Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

China - Shenyang

Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

China - Shenzhen

Tel: 86-755-8203-2660 Fax: 86-755-8203-1760

China - Wuhan

Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

China - Xian

Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

China - Xiamen

Tel: 86-592-2388138 Fax: 86-592-2388130

China - Zhuhai

Tel: 86-756-3210040 Fax: 86-756-3210049

#### ASIA/PACIFIC

India - Bangalore

Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

India - New Delhi

Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune

Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

Japan - Yokohama

Tel: 81-45-471- 6166 Fax: 81-45-471-6122

Korea - Daegu

Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul

Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur

Tel: 60-3-6201-9857 Fax: 60-3-6201-9859

Malaysia - Penang

Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila

Tel: 63-2-634-9065 Fax: 63-2-634-9069

Singapore

Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan - Hsin Chu

Tel: 886-3-6578-300 Fax: 886-3-6578-370

Taiwan - Kaohsiung Tel: 886-7-213-7830

Fax: 886-7-330-9305

Taiwan - Taipei

Tel: 886-2-2500-6610 Fax: 886-2-2508-0102

Thailand - Bangkok

Tel: 66-2-694-1351 Fax: 66-2-694-1350

#### **EUROPE**

Austria - Wels

Tel: 43-7242-2244-39 Fax: 43-7242-2244-393 Denmark - Copenhagen

Tel: 45-4450-2828 Fax: 45-4485-2829

France - Paris

Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany - Munich

Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Italy - Milan

Tel: 39-0331-742611 Fax: 39-0331-466781

Netherlands - Drunen

Tel: 31-416-690399 Fax: 31-416-690340

Spain - Madrid

Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

**UK - Wokingham** Tel: 44-118-921-5869 Fax: 44-118-921-5820

02/18/11