

J-Link / J-Trace Getting started

Document: UM08001
Software Version: 8.52
Date: July 16, 2025



A product of SEGGER Microcontroller GmbH

www.segger.com

Table of contents

1	Introduction	3
1.1	Overview	4
1.1.1	Getting started	4
1.1.2	Supported Cores and tested devices	4
1.1.3	Supported IDEs / debuggers	4
1.1.4	Troubleshooting	4
1.1.5	Other products of interest	4

Chapter 1

Introduction

Thank you for choosing J-Link / J-Trace as your debugging and programming solution.

This manual presents a quick start guide for J-Link / J-Trace and the J-Link Software and Documentation Pack, supported on Windows, Linux and MacOS.

SEGGER's motto is "It simply works" which also applies to getting started with debug probes and the related software.



J-Link - Wiki page

1.1 Overview

1.1.1 Getting started

The only thing you have to do is downloading and installing the J-Link Software and Documentation Pack from the [SEGGER homepage](#). It is a free of charge software pack that contains a wide variety of tools used for debugging and production. For more information about what is included in the J-Link Software and Documentation Pack, please refer to:

- [J-Link / J-Trace Manual](#)
- [J-Link Software and Documentation Pack release notes](#)

1.1.2 Supported Cores and tested devices

J-Link / J-Trace together with the J-Link Software and Documentation Pack provide support for a wide variety of cores and devices.

For a list of cores and devices supported by J-Link / J-Trace, please refer to:

- [List of supported Cores](#)
- [List of supported Devices](#)

1.1.3 Supported IDEs / debuggers

J-Link / J-Trace is supported by all common IDEs on the embedded market. As the J-Link Software and Documentation Pack also comes with a GDB Server, all IDEs supporting the GDB interface are automatically working with J-Link / J-Trace. For a list of tested IDEs, including getting started instructions, please refer to the [SEGGER homepage](#).

1.1.4 Troubleshooting

If you have questions or if you encounter issues, we recommend to check out our Wiki first:

- [Troubleshooting guide](#) - Related to issues between PC & Probe or Probe & CPU.
- [J-Trace wiki article](#) - Information and troubleshooting related to TRACE.

If this does not help you out and your J-Link / J-Trace is still within support period (1 year), please feel free to contact our support team via our [support ticket system](#).

Note

Please do not forget to mention the following points:

- J-Link/J-Trace serial number.
- Information about your target hardware (processor, board, etc.).
- A detailed description of the problem.
- Screenshots of all warnings/errors.
- Output of the J-Link Commander if available.
- Your findings of the signal analysis.

1.1.5 Other products of interest

SEGGER provides additional tools (soft- and hardware) to support the user for debugging and production purposes. This chapter provides a small overview of the products that are connected to the J-Link / J-Trace and its software in the closest way.

- [SEGGER Embedded Studio](#) - SEGGERs IDE solution.
- [SEGGER Ozone](#) - SEGGERs debugger solution. Ideal for usage with J-Trace.
- [SEGGER SystemView](#) - SEGGERs code instrumentation tool.

For an overview of all SEGGER products, please refer to the [SEGGER homepage](#).

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Segger Microcontroller:](#)

[J-Link ULTRA](#) [8.08.28](#) [8.08.91](#) [8.08.93](#) [8.19.00](#) [8.19.28](#) [8.20.00](#) [8.14.28](#) [8.06.19](#) [8.12.28](#)