



MICROCHIP

**MCP9601
Thermocouple IC
Evaluation Board
User's Guide**

Note the following details of the code protection feature on Microchip products:

- Microchip products meet the specifications contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is secure when used in the intended manner, within operating specifications, and under normal conditions.
- Microchip values and aggressively protects its intellectual property rights. Attempts to breach the code protection features of Microchip product is strictly prohibited and may violate the Digital Millennium Copyright Act.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of its code. Code protection does not mean that we are guaranteeing the product is “unbreakable”. Code protection is constantly evolving. Microchip is committed to continuously improving the code protection features of our products.

This publication and the information herein may be used only with Microchip products, including to design, test, and integrate Microchip products with your application. Use of this information in any other manner violates these terms. Information regarding device applications is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. Contact your local Microchip sales office for additional support or, obtain additional support at <https://www.microchip.com/en-us/support/design-help/client-support-services>.

THIS INFORMATION IS PROVIDED BY MICROCHIP "AS IS". MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE, OR WARRANTIES RELATED TO ITS CONDITION, QUALITY, OR PERFORMANCE.

IN NO EVENT WILL MICROCHIP BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL, OR CONSEQUENTIAL LOSS, DAMAGE, COST, OR EXPENSE OF ANY KIND WHATSOEVER RELATED TO THE INFORMATION OR ITS USE, HOWEVER CAUSED, EVEN IF MICROCHIP HAS BEEN ADVISED OF THE POSSIBILITY OR THE DAMAGES ARE FORESEEABLE. TO THE FULLEST EXTENT ALLOWED BY LAW, MICROCHIP'S TOTAL LIABILITY ON ALL CLAIMS IN ANY WAY RELATED TO THE INFORMATION OR ITS USE WILL NOT EXCEED THE AMOUNT OF FEES, IF ANY, THAT YOU HAVE PAID DIRECTLY TO MICROCHIP FOR THE INFORMATION.

Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights unless otherwise stated.

For information regarding Microchip's Quality Management Systems, please visit www.microchip.com/quality.

Trademarks

The Microchip name and logo, the Microchip logo, Adaptec, AnyRate, AVR, AVR logo, AVR Freaks, BesTime, BitCloud, CryptoMemory, CryptoRF, dsPIC, flexPWR, HELDO, IGLOO, JukeBlox, KeeLoq, Klear, LANCheck, LinkMD, maxStylus, maXTouch, MediaLB, megaAVR, Microsemi, Microsemi logo, MOST, MOST logo, MPLAB, OptoLyzer, PIC, picoPower, PICSTART, PIC32 logo, PolarFire, Prochip Designer, QTouch, SAM-BA, SenGenuity, SpyNIC, SST, SST Logo, SuperFlash, Symmetricom, SyncServer, Tachyon, TimeSource, tinyAVR, UNI/O, Vectron, and XMEGA are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

AgileSwitch, APT, ClockWorks, The Embedded Control Solutions Company, EtherSynch, Flashtec, Hyper Speed Control, HyperLight Load, IntelliMOS, Libero, motorBench, mTouch, Powermite 3, Precision Edge, ProASIC, ProASIC Plus, ProASIC Plus logo, QuietWire, SmartFusion, SyncWorld, Temux, TimeCesium, TimeHub, TimePictra, TimeProvider, TrueTime, WinPath, and ZL are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Adjacent Key Suppression, AKS, Analog-for-the-Digital Age, Any Capacitor, AnyIn, AnyOut, Augmented Switching, BlueSky, BodyCom, CodeGuard, CryptoAuthentication, CryptoAutomotive, CryptoCompanion, CryptoController, dsPICDEM, dsPICDEM.net, Dynamic Average Matching, DAM, ECAN, Espresso T1S, EtherGREEN, GridTime, IdealBridge, In-Circuit Serial Programming, ICSP, INICnet, Intelligent Paralleling, Inter-Chip Connectivity, JitterBlocker, Knob-on-Display, maxCrypto, maxView, memBrain, Mindi, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, MultiTRAK, NetDetach, NVM Express, NVMe, Omniscient Code Generation, PICDEM, PICDEM.net, PICkit, PICTail, PowerSmart, PureSilicon, QMatrix, REAL ICE, Ripple Blocker, RTAX, RTG4, SAM-ICE, Serial Quad I/O, simpleMAP, SimpliPHY, SmartBuffer, SmartHLS, SMART-I.S., storClad, SQL, SuperSwitcher, SuperSwitcher II, Switchtec, SynchroPHY, Total Endurance, TSHARC, USBCheck, VariSense, VectorBlox, VeriPHY, ViewSpan, WiperLock, XpressConnect, and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

The Adaptec logo, Frequency on Demand, Silicon Storage Technology, Symmcom, and Trusted Time are registered trademarks of Microchip Technology Inc. in other countries.

GestIC is a registered trademark of Microchip Technology Germany II GmbH & Co. KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2022, Microchip Technology Incorporated and its subsidiaries.

All Rights Reserved.

ISBN: 978-1-5224-9709-7



MCP9601 THERMOCOUPLE IC EVALUATION BOARD USER'S GUIDE

Table of Contents

Preface	5
Introduction.....	5
Document Layout	5
Conventions Used in This Guide.....	6
Recommended Reading.....	7
The Microchip Website	7
Customer Support	7
Revision History	7
Chapter 1. Product Overview	
1.1 Introduction	9
1.2 What is the MCP9601 Device?	9
1.3 What is the MCP9601 Thermocouple IC Evaluation Board?	9
1.4 What the MCP9601 Thermocouple IC Evaluation Board Kit Contains	9
Chapter 2. Installation and Operation	
2.1 Introduction	11
2.2 Required Tool	11
2.3 Getting Started	11
2.3.1 Hardware Setup	11
2.3.2 Hardware Operation	12
2.4 Microchip Thermal Management Software GUI	12
2.5 Configuring the MCP9601	15
2.5.1 MCP9600 vs. MCP9601 Additional Features	15
2.5.2 How to Check for Open Circuit and Short Circuit Conditions	16
2.6 Data Acquisition	16
Appendix A. Schematic and Layouts	
A.1 Introduction	19
A.2 Schematic 1	20
A.3 Schematic 2	21
A.4 Board – Top Silk	22
A.5 Board – Top Copper and Silk	22
A.6 Board – Top Copper	23
A.7 Board – Bottom Copper	23
A.8 Board – Bottom Copper and Silk	24
A.9 Board – Bottom Silk	24
Appendix B. Bill of Materials (BOM)	25
Worldwide Sales and Service	27

MCP9601 Thermocouple IC Evaluation Board User's Guide

NOTES:



MCP9601 THERMOCOUPLE IC EVALUATION BOARD USER'S GUIDE

Preface

NOTICE TO CUSTOMERS

All documentation becomes dated, and this manual is no exception. Microchip tools and documentation are constantly evolving to meet customer needs, so some actual dialogs and/or tool descriptions may differ from those in this document. Please refer to our website (www.microchip.com) to obtain the latest documentation available.

Documents are identified with a “DS” number. This number is located on the bottom of each page, in front of the page number. The numbering convention for the DS number is “DSXXXXXXXXA”, where “XXXXXXXX” is the document number and “A” is the revision level of the document.

For the most up-to-date information on development tools, see the MPLAB® IDE online help. Select the Help menu, and then Topics to open a list of available online help files.

INTRODUCTION

This chapter contains general information that will be useful to know before using the MCP9601 Thermocouple IC Evaluation Board. Items discussed in this chapter include:

- Document Layout
- Conventions Used in This Guide
- Recommended Reading
- The Microchip Website
- Customer Support
- Revision History

DOCUMENT LAYOUT

This document describes how to use the MCP9601 Thermocouple IC Evaluation Board as a development tool. The document is organized as follows:

- **Chapter 1. “Product Overview”** – This chapter includes important information about the MCP9601 Thermocouple IC Evaluation Board.
- **Chapter 2. “Installation and Operation”** – This chapter includes a detailed description of each function of the evaluation board and instructions on how to begin using the board.
- **Appendix A. “Schematic and Layouts”** – Shows the schematic and layout diagrams for MCP9601 Thermocouple IC Evaluation Board.
- **Appendix B. “Bill of Materials (BOM)”** – Lists the parts used to build the MCP9601 Thermocouple IC Evaluation Board.

MCP9601 Thermocouple IC Evaluation Board User's Guide

CONVENTIONS USED IN THIS GUIDE

This manual uses the following documentation conventions:

DOCUMENTATION CONVENTIONS

Description	Represents	Examples
Arial font:		
Italic characters	Referenced books	<i>MPLAB® IDE User's Guide</i>
	Emphasized text	...is the <i>only</i> compiler...
Initial caps	A window	the Output window
	A dialog	the Settings dialog
	A menu selection	select Enable Programmer
Quotes	A field name in a window or dialog	"Save project before build"
Underlined, Italic text with right angle bracket	A menu path	<u>File</u> > <i>Save</i>
Bold characters	A dialog button	Click OK
	A tab	Click the Power tab
N'Rnnnn	A number in verilog format, where N is the total number of digits, R is the radix and n is a digit.	4'b0010, 2'hF1
Text in angle brackets < >	A key on the keyboard	Press <Enter>, <F1>
Courier New font:		
Plain Courier New	Sample source code	#define START
	Filenames	autoexec.bat
	File paths	c:\mcc18\h
	Keywords	_asm, _endasm, static
	Command-line options	-Opa+, -Opa-
	Bit values	0, 1
	Constants	0xFF, 'A'
Italic Courier New	A variable argument	<i>file.o</i> , where <i>file</i> can be any valid filename
Square brackets []	Optional arguments	mcc18 [options] <i>file</i> [options]
Curly brackets and pipe character: { }	Choice of mutually exclusive arguments; an OR selection	errorlevel {0 1}
Ellipses...	Replaces repeated text	var_name [, var_name...]
	Represents code supplied by user	void main (void) { ... }

RECOMMENDED READING

This user's guide describes how to use the MCP9601 Thermocouple IC Evaluation Board. Other useful documents are listed below. The following Microchip documents are available and recommended as supplemental reference resources:

- **MCP960X/L0X/RL0X Data Sheet – “Thermocouple EMF to Temperature Converter, $\pm 1.5^{\circ}\text{C}$ Maximum Accuracy” (DS20005426)**

This data sheet provides detailed information regarding the MCP9601 device:

- **PIC18F2455/2550/4455/4550 Data Sheet – “28/40/44-Pin, High-Performance, Enhanced Flash, USB Microcontrollers with nanoWatt Technology” (DS39632)**

This data sheet provides detailed information regarding the PIC18F2455/2550/4455/4550 devices.

THE MICROCHIP WEBSITE

Microchip provides online support via our website at www.microchip.com. This website is used as a means to make files and information easily available to customers. Accessible by using your favorite Internet browser, the website contains the following information:

- **Product Support** – Data sheets and errata, application notes and sample programs, design resources, user's guides and hardware support documents, latest software releases and archived software
- **General Technical Support** – Frequently Asked Questions (FAQs), technical support requests, online discussion groups, Microchip consultant program member listing
- **Business of Microchip** – Product selector and ordering guides, latest Microchip press releases, listing of seminars and events, listings of Microchip sales offices, distributors and factory representatives

CUSTOMER SUPPORT

Users of Microchip products can receive assistance through several channels:

- Distributor or Representative
- Local Sales Office
- Field Application Engineer (FAE)
- Technical Support

Customers should contact their distributor, representative or field application engineer (FAE) for support. Local sales offices are also available to help customers. A listing of sales offices and locations is included in the back of this document.

Technical support is available through the website at:

<http://www.microchip.com/support>.

REVISION HISTORY

Revision A (January 2022)

MCP9601 Thermocouple IC Evaluation Board User's Guide

NOTES:

Chapter 1. Product Overview

1.1 INTRODUCTION

This chapter provides an overview of the MCP9601 Thermocouple IC Evaluation Board and covers the following topics:

- What is the MCP9601 Device?
- What is the MCP9601 Thermocouple IC Evaluation Board?
- What the MCP9601 Thermocouple IC Evaluation Board Kit Contains

1.2 WHAT IS THE MCP9601 DEVICE?

The MCP9601 is a Thermocouple Electromotive Force (EMF) to temperature converter. This device converts thermocouple EMF to degree Celsius with integrated Cold-Junction compensation. MCP9601 corrects the thermocouple nonlinear error characteristics of eight thermocouple types and outputs $\pm 1.5^{\circ}\text{C}$ accurate temperature data for the selected thermocouple. The correction coefficients are derived from the National Institute of Standards and Technology (NIST) ITS-90 Thermocouple Database.

1.3 WHAT IS THE MCP9601 THERMOCOUPLE IC EVALUATION BOARD?

The MCP9601 Thermocouple IC Evaluation Board is used to evaluate MCP9601 Thermocouple EMF voltage to degree Celsius converter. Users can easily evaluate all device features using a Type K thermocouple. The device also supports Types J, T, N, E, B, S and R thermocouples. Each of these types can be evaluated by replacing the Type K thermocouple connector with the corresponding connectors.

In addition, the MCP9601 Thermocouple IC Evaluation Board connects to a PC via a USB interface. Temperature can be data-logged using the Microchip Thermal Management Software Graphical User Interface (GUI).

1.4 WHAT THE MCP9601 THERMOCOUPLE IC EVALUATION BOARD KIT CONTAINS

The MCP9601 Thermocouple IC Evaluation Board package includes:

- MCP9601 Thermocouple IC Evaluation Board (ADM00665)
- Type K Thermocouple
- Mini USB Cable
- Important Information Sheet

MCP9601 Thermocouple IC Evaluation Board User's Guide

NOTES:

Chapter 2. Installation and Operation

2.1 INTRODUCTION

The MCP9601 Thermocouple IC Evaluation Board enables users to easily evaluate all user-programmable features such as thermocouple selection, temperature alert limit settings, temperature resolutions and Power mode.

Items discussed in this chapter include:

- Required Tool
- Getting Started
- Microchip Thermal Management Software GUI
- Configuring the MCP9601
- Data Acquisition

2.2 REQUIRED TOOL

The evaluation board software requires Windows® 7 or later, with a USB connection.

2.3 GETTING STARTED

This section describes how to power up and interface with the MCP9601 Thermocouple IC Evaluation Board.

2.3.1 Hardware Setup

1. The MCP9601 Thermocouple IC Evaluation Board has a mini USB connector. The USB connection is needed for power and data acquisition.




FIGURE 2-1: MCP9601 Thermocouple IC Evaluation Board.

MCP9601 Thermocouple IC Evaluation Board User's Guide

2.3.2 Hardware Operation

The MCP9601 Thermocouple IC Evaluation Board is fully powered from a PC USB 5V source. Once power is applied and the USB is successfully enumerated, the PIC[®] microcontroller is ready to receive commands from GUI MCP9601 settings or transfer temperature data.




FIGURE 2-2: Functional Block Diagram.

The block diagram (Figure 2-2) shows that the thermocouple connector is directly connected to the MCP9601. The four Alert outputs are connected to test points for external connections. Additionally, these outputs are also connected to the microcontroller I/O pins so that the Alert Output statuses can be detected in software.

2.4 MICROCHIP THERMAL MANAGEMENT SOFTWARE GUI

The Microchip Thermal Management Graphical User Interface allows users to evaluate the MCP9601 for temperature-sensing applications. This software tool can be downloaded and installed from the evaluation board product page. The software requires the 'Microsoft.NET Framework' package. If this framework package is not installed on the computer, then the software will automatically download and install it. After the installation is successfully completed, the hardware is required to start the graphical user interface.

Once the hardware is connected, the software recognizes the device ID and displays the corresponding GUI for the evaluation board. Disconnecting the USB will close the GUI. This tool enables the user to evaluate the sensor features and perform temperature data logging.

Figure 2-3 shows the data acquisition interface with a plot of the thermocouple Hot-Junction and Cold-Junction temperature data. The Y1 axis is the Hot-Junction temperature and the Y2 axis is the Cold-Junction temperature. This data can also be exported by right-clicking the plot and following the export options.

Installation and Operation




FIGURE 2-3: Data Acquisition Interface.

MCP9601 Thermocouple IC Evaluation Board User's Guide

Use the Thermal Management Software Graphical User Interface (GUI) for temperature data logging or to evaluate the sensor board features. If the hardware is properly connected, the software will recognize the hardware, otherwise, the software will show the 'Hardware Not Detected' message box, as indicated in [Figure 2-4](#).




FIGURE 2-4: Hardware Not Detected Message Box.

2.5 CONFIGURING THE MCP9601

Figure 2-5 shows the user interface for various sensor options. Once these options are selected, the software programs the device and refreshes the GUI from the device. Therefore the GUI displays the updated device settings.




FIGURE 2-5: Sensor Configuration Options.

2.5.1 MCP9600 vs. MCP9601 Additional Features

The MCP9601 family integrates an open circuit and short circuit detection mechanism. When open/short circuit is detected, the device asserts an Alert signal using the SC Alert and OC Alert pins. There are test points for these pins on the MCP9601 evaluation board, which can be used to detect open circuit and short circuit conditions.

MCP9601 Thermocouple IC Evaluation Board User's Guide

Additionally, the status register bits 4 and 5 are also set when the open circuit and short circuit conditions are true. However, the MCP9600 family supports only open circuit detection which can only be read by the host controller from the status register. The MCP9600 does not integrate the alert output pin for open circuit detection.

2.5.2 How to Check for Open Circuit and Short Circuit Conditions

The GUI shows the open circuit and short circuit flags using a yellow and red colored texts as shown in [Figure 2-5](#). These features can be validated by simply disconnecting the thermocouple header from the board for open circuit detection, or by shorting the thermocouple wire to the system ground or power source (V_{SS} or V_{DD} test points on the evaluation board).

2.6 DATA ACQUISITION

The black “Play”, “Stop”, and “Reset” icons ([Figure 2-6](#)) can be used to perform continuous data acquisitions. The red “Record” icon enables the user to data log to an external file. The logging interval can be adjusted using the Interval scroll bar from 100 ms to 30s, as shown in [Figure 2-3](#).




FIGURE 2-6: Real-Time Acquisition.

The data acquisition display chart ([Figure 2-3](#)) can be customized. The customizing options ([Figure 2-7](#)) can be selected by either double-clicking or right-clicking the chart ([Figure 2-3](#)). The displayed data can also be exported.




FIGURE 2-7: Chart Setup Options.

MCP9601 Thermocouple IC Evaluation Board User's Guide

NOTES:



MCP9601 THERMOCOUPLE IC EVALUATION BOARD USER'S GUIDE

Appendix A. Schematic and Layouts


A.1 INTRODUCTION

This appendix contains the following schematics and layouts for the MCP9601 Thermocouple IC Evaluation Board:






- [Schematic 1](#)
- [Schematic 2](#)
- [Board – Top Silk](#)
- [Board – Top Copper and Silk](#)
- [Board – Top Copper](#)
- [Board – Bottom Copper](#)
- [Board – Bottom Copper and Silk](#)
- [Board – Bottom Silk](#)

A.2 SCHEMATIC 1

Connectivity




A.3 SCHEMATIC 2




MCP9601 Thermocouple IC Evaluation Board User's Guide


A.4 BOARD – TOP SILK




A.5 BOARD – TOP COPPER AND SILK



A.6 BOARD – TOP COPPER




A.7 BOARD – BOTTOM COPPER




MCP9601 Thermocouple IC Evaluation Board User's Guide

A.8 BOARD – BOTTOM COPPER AND SILK



A.9 BOARD – BOTTOM SILK



Appendix B. Bill of Materials (BOM)

TABLE B-1: BILL OF MATERIALS (BOM)

Qty.	Reference	Description	Manufacturer	Part Number
12	+3.3V, +5V USB, Alert 1, Alert 2, Alert 3, Alert 4, GND, SCL, SDA, TP1, TP2	Connector, TP, loop, silver, 0.38, SMD	Keystone [®] Electronics Corp.	5018
5	C1, C2, C3, C6, C18	Capacitor, ceramic, 0.1 μ F, 10V, 10%, X7R, SMD, 0603	KEMET	C0603C104K8RACTU
2	C4, C5	Capacitor, ceramic, 10 μ F, 10V, 10%, X5R, SMD, 0805	Taiyo Yuden Co., Ltd.	LMK212BJ106KD-T
1	D1	TVS, diode, 5.5V, SOT143B	Nexperia	PRTR5V0U2X,215
1	FB1	Ferrite, 2A, 220R, SMD, 0805	Murata Electronics [®]	BLM21PG221SN1D
2	FB2, FB3	Ferrite, 800 mA, 0.15R, SMD, 0805	Laird Technologies [®]	LI0805H151R-10
1	J1	Connector, USB, 2.0 MICRO-B, female, TH/SMD, R/A	Amphenol Corporation	10118194-0001LF
1	J11	Connector, header-2.54, male, 1x6, gold, 6.10MH, TH R/A – DO NOT POPULATE	3M	961106-5604-AR
1	LABEL1	Label, PCBA, 18x6mm, Datamatrix, Assy# / Rev / Serial / Date	Logimark AB	505462
4	PAD1, PAD2, PAD3, PAD4	Mechanical, hardware, rubber pad, Cylindrical, D7.9, H5.3, black	3M	SJ61A11
1	PCB	MCP9601 Thermocouple IC Evaluation Board – Printed Circuit Board	—	04-11385-R2
2	R1, R2	Resistor, TKF, 4.99k, 1%, 1/10W, SMD, 0603	Panasonic [®] – ECG	ERJ-3EKF4991V
1	R3	Resistor, SMD, 2.49M, Ohm, 1%, 1/10W, 0603	Yageo Corporation	RC0603FR-072M49L
1	R4	Resistor, TKF, 2M, 5%, 1/10W, SMD, 0603	Panasonic – ECG	ERJ-3GEYJ205V
3	R5, R6, R16	Resistor, TKF, 100R, 5%, 1/10W, SMD, 0603	Vishay/Dale	CRCW0603100RJNEA
1	R7	Resistor, SMD, 487K, Ohm, 1%, 1/10W, 0603	Panasonic – ECG	ERJ-3EKF4873V
1	R21	Resistor, TF, 10k, 1%, 1/16W, SMD, 0603	TE Connectivity, Ltd.	CPF0603F10KC1
1	TC1	Mechanical, hardware, adapter, Thermocoupler, TH, R/A	Omega [®] Engineering Inc.	PCC-SMP-K-100
1	U1	Microchip, Analog, LDO, 3.3V, MCP1825ST-3302E/DB, SOT-223-3	Microchip Technology Inc.	MCP1825ST-3302E/DB

Note: The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

Bill of Materials (BOM)

TABLE B-1: BILL OF MATERIALS (BOM) (CONTINUED)

Qty.	Reference	Description	Manufacturer	Part Number
1	U2	Microchip, MCU 8-Bit, 48 MHz 32 kB, 2kB, PIC18LF25K50-I/ML, QFN-28	Microchip Technology Inc.	PIC18LF25K50-I/ML
1	U3	MCP9601 Thermocouple EMF to Temperature Converter	Microchip Technology Inc.	MCP9601-I/MX MQFN-20
1	X1	Resonator, 20 MHz, 0.1%, SMD CSTCE-V13L – DO NOT POPULATE	Murata Electronics	CSTCE20M0V13L99-R0

Note: The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.

TABLE B-2: BILL OF MATERIALS – MECHANICAL PARTS

Qty.	Reference	Description	Manufacturer	Part Number
1	CBL1	Mechanical, hardware, cable, USB, male, A TO USB, Male, Micro-B, 0.91M	Qualtek Electronics Corporation	3025030-03
1	JC1	Sensor, temperature, 5SRTC-TT-K-24-36, Subminiature Connector	Omega Engineering Inc.	5SRTC-TT-K-24-36

Note: The components listed in this Bill of Materials are representative of the PCB assembly. The released BOM used in manufacturing uses all RoHS-compliant components.



MICROCHIP

Worldwide Sales and Service

AMERICAS

Corporate Office
2355 West Chandler Blvd.
Chandler, AZ 85224-6199
Tel: 480-792-7200
Fax: 480-792-7277
Technical Support:
<http://www.microchip.com/support>
Web Address:
www.microchip.com

Atlanta

Duluth, GA
Tel: 678-957-9614
Fax: 678-957-1455

Austin, TX

Tel: 512-257-3370

Boston

Westborough, MA
Tel: 774-760-0087
Fax: 774-760-0088

Chicago

Itasca, IL
Tel: 630-285-0071
Fax: 630-285-0075

Dallas

Addison, TX
Tel: 972-818-7423
Fax: 972-818-2924

Detroit

Novi, MI
Tel: 248-848-4000

Houston, TX

Tel: 281-894-5983

Indianapolis

Noblesville, IN
Tel: 317-773-8323
Fax: 317-773-5453
Tel: 317-536-2380

Los Angeles

Mission Viejo, CA
Tel: 949-462-9523
Fax: 949-462-9608
Tel: 951-273-7800

Raleigh, NC

Tel: 919-844-7510

New York, NY

Tel: 631-435-6000

San Jose, CA

Tel: 408-735-9110
Tel: 408-436-4270

Canada - Toronto

Tel: 905-695-1980
Fax: 905-695-2078

ASIA/PACIFIC

Australia - Sydney
Tel: 61-2-9868-6733

China - Beijing
Tel: 86-10-8569-7000

China - Chengdu
Tel: 86-28-8665-5511

China - Chongqing
Tel: 86-23-8980-9588

China - Dongguan
Tel: 86-769-8702-9880

China - Guangzhou
Tel: 86-20-8755-8029

China - Hangzhou
Tel: 86-571-8792-8115

China - Hong Kong SAR
Tel: 852-2943-5100

China - Nanjing
Tel: 86-25-8473-2460

China - Qingdao
Tel: 86-532-8502-7355

China - Shanghai
Tel: 86-21-3326-8000

China - Shenyang
Tel: 86-24-2334-2829

China - Shenzhen
Tel: 86-755-8864-2200

China - Suzhou
Tel: 86-186-6233-1526

China - Wuhan
Tel: 86-27-5980-5300

China - Xian
Tel: 86-29-8833-7252

China - Xiamen
Tel: 86-592-2388138

China - Zhuhai
Tel: 86-756-3210040

ASIA/PACIFIC

India - Bangalore
Tel: 91-80-3090-4444

India - New Delhi
Tel: 91-11-4160-8631

India - Pune
Tel: 91-20-4121-0141

Japan - Osaka
Tel: 81-6-6152-7160

Japan - Tokyo
Tel: 81-3-6880-3770

Korea - Daegu
Tel: 82-53-744-4301

Korea - Seoul
Tel: 82-2-554-7200

Malaysia - Kuala Lumpur
Tel: 60-3-7651-7906

Malaysia - Penang
Tel: 60-4-227-8870

Philippines - Manila
Tel: 63-2-634-9065

Singapore
Tel: 65-6334-8870

Taiwan - Hsin Chu
Tel: 886-3-577-8366

Taiwan - Kaohsiung
Tel: 886-7-213-7830

Taiwan - Taipei
Tel: 886-2-2508-8600

Thailand - Bangkok
Tel: 66-2-694-1351

Vietnam - Ho Chi Minh
Tel: 84-28-5448-2100

EUROPE

Austria - Wels
Tel: 43-7242-2244-39
Fax: 43-7242-2244-393

Denmark - Copenhagen
Tel: 45-4485-5910
Fax: 45-4485-2829

Finland - Espoo
Tel: 358-9-4520-820

France - Paris
Tel: 33-1-69-53-63-20
Fax: 33-1-69-30-90-79

Germany - Garching
Tel: 49-8931-9700

Germany - Haan
Tel: 49-2129-3766400

Germany - Heilbronn
Tel: 49-7131-72400

Germany - Karlsruhe
Tel: 49-721-625370

Germany - Munich
Tel: 49-89-627-144-0
Fax: 49-89-627-144-44

Germany - Rosenheim
Tel: 49-8031-354-560

Israel - Ra'anana
Tel: 972-9-744-7705

Italy - Milan
Tel: 39-0331-742611
Fax: 39-0331-466781

Italy - Padova
Tel: 39-049-7625286

Netherlands - Drunen
Tel: 31-416-690399
Fax: 31-416-690340

Norway - Trondheim
Tel: 47-7288-4388

Poland - Warsaw
Tel: 48-22-3325737

Romania - Bucharest
Tel: 40-21-407-87-50

Spain - Madrid
Tel: 34-91-708-08-90
Fax: 34-91-708-08-91

Sweden - Gothenberg
Tel: 46-31-704-60-40

Sweden - Stockholm
Tel: 46-8-5090-4654

UK - Wokingham
Tel: 44-118-921-5800
Fax: 44-118-921-5820