
AT09332: USB Device Interface (UDI) for Communication Class Device (CDC)

APPLICATION NOTE

Introduction

USB Device Interface (UDI) for Communication Class Device (CDC) provides an interface for the configuration and management of USB CDC serial device.

The outline of this documentation is as follows:

- [API Overview](#)
- [Quick Start Guide for USB Device Communication Class Device Module \(UDI CDC\)](#)
- [Configuration File Examples](#)

For more details for Atmel® Software Framework (ASF) USB Device Stack and USB Device CDC, refer to following application notes:

- [AVR4900: ASF - USB Device Stack](#)
- [AVR4907: ASF - USB Device CDC Application](#)
- [AVR4920: ASF - USB Device Stack - Compliance and Performance Figures](#)
- [AVR4921: ASF - USB Device Stack Differences between ASF V1 and V2](#)

Table of Contents

Introduction.....	1
1. Software License.....	4
2. API Overview.....	5
2.1. Structure Definitions.....	5
2.1.1. Struct udi_cdc_comm_desc_t.....	5
2.1.2. Struct udi_cdc_data_desc_t.....	5
2.2. Macro Definitions.....	5
2.2.1. Content of Interface Descriptors.....	5
2.2.2. Macro UDI_CDC_COMM_DESC.....	9
2.2.3. Macro UDI_CDC_COMM_EP_SIZE.....	10
2.2.4. Macro UDI_CDC_DATA_DESC_COMMON.....	10
2.2.5. Macro UDI_CDC_DATA_DESC_FS.....	10
2.2.6. Macro UDI_CDC_DATA_DESC_HS.....	10
2.2.7. Macro UDI_CDC_DATA_EPS_FS_SIZE.....	10
2.2.8. Macro UDI_CDC_DATA_EPS_HS_SIZE.....	10
2.2.9. Macro UDI_CDC_IAD_DESC.....	10
2.3. Function Definitions.....	10
2.3.1. Interface for Application with Single CDC Interface Support.....	10
2.3.2. Interface for Application with Multi CDC Interfaces Support.....	13
3. Quick Start Guide for USB Device Communication Class Device Module (UDI CDC).....	18
3.1. Basic Use Case.....	18
3.1.1. Setup Steps.....	18
3.1.2. Usage Steps.....	18
3.2. Advanced Use Cases.....	19
3.3. CDC in a Composite Device.....	20
3.3.1. Setup Steps.....	20
3.3.2. Usage Steps.....	20
3.4. Change USB Speed.....	22
3.4.1. Setup Steps.....	22
3.4.2. Usage Steps.....	22
3.5. Use USB Strings.....	22
3.5.1. Setup Steps.....	22
3.5.2. Usage Steps.....	23
3.6. Use USB Remote Wakeup Feature.....	23
3.6.1. Setup Steps.....	23
3.6.2. Usage Steps.....	23
3.7. Bus Power Application Recommendations.....	24
3.7.1. Setup Steps.....	24
3.7.2. Usage Steps.....	24
3.8. USB Dynamic Serial Number.....	25
3.8.1. Setup Steps.....	25

3.8.2. Usage Steps.....	25
4. Configuration File Examples.....	27
4.1. conf_usb.h.....	27
4.1.1. UDI CDC Single.....	27
4.1.2. UDI CDC Multiple (Composite).....	28
4.2. conf_clock.h.....	33
4.2.1. XMEGA (USB).....	33
4.2.2. AT32UC3A0, AT32UC3A1, AT32UC3B Devices (USBB).....	34
4.2.3. AT32UC3A3 and AT32UC3A4 Devices (USBB with High Speed Support).....	35
4.2.4. AT32UC3C, ATUCXXD, ATUCXXL3U, ATUCXXL4U Devices (USBC).....	35
4.2.5. SAM3S, SAM3SD, SAM4S Devices (UPD: USB Peripheral Device).....	36
4.2.6. SAM3U Device (UPDHS: USB Peripheral Device High Speed).....	37
4.2.7. SAM3X and SAM3A Devices (UOTGHS: USB OTG High Speed).....	38
4.3. conf_clocks.h.....	39
4.3.1. SAM D21 Device (USB).....	39
4.4. conf_board.h.....	42
4.4.1. AT32UC3A0, AT32UC3A1, AT32UC3B Devices (USBB).....	42
4.4.2. AT32UC3A3 and AT32UC3A4 Devices (USBB with High Speed Support).....	42
4.4.3. AT32UC3C, ATUCXXD, ATUCXXL3U, ATUCXXL4U Devices (USBC).....	43
4.4.4. SAM3X and SAM3A Devices (UOTGHS: USB OTG High Speed).....	43
4.4.5. SAM D21 Device (USB).....	43
5. USB Device Basic Setup.....	44
5.1. Custom Configuration.....	44
5.2. VBUS Monitoring.....	45
5.3. USB Device Basic Setup.....	45
5.3.1. USB Device Controller (UDC) - Prerequisites.....	45
5.3.2. USB Device Controller (UDC) - Example Code.....	46
5.3.3. USB Device Controller (UDC) - Workflow.....	47
5.4. conf_clock.h Examples.....	47
6. Document Revision History.....	49

1. Software License

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of Atmel may not be used to endorse or promote products derived from this software without specific prior written permission.
4. This software may only be redistributed and used in connection with an Atmel microcontroller product.

THIS SOFTWARE IS PROVIDED BY ATMEL "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT ARE EXPRESSLY AND SPECIFICALLY DISCLAIMED. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

2. API Overview

2.1. Structure Definitions

2.1.1. Struct udi_cdc_comm_desc_t

Interface descriptor with associated functional and endpoint descriptors for the CDC Communication Class interface.

Table 2-1. Members

Type	Name	Description
usb_cdc_acm_desc_t	acm	CDC Abstract Control Model functional descriptor
usb_cdc_call_mgmt_desc_t	call_mgmt	CDC Call Management functional descriptor
usb_ep_desc_t	ep_notify	Notification endpoint descriptor
usb_cdc_hdr_desc_t	header	CDC Header functional descriptor
usb_iface_desc_t	iface	Standard interface descriptor
usb_cdc_union_desc_t	union_desc	CDC Union functional descriptor

2.1.2. Struct udi_cdc_data_desc_t

Interface descriptor with associated endpoint descriptors for the CDC Data Class interface.

Table 2-2. Members

Type	Name	Description
usb_ep_desc_t	ep_in	Data IN endpoint descriptors
usb_ep_desc_t	ep_out	Data OUT endpoint descriptors
usb_iface_desc_t	iface	Standard interface descriptor

2.2. Macro Definitions

2.2.1. Content of Interface Descriptors

Up to seven CDC interfaces can be implemented on a USB device.

2.2.1.1. Macro UDI_CDC_IAD_STRING_ID_0

```
#define UDI_CDC_IAD_STRING_ID_0
```

No string associated to IAD interface.

2.2.1.2. Macro UDI_CDC_COMM_STRING_ID_0

```
#define UDI_CDC_COMM_STRING_ID_0
```

No string associated to COMM interface.

2.2.1.3. Macro UDI_CDC_DATA_STRING_ID_0

```
#define UDI_CDC_DATA_STRING_ID_0
```

No string associated to DATA interface.

2.2.1.4. Macro UDI_CDC_IAD_DESC_0

```
#define UDI_CDC_IAD_DESC_0
```

IAD descriptor for port 0.

2.2.1.5. Macro UDI_CDC_COMM_DESC_0

```
#define UDI_CDC_COMM_DESC_0
```

COMM descriptors for port 0.

2.2.1.6. Macro UDI_CDC_DATA_DESC_0_FS

```
#define UDI_CDC_DATA_DESC_0_FS
```

DATA descriptor for port 0 of a full speed device.

2.2.1.7. Macro UDI_CDC_DATA_DESC_0_HS

```
#define UDI_CDC_DATA_DESC_0_HS
```

DATA descriptor for port 0 of a high speed device.

2.2.1.8. Macro UDI_CDC_IAD_STRING_ID_1

```
#define UDI_CDC_IAD_STRING_ID_1
```

No string associated to IAD interface.

2.2.1.9. Macro UDI_CDC_COMM_STRING_ID_1

```
#define UDI_CDC_COMM_STRING_ID_1
```

No string associated to COMM interface.

2.2.1.10. Macro UDI_CDC_DATA_STRING_ID_1

```
#define UDI_CDC_DATA_STRING_ID_1
```

2.2.1.11. Macro UDI_CDC_IAD_DESC_1

```
#define UDI_CDC_IAD_DESC_1
```

2.2.1.12. Macro UDI_CDC_COMM_DESC_1

```
#define UDI_CDC_COMM_DESC_1
```

2.2.1.13. Macro UDI_CDC_DATA_DESC_1_FS

```
#define UDI_CDC_DATA_DESC_1_FS
```

2.2.1.14. Macro UDI_CDC_DATA_DESC_1_HS

```
#define UDI_CDC_DATA_DESC_1_HS
```

2.2.1.15. Macro UDI_CDC_IAD_STRING_ID_2

```
#define UDI_CDC_IAD_STRING_ID_2
```

No string associated to IAD interface.

2.2.1.16. Macro UDI_CDC_COMM_STRING_ID_2

```
#define UDI_CDC_COMM_STRING_ID_2
```

No string associated to COMM interface.

2.2.1.17. Macro UDI_CDC_DATA_STRING_ID_2

```
#define UDI_CDC_DATA_STRING_ID_2
```

2.2.1.18. Macro UDI_CDC_IAD_DESC_2

```
#define UDI_CDC_IAD_DESC_2
```

2.2.1.19. Macro UDI_CDC_COMM_DESC_2

```
#define UDI_CDC_COMM_DESC_2
```

2.2.1.20. Macro UDI_CDC_DATA_DESC_2_FS

```
#define UDI_CDC_DATA_DESC_2_FS
```

2.2.1.21. Macro UDI_CDC_DATA_DESC_2_HS

```
#define UDI_CDC_DATA_DESC_2_HS
```

2.2.1.22. Macro UDI_CDC_IAD_STRING_ID_3

```
#define UDI_CDC_IAD_STRING_ID_3
```

No string associated to IAD interface.

2.2.1.23. Macro UDI_CDC_COMM_STRING_ID_3

```
#define UDI_CDC_COMM_STRING_ID_3
```

No string associated to COMM interface.

2.2.1.24. Macro UDI_CDC_DATA_STRING_ID_3

```
#define UDI_CDC_DATA_STRING_ID_3
```

2.2.1.25. Macro UDI_CDC_IAD_DESC_3

```
#define UDI_CDC_IAD_DESC_3
```

2.2.1.26. Macro UDI_CDC_COMM_DESC_3

```
#define UDI_CDC_COMM_DESC_3
```

2.2.1.27. Macro UDI_CDC_DATA_DESC_3_FS

```
#define UDI_CDC_DATA_DESC_3_FS
```

2.2.1.28. Macro UDI_CDC_DATA_DESC_3_HS

```
#define UDI_CDC_DATA_DESC_3_HS
```

2.2.1.29. Macro UDI_CDC_IAD_STRING_ID_4

```
#define UDI_CDC_IAD_STRING_ID_4
```

No string associated to IAD interface.

2.2.1.30. Macro UDI_CDC_COMM_STRING_ID_4

```
#define UDI_CDC_COMM_STRING_ID_4
```

No string associated to COMM interface.

2.2.1.31. Macro UDI_CDC_DATA_STRING_ID_4

```
#define UDI_CDC_DATA_STRING_ID_4
```

2.2.1.32. Macro UDI_CDC_IAD_DESC_4

```
#define UDI_CDC_IAD_DESC_4
```

2.2.1.33. Macro UDI_CDC_COMM_DESC_4

```
#define UDI_CDC_COMM_DESC_4
```

2.2.1.34. Macro UDI_CDC_DATA_DESC_4_FS

```
#define UDI_CDC_DATA_DESC_4_FS
```

2.2.1.35. Macro UDI_CDC_DATA_DESC_4_HS

```
#define UDI_CDC_DATA_DESC_4_HS
```

2.2.1.36. Macro UDI_CDC_IAD_STRING_ID_5

```
#define UDI_CDC_IAD_STRING_ID_5
```

No string associated to IAD interface.

2.2.1.37. Macro UDI_CDC_COMM_STRING_ID_5

```
#define UDI_CDC_COMM_STRING_ID_5
```

No string associated to COMM interface.

2.2.1.38. Macro UDI_CDC_DATA_STRING_ID_5

```
#define UDI_CDC_DATA_STRING_ID_5
```

2.2.1.39. Macro UDI_CDC_IAD_DESC_5

```
#define UDI_CDC_IAD_DESC_5
```

2.2.1.40. Macro UDI_CDC_COMM_DESC_5

```
#define UDI_CDC_COMM_DESC_5
```

2.2.1.41. Macro UDI_CDC_DATA_DESC_5_FS

```
#define UDI_CDC_DATA_DESC_5_FS
```

2.2.1.42. Macro UDI_CDC_DATA_DESC_5_HS

```
#define UDI_CDC_DATA_DESC_5_HS
```

2.2.1.43. Macro UDI_CDC_IAD_STRING_ID_6

```
#define UDI_CDC_IAD_STRING_ID_6
```

No string associated to IAD interface.

2.2.1.44. Macro UDI_CDC_COMM_STRING_ID_6

```
#define UDI_CDC_COMM_STRING_ID_6
```

2.2.1.45. Macro UDI_CDC_DATA_STRING_ID_6

```
#define UDI_CDC_DATA_STRING_ID_6
```

2.2.1.46. Macro UDI_CDC_IAD_DESC_6

```
#define UDI_CDC_IAD_DESC_6
```

2.2.1.47. Macro UDI_CDC_COMM_DESC_6

```
#define UDI_CDC_COMM_DESC_6
```

2.2.1.48. Macro UDI_CDC_DATA_DESC_6_FS

```
#define UDI_CDC_DATA_DESC_6_FS
```

2.2.1.49. Macro UDI_CDC_DATA_DESC_6_HS

```
#define UDI_CDC_DATA_DESC_6_HS
```

2.2.2. Macro UDI_CDC_COMM_DESC

```
#define UDI_CDC_COMM_DESC(port)
```

Content of CDC COMM interface descriptor for all speeds.

2.2.3. Macro UDI_CDC_COMM_EP_SIZE

```
#define UDI_CDC_COMM_EP_SIZE
```

CDC communication endpoints size for all speeds.

2.2.4. Macro UDI_CDC_DATA_DESC_COMMON

```
#define UDI_CDC_DATA_DESC_COMMON
```

Content of CDC DATA interface descriptors.

2.2.5. Macro UDI_CDC_DATA_DESC_FS

```
#define UDI_CDC_DATA_DESC_FS (port)
```

Content of CDC DATA interface descriptors for FS.

2.2.6. Macro UDI_CDC_DATA_DESC_HS

```
#define UDI_CDC_DATA_DESC_HS (port)
```

Content of CDC DATA interface descriptors for HS.

2.2.7. Macro UDI_CDC_DATA_EPS_FS_SIZE

```
#define UDI_CDC_DATA_EPS_FS_SIZE
```

CDC data endpoints size for FS speed (8B, 16B, 32B, 64B).

2.2.8. Macro UDI_CDC_DATA_EPS_HS_SIZE

```
#define UDI_CDC_DATA_EPS_HS_SIZE
```

CDC data endpoints size for HS speed (512B only).

2.2.9. Macro UDI_CDC_IAD_DESC

```
#define UDI_CDC_IAD_DESC (port)
```

Content of CDC IAD interface descriptor for all speeds.

2.3. Function Definitions

2.3.1. Interface for Application with Single CDC Interface Support

2.3.1.1. Function udi_cdc_ctrl_signal_dcd()

Notify a state change of Data Carrier Detect (DCD) signal.

```
void udi_cdc_ctrl_signal_dcd(  
    bool b_set)
```

Table 2-3. Parameters

Data direction	Parameter name	Description
[in]	b_set	DCD is enabled if true, else disabled

2.3.1.2. Function udi_cdc_ctrl_signal_dsr()

Notify a state change of Data Set Ready (DSR) signal.

```
void udi_cdc_ctrl_signal_dsr(  
    bool b_set)
```

Table 2-4. Parameters

Data direction	Parameter name	Description
[in]	b_set	DSR is enabled if true, else disabled

2.3.1.3. Function udi_cdc_signal_framing_error()

Notify a framing error.

```
void udi_cdc_signal_framing_error( void )
```

2.3.1.4. Function udi_cdc_signal_parity_error()

Notify a parity error.

```
void udi_cdc_signal_parity_error( void )
```

2.3.1.5. Function udi_cdc_signal_overrun()

Notify a overrun.

```
void udi_cdc_signal_overrun( void )
```

2.3.1.6. Function udi_cdc_get_nb_received_data()

Gets the number of byte received.

```
iram_size_t udi_cdc_get_nb_received_data( void )
```

Returns

The number of data available.

2.3.1.7. Function udi_cdc_is_rx_ready()

This function checks if a character has been received on the CDC line.

```
bool udi_cdc_is_rx_ready( void )
```

Returns

1 if a byte is ready to be read.

2.3.1.8. Function udi_cdc_getc()

Waits and gets a value on CDC line.

```
int udi_cdc_getc( void )
```

Returns

Value read on CDC line.

2.3.1.9. Function udi_cdc_read_buf()

Reads a RAM buffer on CDC line.

```
iram_size_t udi_cdc_read_buf(
    void * buf,
    iram_size_t size)
```

Table 2-5. Parameters

Data direction	Parameter name	Description
[out]	buf	Values read
[in]	size	Number of value read

Returns

The number of data remaining.

2.3.1.10. Function udi_cdc_get_free_tx_buffer()

Gets the number of free byte in TX buffer.

```
iram_size_t udi_cdc_get_free_tx_buffer( void )
```

Returns

The number of free byte in TX buffer.

2.3.1.11. Function udi_cdc_is_tx_ready()

This function checks if a new character sent is possible. The type int is used to support scanf redirection from compiler .lib file.

```
bool udi_cdc_is_tx_ready( void )
```

Returns

1 if a new character can be sent.

2.3.1.12. Function udi_cdc_putc()

Puts a byte on CDC line.

```
int udi_cdc_putc(
    int value)
```

The type int is used to support printf redirection from compiler LIB.

Table 2-6. Parameters

Data direction	Parameter name	Description
[in]	value	Value to put

Returns

1 if function was successfully done, otherwise 0.

2.3.1.13. Function udi_cdc_write_buf()

Writes a RAM buffer on CDC line.

```
iram_size_t udi_cdc_write_buf(
    const void * buf,
    iram_size_t size)
```

Table 2-7. Parameters

Data direction	Parameter name	Description
[in]	buf	Values to write
[in]	size	Number of value to write

Returns

The number of data remaining.

2.3.2. Interface for Application with Multi CDC Interfaces Support**2.3.2.1. Function udi_cdc_multi_ctrl_signal_dcd()**

Notify a state change of DCD signal.

```
void udi_cdc_multi_ctrl_signal_dcd(
    uint8_t port,
    bool b_set)
```

Table 2-8. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage
[in]	b_set	DCD is enabled if true, else disabled

2.3.2.2. Function udi_cdc_multi_ctrl_signal_dsr()

Notify a state change of DSR signal.

```
void udi_cdc_multi_ctrl_signal_dsr(
    uint8_t port,
    bool b_set)
```

Table 2-9. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage
[in]	b_set	DSR is enabled if true, else disabled

2.3.2.3. Function udi_cdc_multi_signal_framing_error()

Notify a framing error.

```
void udi_cdc_multi_signal_framing_error(  
    uint8_t port)
```

Table 2-10. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage

2.3.2.4. Function udi_cdc_multi_signal_parity_error()

Notify a parity error.

```
void udi_cdc_multi_signal_parity_error(  
    uint8_t port)
```

Table 2-11. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage

2.3.2.5. Function udi_cdc_multi_signal_overrun()

Notify a overrun.

```
void udi_cdc_multi_signal_overrun(  
    uint8_t port)
```

Table 2-12. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage

2.3.2.6. Function udi_cdc_multi_get_nb_received_data()

Gets the number of byte received.

```
iram_size_t udi_cdc_multi_get_nb_received_data(  
    uint8_t port)
```

Table 2-13. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage

Returns

The number of data available.

2.3.2.7. Function udi_cdc_multi_is_rx_ready()

This function checks if a character has been received on the CDC line.

```
bool udi_cdc_multi_is_rx_ready(  
    uint8_t port)
```

Table 2-14. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage

Returns

1 if a byte is ready to be read.

2.3.2.8. Function udi_cdc_multi_getc()

Waits and gets a value on CDC line.

```
int udi_cdc_multi_getc(  
    uint8_t port)
```

Table 2-15. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage

Returns

Value read on CDC line.

2.3.2.9. Function udi_cdc_multi_read_buf()

Reads a RAM buffer on CDC line.

```
iram_size_t udi_cdc_multi_read_buf(  
    uint8_t port,  
    void * buf,  
    iram_size_t size)
```

Table 2-16. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage
[out]	buf	Values read
[in]	size	Number of values read

Returns

The number of data remaining.

2.3.2.10. Function udi_cdc_multi_get_free_tx_buffer()

Gets the number of free byte in TX buffer.

```
iram_size_t udi_cdc_multi_get_free_tx_buffer(  
    uint8_t port)
```

Table 2-17. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage

Returns

The number of free byte in TX buffer.

2.3.2.11. Function udi_cdc_multi_is_tx_ready()

This function checks if a new character sent is possible.

```
bool udi_cdc_multi_is_tx_ready(  
    uint8_t port)
```

The type int is used to support scanf redirection from compiler LIB.

Table 2-18. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage

Returns

1 if a new character can be sent.

2.3.2.12. Function udi_cdc_multi_putc()

Puts a byte on CDC line, and the type int is used to support printf redirection from compiler LIB.

```
int udi_cdc_multi_putc(  
    uint8_t port,  
    int value)
```

Table 2-19. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage
[in]	value	Value to put

Returns

1 if function was successfully done, otherwise 0.

2.3.2.13. Function udi_cdc_multi_write_buf()

Writes a RAM buffer on CDC line.

```
iram_size_t udi_cdc_multi_write_buf(  
    uint8_t port,
```

```
const void * buf,  
iram_size_t size)
```

Table 2-20. Parameters

Data direction	Parameter name	Description
[in]	port	Communication port number to manage
[in]	buf	Values to write
[in]	size	Number of value to write

Returns

The number of data remaining.

3. Quick Start Guide for USB Device Communication Class Device Module (UDI CDC)

This is the quick start guide for the [USB Device Interface CDC Module \(UDI CDC\)](#) with step-by-step instructions on how to configure and use the modules in a selection of use cases.

The use cases contain or highlights several code fragments. The code fragments in the steps for setup can be copied into a custom initialization function, while the steps for usage can be copied into, e.g., the main application function.

3.1. Basic Use Case

In this basic use case, the "USB CDC (Single Interface Device)" module is used with only one communication port. The "USB CDC (Composite Device)" module usage is described in [Advanced Use Cases](#).

3.1.1. Setup Steps

As a USB device, it follows common USB device setup steps. Refer to [USB Device Basic Setup](#).

3.1.2. Usage Steps

3.1.2.1. Example Code

Content of conf_usb.h:

```
#define UDI_CDC_ENABLE_EXT(port) my_callback_cdc_enable()  
extern bool my_callback_cdc_enable(void);  
#define UDI_CDC_DISABLE_EXT(port) my_callback_cdc_disable()  
extern void my_callback_cdc_disable(void);  
#define UDI_CDC_LOW_RATE  
  
#define UDI_CDC_DEFAULT_RATE 115200  
#define UDI_CDC_DEFAULT_STOPBITS CDC_STOP_BITS_1  
#define UDI_CDC_DEFAULT_PARITY CDC_PAR_NONE  
#define UDI_CDC_DEFAULT_DATABITS 8  
  
#include "udi_cdc_conf.h" // At the end of conf_usb.h file
```

Add to application C-file:

```
static bool my_flag_authorize_cdc_transfert = false;  
bool my_callback_cdc_enable(void)  
{  
    my_flag_authorize_cdc_transfert = true;  
    return true;  
}  
  
void my_callback_cdc_disable(void)  
{  
    my_flag_authorize_cdc_transfert = false;  
}  
  
void task(void)  
{  
    if (my_flag_authorize_cdc_transfert) {  
        udi_cdc_putc('A');  
        udi_cdc_getc();  
    }  
}
```

```
}
```

3.1.2.2. Workflow

1. Ensure that conf_usb.h is available and contains the following configuration, which is the USB device CDC configuration:

```
#define USB_DEVICE_SERIAL_NAME "12...EF" // Disk SN for CDC
```

Note: The USB serial number is mandatory when a CDC interface is used.

```
#define UDI_CDC_ENABLE_EXT(port) my_callback_cdc_enable()  
extern bool my_callback_cdc_enable(void);
```

Note: After the device enumeration (detecting and identifying USB devices), the USB host starts the device configuration. When the USB CDC interface from the device is accepted by the host, the USB host enables this interface and the UDI_CDC_ENABLE_EXT() callback function is called and return true. Thus, when this event is received, the data transfer on CDC interface are authorized.

```
#define UDI_CDC_DISABLE_EXT(port) my_callback_cdc_disable()  
extern void my_callback_cdc_disable(void);
```

Note: When the USB device is unplugged or is reset by the USB host, the USB interface is disabled and the UDI_CDC_DISABLE_EXT() callback function is called. Thus, the data transfer must be stopped on CDC interface.

```
#define UDI_CDC_LOW_RATE
```

Note: Define it when the transfer CDC Device to Host is a low rate (<512000 bauds) to reduce CDC buffers size.

```
#define UDI_CDC_DEFAULT_RATE 115200  
#define UDI_CDC_DEFAULT_STOPBITS CDC_STOP_BITS_1  
#define UDI_CDC_DEFAULT_PARITY CDC_PAR_NONE  
#define UDI_CDC_DEFAULT_DATABITS 8
```

Note: Default configuration of communication port at startup.

2. Send or wait data on CDC line:

```
// Waits and gets a value on CDC line  
int udi_cdc_getc(void);  
// Reads a RAM buffer on CDC line  
iram_size_t udi_cdc_read_buf(int* buf, iram_size_t size);  
// Puts a byte on CDC line  
int udi_cdc_putc(int value);  
// Writes a RAM buffer on CDC line  
iram_size_t udi_cdc_write_buf(const int* buf, iram_size_t size);
```

3.2. Advanced Use Cases

For more advanced use of the UDI CDC module, see the following use cases:

- [CDC in a Composite Device](#)
- [Change USB Speed](#)
- [Use USB Strings](#)

- Use USB Remote Wakeup Feature
- Bus Power Application Recommendations
- USB Dynamic Serial Number
- Custom Configuration
- VBUS Monitoring

3.3. CDC in a Composite Device

A USB Composite Device is a USB Device which uses more than one USB class. In this use case, the "USB CDC (Composite Device)" module is used to create a USB composite device. Thus, this USB module can be associated with another "Composite Device" module, like "USB HID Mouse (Composite Device)".

Also, you can refer to application note [AVR4902 ASF - USB Composite Device](#).

3.3.1. Setup Steps

For the setup code of this use case to work, the [Basic Use Case](#) must be followed.

3.3.2. Usage Steps

3.3.2.1. Example Code

Content of conf_usb.h:

```
#define USB_DEVICE_EP_CTRL_SIZE 64
#define USB_DEVICE_NB_INTERFACE (X+2)
#define USB_DEVICE_MAX_EP (X+3)

#define UDI_CDC_DATA_EP_IN_0           (1 | USB_EP_DIR_IN) // TX
#define UDI_CDC_DATA_EP_OUT_0          (2 | USB_EP_DIR_OUT) // RX
#define UDI_CDC_COMM_EP_0              (3 | USB_EP_DIR_IN) // Notify
endpoint
#define UDI_CDC_COMM_IFACE_NUMBER_0   X+0
#define UDI_CDC_DATA_IFACE_NUMBER_0   X+1

#define UDI_COMPOSITE_DESC_T \
    usb_iad_desc_t udi_cdc_iad; \
    udi_cdc_comm_desc_t udi_cdc_comm; \
    udi_cdc_data_desc_t udi_cdc_data; \
    ...
#define UDI_COMPOSITE_DESC_FS \
    .udi_cdc_iad           = UDI_CDC_IAD_DESC_0, \
    .udi_cdc_comm          = UDI_CDC_COMM_DESC_0, \
    .udi_cdc_data          = UDI_CDC_DATA_DESC_0_FS, \
    ...
#define UDI_COMPOSITE_DESC_HS \
    .udi_cdc_iad           = UDI_CDC_IAD_DESC_0, \
    .udi_cdc_comm          = UDI_CDC_COMM_DESC_0, \
    .udi_cdc_data          = UDI_CDC_DATA_DESC_0_HS, \
    ...
#define UDI_COMPOSITE_API \
    &udi_api_cdc_comm, \
    &udi_api_cdc_data, \
    ...


```

3.3.2.2. Workflow

1. Ensure that conf_usb.h is available and contains the following parameters required for a USB composite device configuration:

```
// Endpoint control size, This must be:  
// - 8, 16, 32 or 64 for full speed device (8 is recommended to save RAM)  
// - 64 for a high speed device  
#define USB_DEVICE_EP_CTRL_SIZE 64  
// Total Number of interfaces on this USB device.  
// Add 2 for CDC.  
#define USB_DEVICE_NB_INTERFACE (X+2)  
// Total number of endpoints on this USB device.  
// This must include each endpoint for each interface.  
// Add 3 for CDC.  
#define USB_DEVICE_MAX_EP (X+3)
```

2. Ensure that conf_usb.h contains the description of composite device:

```
// The endpoint numbers chosen by you for the CDC.  
// The endpoint numbers starting from 1.  
#define UDI_CDC_DATA_EP_IN_0 (1 | USB_EP_DIR_IN) // TX  
#define UDI_CDC_DATA_EP_OUT_0 (2 | USB_EP_DIR_OUT) // RX  
#define UDI_CDC_COMM_EP_0 (3 | USB_EP_DIR_IN) //  
Notify endpoint  
// The interface index of an interface starting from 0  
#define UDI_CDC_COMM_IFACE_NUMBER_0 X+0  
#define UDI_CDC_DATA_IFACE_NUMBER_0 X+1
```

3. Ensure that conf_usb.h contains the following parameters required for a USB composite device configuration:

```
// USB Interfaces descriptor structure  
#define UDI_COMPOSITE_DESC_T \  
...  
usb_iad_desc_t udi_cdc_iad; \  
udi_cdc_comm_desc_t udi_cdc_comm; \  
udi_cdc_data_desc_t udi_cdc_data; \  
...  
// USB Interfaces descriptor value for Full Speed  
#define UDI_COMPOSITE_DESC_FS \  
...  
.udi_cdc_iad = UDI_CDC_IAD_DESC_0, \  
.udi_cdc_comm = UDI_CDC_COMM_DESC_0, \  
.udi_cdc_data = UDI_CDC_DATA_DESC_0_FS, \  
...  
// USB Interfaces descriptor value for High Speed  
#define UDI_COMPOSITE_DESC_HS \  
...  
.udi_cdc_iad = UDI_CDC_IAD_DESC_0, \  
.udi_cdc_comm = UDI_CDC_COMM_DESC_0, \  
.udi_cdc_data = UDI_CDC_DATA_DESC_0_HS, \  
...  
// USB Interface APIs  
#define UDI_COMPOSITE_API \  
...  
&udi_api_cdc_comm, \  
&udi_api_cdc_data, \  
...
```

Note: The descriptors order given in the four lists above must be the same as the order defined by all interface indexes. The interface index orders are defined through UDI_X_IFACE_NUMBER defines. Also, the CDC requires a USB Interface Association Descriptor (IAD) for composite device.

3.4. Change USB Speed

In this use case, the USB device is used with different USB speeds.

3.4.1. Setup Steps

Prior to implement this use case, be sure to have already applied the UDI module "basic use case".

3.4.2. Usage Steps

3.4.2.1. Example Code

Content of conf_usb.h:

```
#if // Low speed
#define USB_DEVICE_LOW_SPEED
// #define USB_DEVICE_HS_SUPPORT

#elif // Full speed
// #define USB_DEVICE_LOW_SPEED
// #define USB_DEVICE_HS_SUPPORT
#elif // High speed
// #define USB_DEVICE_LOW_SPEED
#define USB_DEVICE_HS_SUPPORT

#endif
```

3.4.2.2. Workflow

1. Ensure that conf_usb.h is available and contains the following parameters required for a USB device low speed (1.5Mbit/s):

```
#define USB_DEVICE_LOW_SPEED
// #define USB_DEVICE_HS_SUPPORT
```

2. Ensure that conf_usb.h contains the following parameters required for a USB device full speed (12Mbit/s):

```
// #define USB_DEVICE_LOW_SPEED
// #define USB_DEVICE_HS_SUPPORT
```

3. Ensure that conf_usb.h contains the following parameters required for a USB device high speed (480Mbit/s):

```
// #define USB_DEVICE_LOW_SPEED
#define USB_DEVICE_HS_SUPPORT
```

3.5. Use USB Strings

In this use case, the usual USB strings are added in the USB device.

3.5.1. Setup Steps

Prior to implement this use case, be sure to have already applied the UDI module "basic use case".

3.5.2. Usage Steps

3.5.2.1. Example Code

Content of conf_usb.h:

```
#define USB_DEVICE_MANUFACTURE_NAME "Manufacture name"  
#define USB_DEVICE_PRODUCT_NAME "Product name"  
#define USB_DEVICE_SERIAL_NAME "12...EF"
```

3.5.2.2. Workflow

1. Ensure that conf_usb.h is available and contains the following parameters required to enable different USB strings:

```
// Static ASCII name for the manufacture  
#define USB_DEVICE_MANUFACTURE_NAME "Manufacture name"
```

```
// Static ASCII name for the product  
#define USB_DEVICE_PRODUCT_NAME "Product name"
```

```
// Static ASCII name to enable and set a serial number  
#define USB_DEVICE_SERIAL_NAME "12...EF"
```

3.6. Use USB Remote Wakeup Feature

In this use case, the USB remote wakeup feature is enabled.

3.6.1. Setup Steps

Prior to implement this use case, be sure to have already applied the UDI module "basic use case".

3.6.2. Usage Steps

3.6.2.1. Example Code

Content of conf_usb.h:

```
#define USB_DEVICE_ATTR \  
(USB_CONFIG_ATTR_REMOTE_WAKEUP | USB_CONFIG_ATTR_..._POWERED)  
#define UDC_REMOTEWAKEUP_ENABLE() my_callback_remotewakeup_enable()  
extern void my_callback_remotewakeup_enable(void);  
#define UDC_REMOTEWAKEUP_DISABLE() my_callback_remotewakeup_disable()  
extern void my_callback_remotewakeup_disable(void);
```

Add to application C-file:

```
void my_callback_remotewakeup_enable(void)  
{  
    // Enable application wakeup events (e.g. enable GPIO interrupt)  
}  
void my_callback_remotewakeup_disable(void)  
{  
    // Disable application wakeup events (e.g. disable GPIO interrupt)  
}  
  
void my_interrupt_event(void)  
{
```

```

        udc_remotewakeup();
    }

```

3.6.2.2. Workflow

1. Ensure that conf_usb.h is available and contains the following parameters required to enable the remote wakeup feature:

```

// Authorizes the remote wakeup feature
#define USB_DEVICE_ATTR (USB_CONFIG_ATTR_REMOTE_WAKEUP |
USB_CONFIG_ATTR_POWERED)

// Define callback called when the host enables the remotewakeup feature
#define UDC_REMOTEWAKEUP_ENABLE() my_callback_remotewakeup_enable()
extern void my_callback_remotewakeup_enable(void);

// Define callback called when the host disables the remotewakeup feature
#define UDC_REMOTEWAKEUP_DISABLE() my_callback_remotewakeup_disable()
extern void my_callback_remotewakeup_disable(void);

```

2. Send a remote wakeup (USB upstream):

```
udc_remotewakeup();
```

3.7. Bus Power Application Recommendations

In this use case, the USB device bus power feature is enabled. This feature requires a correct power consumption management.

3.7.1. Setup Steps

Prior to implement this use case, be sure to have already applied the UDI module "basic use case".

3.7.2. Usage Steps

3.7.2.1. Example Code

Content of conf_usb.h:

```

#define USB_DEVICE_ATTR (USB_CONFIG_ATTR_BUS_POWERED)
#define UDC_SUSPEND_EVENT() user_callback_suspend_action()
extern void user_callback_suspend_action(void)
#define UDC_RESUME_EVENT() user_callback_resume_action()
extern void user_callback_resume_action(void)

```

Add to application C-file:

```

void user_callback_suspend_action(void)
{
    // Disable hardware component to reduce power consumption
}
void user_callback_resume_action(void)
{
    // Re-enable hardware component
}

```

3.7.2.2. Workflow

1. Ensure that conf_usb.h is available and contains the following parameters:

```
// Authorizes the BUS power feature  
#define USB_DEVICE_ATTR (USB_CONFIG_ATTR_BUS_POWERED)  
  
// Define callback called when the host suspend the USB line  
#define UDC_SUSPEND_EVENT() user_callback_suspend_action()  
extern void user_callback_suspend_action(void);  
  
// Define callback called when the host or device resume the USB line  
#define UDC_RESUME_EVENT() user_callback_resume_action()  
extern void user_callback_resume_action(void);
```

2. Reduce power consumption in suspend mode (max. 2.5mA on VBUS):

```
void user_callback_suspend_action(void)  
{  
    turn_off_components();  
}
```

3.8. USB Dynamic Serial Number

In this use case, the USB serial strings are dynamic. For a static serial string refer to [Use USB Strings](#).

3.8.1. Setup Steps

Prior to implement this use case, be sure to have already applied the UDI module "basic use case".

3.8.2. Usage Steps

3.8.2.1. Example Code

Content of conf_usb.h:

```
#define USB_DEVICE_SERIAL_NAME  
#define USB_DEVICE_GET_SERIAL_NAME_POINTER serial_number  
#define USB_DEVICE_GET_SERIAL_NAME_LENGTH 12  
extern uint8_t serial_number[];
```

Add to application C-file:

```
uint8_t serial_number[USB_DEVICE_GET_SERIAL_NAME_LENGTH];  
void init_build_usb_serial_number(void)  
{  
    serial_number[0] = 'A';  
    serial_number[1] = 'B';  
    ...  
    serial_number[USB_DEVICE_GET_SERIAL_NAME_LENGTH-1] = 'C';  
}
```

3.8.2.2. Workflow

1. Ensure that conf_usb.h is available and contains the following parameters required to enable a USB serial number string dynamically:

```
#define USB_DEVICE_SERIAL_NAME // Define this empty  
#define USB_DEVICE_GET_SERIAL_NAME_POINTER serial_number // Give  
serial array pointer
```

```
#define USB_DEVICE_GET_SERIAL_NAME_LENGTH 12 // Give size of serial  
array  
extern uint8_t serial_number[]; // Declare external serial array
```

2. Before starting USB stack, initialize the serial array:

```
uint8_t serial_number[USB_DEVICE_GET_SERIAL_NAME_LENGTH];  
void init_build_usb_serial_number(void)  
{  
    serial_number[0] = 'A';  
    serial_number[1] = 'B';  
    ...  
    serial_number[USB_DEVICE_GET_SERIAL_NAME_LENGTH-1] = 'C';  
}
```

4. Configuration File Examples

4.1. conf_usb.h

4.1.1. UDI CDC Single

```
/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
 */

#ifndef _CONF_USB_H_
#define _CONF_USB_H_

#include "compiler.h"

#warning You must refill the following definitions with a correct values

#define USB_DEVICE_VENDOR_ID           USB_VID_ATMEL
#define USB_DEVICE_PRODUCT_ID          USB_PID_ATMEL ASF_CDC
#define USB_DEVICE_MAJOR_VERSION       1
#define USB_DEVICE_MINOR_VERSION      0
#define USB_DEVICE_POWER              100 // Consumption on Vbus line
(mA)
#define USB_DEVICE_ATTR                \
    (USB_CONFIG_ATTR_SELF_POWERED) \
// (USB_CONFIG_ATTR_BUS_POWERED) \
// (USB_CONFIG_ATTR_REMOTE_WAKEUP|USB_CONFIG_ATTR_SELF_POWERED) \
// (USB_CONFIG_ATTR_REMOTE_WAKEUP|USB_CONFIG_ATTR_BUS_POWERED)

// #define USB_DEVICE_MANUFACTURE_NAME      "Manufacture name"
// #define USB_DEVICE_PRODUCT_NAME          "Product name"
// #define USB_DEVICE_SERIAL_NAME          "12...EF"

#if (UC3A3||UC3A4)
#define USB_DEVICE_HS_SUPPORT
#endif

// #define UDC_VBUS_EVENT(b_vbus_high)      user_callback_vbus_action(b_vbus_high)
// extern void user_callback_vbus_action(bool b_vbus_high);
// #define UDC_SOFTWARE_RESET()            user_callback_software_reset()
// extern void user_callback_software_reset(void);
// #define UDC_SUSPEND_EVENT()            user_callback_suspend_action()
// extern void user_callback_suspend_action(void);
// #define UDC_RESUME_EVENT()             user_callback_resume_action()
// extern void user_callback_resume_action(void);
// Mandatory when USB_DEVICE_ATTR authorizes remote wakeup feature
// #define UDC_REMOTEWAKEUP_ENABLE()       user_callback_remotewakeup_enable()
// extern void user_callback_remotewakeup_enable(void);
// #define UDC_REMOTEWAKEUP_DISABLE()     user_callback_remotewakeup_disable()
// extern void user_callback_remotewakeup_disable(void);
// When a extra string descriptor must be supported
// other than manufacturer, product and serial string
// #define UDC_GET_EXTRA_STRING()
```

```

#define UDI_CDC_PORT_NB 1

#define UDI_CDC_ENABLE_EXT(port) true
#define UDI_CDC_DISABLE_EXT(port)
#define UDI_CDC_RX_NOTIFY(port)
#define UDI_CDC_TX_EMPTY_NOTIFY(port)
#define UDI_CDC_SET_CODING_EXT(port,cfg)
#define UDI_CDC_SET_DTR_EXT(port,set)
#define UDI_CDC_SET_RTS_EXT(port,set)

// #define UDI_CDC_ENABLE_EXT(port) my_callback_cdc_enable()
// extern bool my_callback_cdc_enable(void);
// #define UDI_CDC_DISABLE_EXT(port) my_callback_cdc_disable()
// extern void my_callback_cdc_disable(void);
// #define UDI_CDC_RX_NOTIFY(port) my_callback_rx_notify(port)
// extern void my_callback_rx_notify(uint8_t port);
// #define UDI_CDC_TX_EMPTY_NOTIFY(port) my_callback_tx_empty_notify(port)
// extern void my_callback_tx_empty_notify(uint8_t port);
// #define UDI_CDC_SET_CODING_EXT(port,cfg) my_callback_config(port,cfg)
// extern void my_callback_config(uint8_t port, usb_cdc_line_coding_t * cfg);
// #define UDI_CDC_SET_DTR_EXT(port,set) my_callback_cdc_set_dtr(port,set)
// extern void my_callback_cdc_set_dtr(uint8_t port, bool b_enable);
// #define UDI_CDC_SET_RTS_EXT(port,set) my_callback_cdc_set_rts(port,set)
// extern void my_callback_cdc_set_rts(uint8_t port, bool b_enable);

#define UDI_CDC_LOW_RATE

#define UDI_CDC_DEFAULT_RATE 115200
#define UDI_CDC_DEFAULT_STOPBITS CDC_STOP_BITS_1
#define UDI_CDC_DEFAULT_PARITY CDC_PAR_NONE
#define UDI_CDC_DEFAULT_DATABITS 8

#include "udi_cdc_conf.h"

#endif // _CONF_USB_H_

```

4.1.2. UDI CDC Multiple (Composite)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
 */

#ifndef _CONF_USB_H_
#define _CONF_USB_H_

#include "compiler.h"

#warning You must refill the following definitions with a correct values

#define USB_DEVICE_VENDOR_ID USB_VID_ATMEL
#define USB_DEVICE_PRODUCT_ID 0xFFFF
#define USB_DEVICE_MAJOR_VERSION 1
#define USB_DEVICE_MINOR_VERSION 0
#define USB_DEVICE_POWER 100 // Consumption on VBUS line
(mA)

```

```

#define  USB_DEVICE_ATTR          \
    (USB_CONFIG_ATTR_SELF_POWERED) \
// (USB_CONFIG_ATTR_BUS_POWERED) \
// (USB_CONFIG_ATTR_REMOTE_WAKEUP|USB_CONFIG_ATTR_SELF_POWERED) \
// (USB_CONFIG_ATTR_REMOTE_WAKEUP|USB_CONFIG_ATTR_BUS_POWERED)

// #define  USB_DEVICE_MANUFACTURE_NAME      "Manufacture name"
// #define  USB_DEVICE_PRODUCT_NAME          "Product name"
// #define  USB_DEVICE_SERIAL_NAME           "12...EF" // Disk SN for MSC

// #define  USB_DEVICE_LOW_SPEED

#if (UC3A3||UC3A4)
#define  USB_DEVICE_HS_SUPPORT
#endif

// #define  UDC_VBUS_EVENT(b_vbus_high)      user_callback_vbus_action(b_vbus_high)
// extern void user_callback_vbus_action(bool b_vbus_high);
// #define  UDC_SOF_EVENT()                 user_callback_sof_action()
// extern void user_callback_sof_action(void);
// #define  UDC_SUSPEND_EVENT()            user_callback_suspend_action()
// extern void user_callback_suspend_action(void);
// #define  UDC_RESUME_EVENT()            user_callback_resume_action()
// extern void user_callback_resume_action(void);
// #define  UDC_REMOTEWAKEUP_ENABLE()     user_callback_remotewakeup_enable()
// extern void user_callback_remotewakeup_enable(void);
// #define  UDC_REMOTEWAKEUP_DISABLE()    user_callback_remotewakeup_disable()
// extern void user_callback_remotewakeup_disable(void);
// #define  UDC_GET_EXTRA_STRING()

#define  USB_DEVICE_EP_CTRL_SIZE        64
#define  USB_DEVICE_NB_INTERFACE       1 // 1 or more
#define  USB_DEVICE_MAX_EP             1 // 0 to max endpoint requested by interfaces

#define  UDI_CDC_PORT_NB 1

#define  UDI_CDC_ENABLE_EXT(port)      true
#define  UDI_CDC_DISABLE_EXT(port)
#define  UDI_CDC_RX_NOTIFY(port)
#define  UDI_CDC_TX_EMPTY_NOTIFY(port)
#define  UDI_CDC_SET_CODING_EXT(port,cfg)
#define  UDI_CDC_SET_DTR_EXT(port,set)
#define  UDI_CDC_SET_RTS_EXT(port,set)
/*
 * #define UDI_CDC_ENABLE_EXT(port) my_callback_cdc_enable();
 * extern bool my_callback_cdc_enable(void);
 * #define UDI_CDC_DISABLE_EXT(port) my_callback_cdc_disable();
 * extern void my_callback_cdc_disable(void);
 * #define UDI_CDC_RX_NOTIFY(port) my_callback_rx_notify(port)
 * extern void my_callback_rx_notify(uint8_t port);
 * #define UDI_CDC_TX_EMPTY_NOTIFY(port) my_callback_tx_empty_notify(port)
 * extern void my_callback_tx_empty_notify(uint8_t port);
 * #define UDI_CDC_SET_CODING_EXT(port,cfg) my_callback_config(port,cfg)
 * extern void my_callback_config(uint8_t port, usb_cdc_line_coding_t * cfg);
 * #define UDI_CDC_SET_DTR_EXT(port,set) my_callback_cdc_set_dtr(port,set)
 * extern void my_callback_cdc_set_dtr(uint8_t port, bool b_enable);
 * #define UDI_CDC_SET_RTS_EXT(port,set) my_callback_cdc_set_rts(port,set)
*/

```

```

/* extern void my_callback_cdc_set_rts(uint8_t port, bool b_enable);
 */

#define UDI_CDC_LOW_RATE

#define UDI_CDC_DEFAULT_RATE           115200
#define UDI_CDC_DEFAULT_STOPBITS      CDC_STOP_BITS_1
#define UDI_CDC_DEFAULT_PARITY        CDC_PAR_NONE
#define UDI_CDC_DEFAULT_DATABITS      8

#define UDI_CDC_DATA_EP_IN_0          (1 | USB_EP_DIR_IN) // TX
#define UDI_CDC_DATA_EP_OUT_0         (2 | USB_EP_DIR_OUT) // RX
#define UDI_CDC_COMM_EP_0             (3 | USB_EP_DIR_IN) // Notify
endpoint
#define UDI_CDC_DATA_EP_IN_2          (4 | USB_EP_DIR_IN) // TX
#define UDI_CDC_DATA_EP_OUT_2         (5 | USB_EP_DIR_OUT) // RX
#define UDI_CDC_COMM_EP_2             (6 | USB_EP_DIR_IN) // Notify
endpoint
#define UDI_CDC_DATA_EP_IN_3          (7 | USB_EP_DIR_IN) // TX
#define UDI_CDC_DATA_EP_OUT_3         (8 | USB_EP_DIR_OUT) // RX
#define UDI_CDC_COMM_EP_3             (9 | USB_EP_DIR_IN) // Notify
endpoint

#define UDI_CDC_COMM_IFACE_NUMBER_0    0
#define UDI_CDC_DATA_IFACE_NUMBER_0   1
#define UDI_CDC_COMM_IFACE_NUMBER_2    2
#define UDI_CDC_DATA_IFACE_NUMBER_2   3
#define UDI_CDC_COMM_IFACE_NUMBER_3    4
#define UDI_CDC_DATA_IFACE_NUMBER_3   5

#define UDI_MSC_GLOBAL_VENDOR_ID      \
    'A', 'T', 'M', 'E', 'L', '-', ' ', ' '
#define UDI_MSC_GLOBAL_PRODUCT_VERSION \
    '1', '.', '0', '0'

#define UDI_MSC_ENABLE_EXT()          true
#define UDI_MSC_DISABLE_EXT()
#define UDI_MSC_NOTIFY_TRANS_EXT()
/*
 * #define UDI_MSC_ENABLE_EXT() my_callback_msc_enable()
 * extern bool my_callback_msc_enable(void);
 * #define UDI_MSC_DISABLE_EXT() my_callback_msc_disable()
 * extern void my_callback_msc_disable(void);
 * #define UDI_MSC_NOTIFY_TRANS_EXT() msc_notify_trans()
 * extern void msc_notify_trans(void) {
 */

#define UDI_MSC_EP_IN                 (1 | USB_EP_DIR_IN)
#define UDI_MSC_EP_OUT                (2 | USB_EP_DIR_OUT)

#define UDI_MSC_IFACE_NUMBER          0

#define UDI_HID_MOUSE_ENABLE_EXT()     true
#define UDI_HID_MOUSE_DISABLE_EXT()
// #define UDI_HID_MOUSE_ENABLE_EXT() my_callback_mouse_enable()
// extern bool my_callback_mouse_enable(void);
// #define UDI_HID_MOUSE_DISABLE_EXT() my_callback_mouse_disable()

```

```

// extern void my_callback_mouse_disable(void);

#define UDI_HID_MOUSE_EP_IN           (1 | USB_EP_DIR_IN)
#define UDI_HID_MOUSE_IFACE_NUMBER    0


#define UDI_HID_KBD_ENABLE_EXT()      true
#define UDI_HID_KBD_DISABLE_EXT()
// #define UDI_HID_KBD_ENABLE_EXT() my_callback_keyboard_enable()
// extern bool my_callback_keyboard_enable(void);
// #define UDI_HID_KBD_DISABLE_EXT() my_callback_keyboard_disable()
// extern void my_callback_keyboard_disable(void);
#define UDI_HID_KBD_CHANGE_LED(value)
// #define UDI_HID_KBD_CHANGE_LED(value) my_callback_keyboard_led(value)
// extern void my_callback_keyboard_led(uint8_t value)

#define UDI_HID_KBD_EP_IN           (1 | USB_EP_DIR_IN)
#define UDI_HID_KBD_IFACE_NUMBER    0


#define UDI_HID_GENERIC_ENABLE_EXT()   true
#define UDI_HID_GENERIC_DISABLE_EXT()
#define UDI_HID_GENERIC_REPORT_OUT(ptr)
#define UDI_HID_GENERIC_SET_FEATURE(f)
/*
 * #define UDI_HID_GENERIC_ENABLE_EXT() my_callback_generic_enable()
 * extern bool my_callback_generic_enable(void);
 * #define UDI_HID_GENERIC_DISABLE_EXT() my_callback_generic_disable()
 * extern void my_callback_generic_disable(void);
 * #define UDI_HID_GENERIC_REPORT_OUT(ptr) my_callback_generic_report_out(ptr)
 * extern void my_callback_generic_report_out(uint8_t *report);
 * #define UDI_HID_GENERIC_SET_FEATURE(f) my_callback_generic_set_feature(f)
 * extern void my_callback_generic_set_feature(uint8_t *report_feature);
 */
#define UDI_HID_REPORT_IN_SIZE        64
#define UDI_HID_REPORT_OUT_SIZE       64
#define UDI_HID_REPORT_FEATURE_SIZE   4
#define UDI_HID_GENERIC_EP_SIZE       64

#define UDI_HID_GENERIC_EP_OUT        (2 | USB_EP_DIR_OUT)
#define UDI_HID_GENERIC_EP_IN         (1 | USB_EP_DIR_IN)

#define UDI_HID_GENERIC_IFACE_NUMBER  0


#define UDI_PHDC_ENABLE_EXT()         true
#define UDI_PHDC_DISABLE_EXT()

#define UDI_PHDC_DATAMSG_FORMAT      USB_PHDC_DATAMSG_FORMAT_11073_20601
#define UDI_PHDC_SPECIALIZATION      {0x2345} // Define in 11073_20601

#define UDI_PHDC_QOS_OUT             \
(USB_PHDC_QOS_MEDIUM_BETTER|USB_PHDC_QOS_HIGH_BEST)
#define UDI_PHDC_QOS_IN              \
(USB_PHDC_QOS_LOW_GOOD|USB_PHDC_QOS_MEDIUM_BETTER|

```

```

USB_PHDC_QOS_MEDIUM_BEST)

#define UDI_PHDC_METADATA_DESC_BULK_IN {0x01,0x02,0x03}
#define UDI_PHDC_METADATA_DESC_BULK_OUT {0x01,0x02,0x03}
#define UDI_PHDC_METADATA_DESC_INT_IN {0x01,0x02,0x03}

#define UDI_PHDC_EP_BULK_OUT (1 | USB_EP_DIR_OUT)
#define UDI_PHDC_EP_BULK_IN (2 | USB_EP_DIR_IN)
#if ((UDI_PHDC_QOS_IN&USB_PHDC_QOS_LOW_GOOD)==USB_PHDC_QOS_LOW_GOOD)
// Only if UDI_PHDC_QOS_IN include USB_PHDC_QOS_LOW_GOOD
#define UDI_PHDC_EP_INTERRUPT_IN (3 | USB_EP_DIR_IN)
#endif

#define UDI_PHDC_EP_SIZE_BULK_OUT 32
#define UDI_PHDC_EP_SIZE_BULK_IN 32
#define UDI_PHDC_EP_SIZE_INT_IN 8

#define UDI_PHDC_IFACE_NUMBER 0

#define UDI_VENDOR_ENABLE_EXT() true
#define UDI_VENDOR_DISABLE_EXT()
#define UDI_VENDOR_SETUP_OUT_RECEIVED() false
#define UDI_VENDOR_SETUP_IN_RECEIVED() false
/*
 * #define UDI_VENDOR_ENABLE_EXT() my_callback_vendor_enable()
 * extern bool my_callback_vendor_enable(void);
 * #define UDI_VENDOR_DISABLE_EXT() my_callback_vendor_disable()
 * extern void my_callback_vendor_disable(void);
 *
 * #define UDI_VENDOR_SETUP_OUT_RECEIVED() my_vendor_setup_out_received()
 * extern bool my_vendor_setup_out_received(void);
 * #define UDI_VENDOR_SETUP_IN_RECEIVED() my_vendor_setup_in_received()
 * extern bool my_vendor_setup_in_received(void);
 */
#define UDI_VENDOR_EPS_SIZE_INT_FS 64
#define UDI_VENDOR_EPS_SIZE_BULK_FS 64
#define UDI_VENDOR_EPS_SIZE_ISO_FS 256

#define UDI_VENDOR_EPS_SIZE_INT_HS 64
#define UDI_VENDOR_EPS_SIZE_BULK_HS 512
#define UDI_VENDOR_EPS_SIZE_ISO_HS 64

#define UDI_VENDOR_EP_INTERRUPT_IN (1 | USB_EP_DIR_IN)
#define UDI_VENDOR_EP_INTERRUPT_OUT (2 | USB_EP_DIR_OUT)
#define UDI_VENDOR_EP_BULK_IN (3 | USB_EP_DIR_IN)
#define UDI_VENDOR_EP_BULK_OUT (4 | USB_EP_DIR_OUT)
#define UDI_VENDOR_EP_ISO_IN (5 | USB_EP_DIR_IN)
#define UDI_VENDOR_EP_ISO_OUT (6 | USB_EP_DIR_OUT)

#define UDI_VENDOR_IFACE_NUMBER 0

//... Eventually add other Interface Configuration

#define UDI_COMPOSITE_DESC_T

```

```

#define UDI_COMPOSITE_DESC_FS
#define UDI_COMPOSITE_DESC_HS
#define UDI_COMPOSITE_API

/* Example for device with cdc, msc and hid mouse interface
#define UDI_COMPOSITE_DESC_T \
    usb_iad_desc_t udi_cdc_iad; \
    udi_cdc_comm_desc_t udi_cdc_comm; \
    udi_cdc_data_desc_t udi_cdc_data; \
    udi_msc_desc_t udi_msc; \
    udi_hid_mouse_desc_t udi_hid_mouse

#define UDI_COMPOSITE_DESC_FS \
    .udi_cdc_iad          = UDI_CDC_IAD_DESC_0, \
    .udi_cdc_comm         = UDI_CDC_COMM_DESC_0, \
    .udi_cdc_data         = UDI_CDC_DATA_DESC_0_FS, \
    .udi_msc              = UDI_MSC_DESC_FS, \
    .udi_hid_mouse        = UDI_HID_MOUSE_DESC

#define UDI_COMPOSITE_DESC_HS \
    .udi_cdc_iad          = UDI_CDC_IAD_DESC_0, \
    .udi_cdc_comm         = UDI_CDC_COMM_DESC_0, \
    .udi_cdc_data         = UDI_CDC_DATA_DESC_0_HS, \
    .udi_msc              = UDI_MSC_DESC_HS, \
    .udi_hid_mouse        = UDI_HID_MOUSE_DESC

#define UDI_COMPOSITE_API \
    &udi_api_cdc_comm, \
    &udi_api_cdc_data, \
    &udi_api_msc, \
    &udi_api_hid_mouse
*/
/* Example of include for interface
#include "udi_msc.h"
#include "udi_hid_kbd.h"
#include "udi_hid_mouse.h"
#include "udi_cdc.h"
#include "udi_phdc.h"
#include "udi_vendor.h"
*/
/* Declaration of callbacks used by USB
#include "callback_def.h"
*/
#endif // _CONF_USB_H_

```

4.2. conf_clock.h

4.2.1. XMEGA (USB)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
 */
#ifndef CONF_CLOCK_H_INCLUDED
#define CONF_CLOCK_H_INCLUDED

```

```

#define CONFIG_USBCLK_SOURCE      USBCLK_SRC_RCOSC
#define CONFIG_OSC_RC32_CAL        48000000UL

#define CONFIG_OSC_AUTOCAL_RC32MHZ_REF_OSC  OSC_ID_USBSOF

#define CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_RC32MHZ
#define CONFIG_SYSCLK_PSADIV       SYSCLK_PSADIV_2
#define CONFIG_SYSCLK_PSBCDIV     SYSCLK_PSBCDIV_1_1

/*
#define CONFIG_PLL0_SOURCE        PLL_SRC_XOSC
#define CONFIG_PLL0_MUL           6
#define CONFIG_PLL0_DIV            1

#define CONFIG_USBCLK_SOURCE      USBCLK_SRC_PLL

#define CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_PLL
#define CONFIG_SYSCLK_PSADIV       SYSCLK_PSADIV_2
#define CONFIG_SYSCLK_PSBCDIV     SYSCLK_PSBCDIV_1_2
*/

#endif /* CONF_CLOCK_H_INCLUDED */

```

4.2.2. AT32UC3A0, AT32UC3A1, AT32UC3B Devices (USBB)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
*/
#ifndef CONF_CLOCK_H_INCLUDED
#define CONF_CLOCK_H_INCLUDED

// ===== System Clock Source Options
//#define CONFIG_SYSCLK_SOURCE      SYSCLK_SRC_RCSYS
//#define CONFIG_SYSCLK_SOURCE      SYSCLK_SRC_OSC0
#define CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_PLL0

// ===== PLL0 Options
#define CONFIG_PLL0_SOURCE         PLL_SRC_OSC0
//#define CONFIG_PLL0_SOURCE         PLL_SRC_OSC1
#define CONFIG_PLL0_MUL            8 /* Fpll = (Fclk * PLL_mul) / PLL_div */
#define CONFIG_PLL0_DIV             2 /* Fpll = (Fclk * PLL_mul) / PLL_div */

// ===== PLL1 Options
//#define CONFIG_PLL1_SOURCE         PLL_SRC_OSC0
//#define CONFIG_PLL1_SOURCE         PLL_SRC_OSC1
//#define CONFIG_PLL1_MUL            8 /* Fpll = (Fclk * PLL_mul) / PLL_div */
//#define CONFIG_PLL1_DIV             2 /* Fpll = (Fclk * PLL_mul) / PLL_div */

// ===== System Clock Bus Division Options
//#define CONFIG_SYSCLK_CPU_DIV      0 /* Fcpu = Fsys/(2 ^ CPU_div) */
//#define CONFIG_SYSCLK_PBA_DIV       0 /* Fpba = Fsys/(2 ^ PBA_div) */
//#define CONFIG_SYSCLK_PBB_DIV       0 /* Fpbb = Fsys/(2 ^ PBB_div) */

// ===== Peripheral Clock Management Options
//#define CONFIG_SYSCLK_INIT_CPUMASK ((1 << SYSCLK_SYSTIMER) | (1 << SYSCLK_OCD))
//#define CONFIG_SYSCLK_INIT_PBAMASK (1 << SYSCLK_USART0)
//#define CONFIG_SYSCLK_INIT_PBBMASK (1 << SYSCLK_HMATRIX)
//#define CONFIG_SYSCLK_INIT_HSBMASK (1 << SYSCLK_MDMA_HSB)

```

```

// ===== USB Clock Source Options
#ifndef CONFIG_USBCLK_SOURCE
#define CONFIG_USBCLK_SOURCE          USBCLK_SRC_OSC0
#endif
#define CONFIG_USBCLK_SOURCE          USBCLK_SRC_PLL0
#ifndef CONFIG_USBCLK_SOURCE
#define CONFIG_USBCLK_DIV             USBCLK_SRC_PLL1
                           1 /* Fusb = Fsys/(2 ^ USB_div) */
#endif
#endif /* CONF_CLOCK_H_INCLUDED */

```

4.2.3. AT32UC3A3 and AT32UC3A4 Devices (USBB with High Speed Support)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
*/
#ifndef CONF_CLOCK_H_INCLUDED
#define CONF_CLOCK_H_INCLUDED

// ===== System Clock Source Options
#ifndef CONFIG_SYSCLK_SOURCE
#define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_RCSYS
#endif
#define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_OSC0
#ifndef CONFIG_SYSCLK_SOURCE
#define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_PLL0
#endif

// ===== PLL0 Options
#define CONFIG_PLL0_SOURCE           PLL_SRC_OSC0
#ifndef CONFIG_PLL0_SOURCE
#define CONFIG_PLL0_SOURCE           PLL_SRC_OSC1
#endif
#define CONFIG_PLL0_MUL              11 /* Fpll = (Fclk * PLL_mul) / PLL_div
*/
#define CONFIG_PLL0_DIV               2 /* Fpll = (Fclk * PLL_mul) / PLL_div */

// ===== PLL1 Options
#ifndef CONFIG_PLL1_SOURCE
#define CONFIG_PLL1_SOURCE           PLL_SRC_OSC0
#endif
#ifndef CONFIG_PLL1_SOURCE
#define CONFIG_PLL1_SOURCE           PLL_SRC_OSC1
#endif
#ifndef CONFIG_PLL1_MUL
#define CONFIG_PLL1_MUL              8 /* Fpll = (Fclk * PLL_mul) / PLL_div */
#endif
#ifndef CONFIG_PLL1_DIV
#define CONFIG_PLL1_DIV               2 /* Fpll = (Fclk * PLL_mul) / PLL_div */
#endif

// ===== System Clock Bus Division Options
#ifndef CONFIG_SYSCLK_CPU_DIV
#define CONFIG_SYSCLK_CPU_DIV         0 /* Fcpu = Fsys/(2 ^ CPU_div) */
#endif
#ifndef CONFIG_SYSCLK_PBA_DIV
#define CONFIG_SYSCLK_PBA_DIV         0 /* Fpba = Fsys/(2 ^ PBA_div) */
#endif
#ifndef CONFIG_SYSCLK_PBB_DIV
#define CONFIG_SYSCLK_PBB_DIV         0 /* Fpbb = Fsys/(2 ^ PBB_div) */
#endif

// ===== Peripheral Clock Management Options
#ifndef CONFIG_SYSCLK_INIT_CPUMASK
#define CONFIG_SYSCLK_INIT_CPUMASK   ((1 << SYSCLK_SYSTIMER) | (1 << SYSCLK_OCD))
#endif
#ifndef CONFIG_SYSCLK_INIT_PBAMASK
#define CONFIG_SYSCLK_INIT_PBAMASK   (1 << SYSCLK_USART0)
#endif
#ifndef CONFIG_SYSCLK_INIT_PBBMASK
#define CONFIG_SYSCLK_INIT_PBBMASK   (1 << SYSCLK_HMATRIX)
#endif
#ifndef CONFIG_SYSCLK_INIT_HSBMASK
#define CONFIG_SYSCLK_INIT_HSBMASK   (1 << SYSCLK_MDMA_HSB)
#endif

// ===== USB Clock Source Options
#define CONFIG_USBCLK_SOURCE          USBCLK_SRC_OSC0
#ifndef CONFIG_USBCLK_SOURCE
#define CONFIG_USBCLK_SOURCE          USBCLK_SRC_PLL0
#endif
#define CONFIG_USBCLK_SOURCE          USBCLK_SRC_PLL1
                           1 /* Fusb = Fsys/(2 ^ USB_div) */
#endif
#endif /* CONF_CLOCK_H_INCLUDED */

```

4.2.4. AT32UC3C, ATUCXXD, ATUCXXL3U, ATUCXXL4U Devices (USBC)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
*/
#ifndef CONF_CLOCK_H_INCLUDED

```

```

#define CONF_CLOCK_H_INCLUDED

// ===== System Clock Source Options
#ifndef CONFIG_SYSCLK_SOURCE      SYSCLK_SRC_RCSYS
#define CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_OSC0
#define CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_OSC1
#define CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_PLL0
#define CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_PLL1
#define CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_RC8M

// ===== PLL0 Options
#define CONFIG_PLL0_SOURCE        PLL_SRC_OSC0
#ifndef CONFIG_PLL0_SOURCE       PLL_SRC_OSC1
#define CONFIG_PLL0_SOURCE        PLL_SRC_RC8M
#define CONFIG_PLL0_MUL           3 /* Fpll = (Fclk * PLL_mul) / PLL_div */
#define CONFIG_PLL0_DIV            1 /* Fpll = (Fclk * PLL_mul) / PLL_div */

// ===== PLL1 Options
#ifndef CONFIG_PLL1_SOURCE       PLL_SRC_OSC0
#define CONFIG_PLL1_SOURCE        PLL_SRC_OSC1
#define CONFIG_PLL1_SOURCE        PLL_SRC_RC8M
#define CONFIG_PLL1_MUL           3 /* Fpll = (Fclk * PLL_mul) / PLL_div */
#define CONFIG_PLL1_DIV            1 /* Fpll = (Fclk * PLL_mul) / PLL_div */

// ===== System Clock Bus Division Options
#ifndef CONFIG_SYSCLK_CPU_DIV     0 /* Fcpu = Fsys/(2 ^ CPU_div) */
#ifndef CONFIG_SYSCLK_PBA_DIV     0 /* Fpba = Fsys/(2 ^ PBA_div) */
#ifndef CONFIG_SYSCLK_PBB_DIV     0 /* Fpbb = Fsys/(2 ^ PBB_div) */
#ifndef CONFIG_SYSCLK_PBC_DIV     0 /* Fpbc = Fsys/(2 ^ PBC_div) */

// ===== Peripheral Clock Management Options
#ifndef CONFIG_SYSCLK_INIT_CPUMASK ((1 << SYSCLK_SYSTIMER) | (1 << SYSCLK_OCD))
#ifndef CONFIG_SYSCLK_INIT_PBAMASK (1 << SYSCLK_USART0)
#ifndef CONFIG_SYSCLK_INIT_PBBMASK (1 << SYSCLK_HMATRIX)
#ifndef CONFIG_SYSCLK_INIT_HSBMASK (1 << SYSCLK MDMA_HSB)

// ===== USB Clock Source Options
#ifndef CONFIG_USBCLK_SOURCE      USBCLK_SRC_OSC0
#ifndef CONFIG_USBCLK_SOURCE       USBCLK_SRC_OSC1
#define CONFIG_USBCLK_SOURCE        USBCLK_SRC_PLL0
#ifndef CONFIG_USBCLK_SOURCE       USBCLK_SRC_PLL1
#define CONFIG_USBCLK_DIV           1 /* Fusb = Fsys/(2 ^ USB_div) */

#endif /* CONF_CLOCK_H_INCLUDED */

```

4.2.5. SAM3S, SAM3SD, SAM4S Devices (UPD: USB Peripheral Device)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
 */

#ifndef CONF_CLOCK_H_INCLUDED
#define CONF_CLOCK_H_INCLUDED

// ===== System Clock (MCK) Source Options
#ifndef CONFIG_SYSCLK_SOURCE      SYSCLK_SRC_SLCK_RC
#ifndef CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_SLCK_XTAL
#ifndef CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_SLCK_BYPASS
#ifndef CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_MAINCK_4M_RC
#ifndef CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_MAINCK_8M_RC
#ifndef CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_MAINCK_12M_RC

```

```

//#define CONFIG_SYSCLK_SOURCE      SYSCLK_SRC_MAINCK_XTAL
//#define CONFIG_SYSCLK_SOURCE      SYSCLK_SRC_MAINCK_BYPASS
#define CONFIG_SYSCLK_SOURCE       SYSCLK_SRC_PLLACK
//#define CONFIG_SYSCLK_SOURCE      SYSCLK_SRC_PLLBCK

// ===== System Clock (MCK) Prescaler Options   (Fmck = Fsys / (SYSCLK_PRES))
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_1
#define CONFIG_SYSCLK_PRES         SYSCLK_PRES_2
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_4
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_8
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_16
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_32
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_64
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_3

// ===== PLL0 (A) Options   (Fpll = (Fclk * PLL_mul) / PLL_div)
// Use mul and div effective values here.
#define CONFIG_PLL0_SOURCE          PLL_SRC_MAINCK_XTAL
#define CONFIG_PLL0_MUL             32
#define CONFIG_PLL0_DIV              3

// ===== PLL1 (B) Options   (Fpll = (Fclk * PLL_mul) / PLL_div)
// Use mul and div effective values here.
#define CONFIG_PLL1_SOURCE          PLL_SRC_MAINCK_XTAL
#define CONFIG_PLL1_MUL             16
#define CONFIG_PLL1_DIV              2

// ===== USB Clock Source Options   (Fusb = FpllX / USB_div)
// Use div effective value here.
//#define CONFIG_USBCLK_SOURCE        USBCLK_SRC_PLL0
#define CONFIG_USBCLK_SOURCE         USBCLK_SRC_PLL1
#define CONFIG_USBCLK_DIV              2

// ===== Target frequency (System clock)
// - XTAL frequency: 12MHz
// - System clock source: PLLA
// - System clock prescaler: 2 (divided by 2)
// - PLLA source: XTAL
// - PLLA output: XTAL * 32 / 3
// - System clock is: 12 * 32 / 3 / 2 = 64MHz
// ===== Target frequency (USB Clock)
// - USB clock source: PLLB
// - USB clock divider: 2 (divided by 2)
// - PLLB output: XTAL * 16 / 2
// - USB clock: 12 * 16 / 2 / 2 = 48MHz

#endif /* CONF_CLOCK_H_INCLUDED */

```

4.2.6. SAM3U Device (UPDHS: USB Peripheral Device High Speed)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
 */

#ifndef CONF_CLOCK_H_INCLUDED
#define CONF_CLOCK_H_INCLUDED

// ===== System Clock (MCK) Source Options
//#define CONFIG_SYSCLK_SOURCE        SYSCLK_SRC_SLCK_RC
//#define CONFIG_SYSCLK_SOURCE        SYSCLK_SRC_SLCK_XTAL

```

```

//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_SLCK_BYPASS
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_MAINCK_4M_RC
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_MAINCK_8M_RC
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_MAINCK_12M_RC
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_MAINCK_XTAL
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_MAINCK_BYPASS
#define CONFIG_SYSCLK_SOURCE           SYSCLK_SRC_PLLACK
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_UPLLCK

// ===== System Clock (MCK) Prescaler Options   (Fmck = Fsys / (SYSCLK_PRES))
//##define CONFIG_SYSCLK_PRES           SYSCLK_PRES_1
#define CONFIG_SYSCLK_PRES            SYSCLK_PRES_2
//##define CONFIG_SYSCLK_PRES           SYSCLK_PRES_4
//##define CONFIG_SYSCLK_PRES           SYSCLK_PRES_8
//##define CONFIG_SYSCLK_PRES           SYSCLK_PRES_16
//##define CONFIG_SYSCLK_PRES           SYSCLK_PRES_32
//##define CONFIG_SYSCLK_PRES           SYSCLK_PRES_64
//##define CONFIG_SYSCLK_PRES           SYSCLK_PRES_3

// ===== PLL0 (A) Options    (Fpll = (Fclk * PLL_mul) / PLL_div)
// Use mul and div effective values here.
#define CONFIG_PLL0_SOURCE            PLL_SRC_MAINCK_XTAL
#define CONFIG_PLL0_MUL               16
#define CONFIG_PLL0_DIV                1

// ===== UPPLL (UTMI) Hardware fixed at 480MHz.

// ===== USB Clock Source fixed at UPPLL.

// ===== Target frequency (System clock)
// - XTAL frequency: 12MHz
// - System clock source: PLLA
// - System clock prescaler: 2 (divided by 2)
// - PLLA source: XTAL
// - PLLA output: XTAL * 16 / 1
// - System clock is: 12 * 16 / 1 / 2 = 96MHz
// ===== Target frequency (USB Clock)
// - USB clock source: UPPLL
// - UPPLL frequency: 480MHz
// - USB clock: 480MHz

#endif /* CONF_CLOCK_H_INCLUDED */

```

4.2.7. SAM3X and SAM3A Devices (UOTGHS: USB OTG High Speed)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
 */

#ifndef CONF_CLOCK_H_INCLUDED
#define CONF_CLOCK_H_INCLUDED

// ===== System Clock (MCK) Source Options
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_SLCK_RC
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_SLCK_XTAL
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_SLCK_BYPASS
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_MAINCK_4M_RC
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_MAINCK_8M_RC
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_MAINCK_12M_RC
//##define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_MAINCK_XTAL

```

```

//#define CONFIG_SYSCLK_SOURCE      SYSCLK_SRC_MAINCK_BYPASS
#define CONFIG_SYSCLK_SOURCE        SYSCLK_SRC_PLLACK
//#define CONFIG_SYSCLK_SOURCE      SYSCLK_SRC_UPLLCK

// ===== System Clock (MCK) Prescaler Options   (Fmck = Fsys / (SYSCLK_PRES))
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_1
#define CONFIG_SYSCLK_PRES         SYSCLK_PRES_2
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_4
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_8
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_16
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_32
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_64
//#define CONFIG_SYSCLK_PRES        SYSCLK_PRES_3

// ===== PLL0 (A) Options   (Fpll = (Fclk * PLL_mul) / PLL_div)
// Use mul and div effective values here.
#define CONFIG_PLL0_SOURCE          PLL_SRC_MAINCK_XTAL
#define CONFIG_PLL0_MUL             14
#define CONFIG_PLL0_DIV              1

// ===== UPLL (UTMI) Hardware fixed at 480MHz.

// ===== USB Clock Source Options   (Fusb = FpllX / USB_div)
// Use div effective value here.
//#define CONFIG_USBCLK_SOURCE       USBCLK_SRC_PLL0
#define CONFIG_USBCLK_SOURCE        USBCLK_SRC_UPLL
#define CONFIG_USBCLK_DIV            1

// ===== Target frequency (System clock)
// - XTAL frequency: 12MHz
// - System clock source: PLLA
// - System clock prescaler: 2 (divided by 2)
// - PLLA source: XTAL
// - PLLA output: XTAL * 14 / 1
// - System clock is: 12 * 14 / 1 /2 = 84MHz
// ===== Target frequency (USB Clock)
// - USB clock source: UPLL
// - USB clock divider: 1 (not divided)
// - UPLL frequency: 480MHz
// - USB clock: 480 / 1 = 480MHz

#endif /* CONF_CLOCK_H_INCLUDED */

```

4.3. conf_clocks.h

4.3.1. SAM D21 Device (USB)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
 */
#include <clock.h>

#ifndef CONF_CLOCKS_H_INCLUDED
#define CONF_CLOCKS_H_INCLUDED

/* System clock bus configuration */
#define CONF_CLOCK_CPU_CLOCK_FAILURE_DETECT      false
#define CONF_CLOCK_FLASH_WAIT_STATES             2

```

```

# define CONF_CLOCK_CPU_DIVIDER SYSTEM_MAIN_CLOCK_DIV_1
# define CONF_CLOCK_APBA_DIVIDER SYSTEM_MAIN_CLOCK_DIV_1
# define CONF_CLOCK_APBB_DIVIDER SYSTEM_MAIN_CLOCK_DIV_1
# define CONF_CLOCK_APBC_DIVIDER SYSTEM_MAIN_CLOCK_DIV_1

/* SYSTEM_CLOCK_SOURCE_OSC8M configuration - Internal 8MHz oscillator */
# define CONF_CLOCK_OSC8M_PRESCALER SYSTEM_OSC8M_DIV_1
# define CONF_CLOCK_OSC8M_ON_DEMAND true
# define CONF_CLOCK_OSC8M_RUN_IN_STANDBY false

/* SYSTEM_CLOCK_SOURCE_XOSC configuration - External clock/oscillator */
# define CONF_CLOCK_XOSC_ENABLE false
# define CONF_CLOCK_XOSC_EXTERNAL_CRYSTAL SYSTEM_CLOCK_EXTERNAL_CRYSTAL
# define CONF_CLOCK_XOSC_EXTERNAL_FREQUENCY 12000000UL
# define CONF_CLOCK_XOSC_STARTUP_TIME SYSTEM_XOSC_STARTUP_32768
# define CONF_CLOCK_XOSC_AUTO_GAIN_CONTROL true
# define CONF_CLOCK_XOSC_ON_DEMAND true
# define CONF_CLOCK_XOSC_RUN_IN_STANDBY false

/* SYSTEM_CLOCK_SOURCE_XOSC32K configuration - External 32KHz crystal/clock
oscillator */
# define CONF_CLOCK_XOSC32K_ENABLE false
# define CONF_CLOCK_XOSC32K_EXTERNAL_CRYSTAL SYSTEM_CLOCK_EXTERNAL_CRYSTAL
# define CONF_CLOCK_XOSC32K_STARTUP_TIME SYSTEM_XOSC32K_STARTUP_65536
# define CONF_CLOCK_XOSC32K_AUTO_AMPLITUDE_CONTROL false
# define CONF_CLOCK_XOSC32K_ENABLE_1KHZ_OUTPUT false
# define CONF_CLOCK_XOSC32K_ENABLE_32KHZ_OUTPUT true
# define CONF_CLOCK_XOSC32K_ON_DEMAND true
# define CONF_CLOCK_XOSC32K_RUN_IN_STANDBY false

/* SYSTEM_CLOCK_SOURCE_OSC32K configuration - Internal 32KHz oscillator */
# define CONF_CLOCK_OSC32K_ENABLE false
# define CONF_CLOCK_OSC32K_STARTUP_TIME SYSTEM_OSC32K_STARTUP_130
# define CONF_CLOCK_OSC32K_ENABLE_1KHZ_OUTPUT true
# define CONF_CLOCK_OSC32K_ENABLE_32KHZ_OUTPUT true
# define CONF_CLOCK_OSC32K_ON_DEMAND true
# define CONF_CLOCK_OSC32K_RUN_IN_STANDBY false

/* SYSTEM_CLOCK_SOURCE_DFLL configuration - Digital Frequency Locked Loop */
# define CONF_CLOCK_DFLL_ENABLE true
# define CONF_CLOCK_DFLL_LOOP_MODE SYSTEM_CLOCK_DFLL_LOOP_MODE_USB_RECOVERY
# define CONF_CLOCK_DFLL_ON_DEMAND true

/* DFLL open loop mode configuration */
# define CONF_CLOCK_DFLL_FINE_VALUE (512)

/* DFLL closed loop mode configuration */
# define CONF_CLOCK_DFLL_SOURCE_GCLK_GENERATOR GCLK_GENERATOR_1
# define CONF_CLOCK_DFLL_MULTIPLY_FACTOR (48000000 / 32768)
# define CONF_CLOCK_DFLL_QUICK_LOCK true
# define CONF_CLOCK_DFLL_TRACK_AFTER_FINE_LOCK true
# define CONF_CLOCK_DFLL_KEEP_LOCK_ON_WAKEUP true
# define CONF_CLOCK_DFLL_ENABLE_CHILL_CYCLE true
# define CONF_CLOCK_DFLL_MAX_COARSE_STEP_SIZE (0x1f / 4)
# define CONF_CLOCK_DFLL_MAX_FINE_STEP_SIZE (0xff / 4)

/* SYSTEM_CLOCK_SOURCE_DPLL configuration - Digital Phase-Locked Loop */
# define CONF_CLOCK_DPLL_ENABLE false

```

```

# define CONF_CLOCK_DPLL_ON_DEMAND true
# define CONF_CLOCK_DPLL_RUN_IN_STANDBY false
# define CONF_CLOCK_DPLL_LOCK_BYPASS false
# define CONF_CLOCK_DPLL_WAKE_UP_FAST false
# define CONF_CLOCK_DPLL_LOW_POWER_ENABLE false

# define CONF_CLOCK_DPLL_LOCK_TIME
SYSTEM_CLOCK_SOURCE_DPLL_LOCK_TIME_DEFAULT
# define CONF_CLOCK_DPLL_REFERENCE_CLOCK
SYSTEM_CLOCK_SOURCE_DPLL_REFERENCE_CLOCK_XOSC32K
# define CONF_CLOCK_DPLL_FILTER
SYSTEM_CLOCK_SOURCE_DPLL_FILTER_DEFAULT

# define CONF_CLOCK_DPLL_REFERENCE_FREQUENCY 32768
# define CONF_CLOCK_DPLL_REFERENCE_DIVIDER 1
# define CONF_CLOCK_DPLL_OUTPUT_FREQUENCY 48000000

/* DPLL GCLK reference configuration */
# define CONF_CLOCK_DPLL_REFERENCE_GCLK_GENERATOR GCLK_GENERATOR_1
/* DPLL GCLK lock timer configuration */
# define CONF_CLOCK_DPLL_LOCK_GCLK_GENERATOR GCLK_GENERATOR_1

/* Set this to true to configure the GCLK when running clocks_init. If set to
 * false, none of the GCLK generators will be configured in clocks_init(). */
# define CONF_CLOCK_CONFIGURE_GCLK true

/* Configure GCLK generator 0 (Main Clock) */
# define CONF_CLOCK_GCLK_0_ENABLE true
# define CONF_CLOCK_GCLK_0_RUN_IN_STANDBY true
# define CONF_CLOCK_GCLK_0_CLOCK_SOURCE SYSTEM_CLOCK_SOURCE_DFLL
# define CONF_CLOCK_GCLK_0_PRESCALER 1
# define CONF_CLOCK_GCLK_0_OUTPUT_ENABLE false

/* Configure GCLK generator 1 */
# define CONF_CLOCK_GCLK_1_ENABLE false
# define CONF_CLOCK_GCLK_1_RUN_IN_STANDBY false
# define CONF_CLOCK_GCLK_1_CLOCK_SOURCE SYSTEM_CLOCK_SOURCE_XOSC32K
# define CONF_CLOCK_GCLK_1_PRESCALER 1
# define CONF_CLOCK_GCLK_1_OUTPUT_ENABLE false

/* Configure GCLK generator 2 (RTC) */
# define CONF_CLOCK_GCLK_2_ENABLE false
# define CONF_CLOCK_GCLK_2_RUN_IN_STANDBY false
# define CONF_CLOCK_GCLK_2_CLOCK_SOURCE SYSTEM_CLOCK_SOURCE_OSC32K
# define CONF_CLOCK_GCLK_2_PRESCALER 32
# define CONF_CLOCK_GCLK_2_OUTPUT_ENABLE false

/* Configure GCLK generator 3 */
# define CONF_CLOCK_GCLK_3_ENABLE true
# define CONF_CLOCK_GCLK_3_RUN_IN_STANDBY false
# define CONF_CLOCK_GCLK_3_CLOCK_SOURCE SYSTEM_CLOCK_SOURCE_OSC8M
# define CONF_CLOCK_GCLK_3_PRESCALER 1
# define CONF_CLOCK_GCLK_3_OUTPUT_ENABLE false

/* Configure GCLK generator 4 */
# define CONF_CLOCK_GCLK_4_ENABLE false
# define CONF_CLOCK_GCLK_4_RUN_IN_STANDBY false
# define CONF_CLOCK_GCLK_4_CLOCK_SOURCE SYSTEM_CLOCK_SOURCE_OSC8M
# define CONF_CLOCK_GCLK_4_PRESCALER 1
# define CONF_CLOCK_GCLK_4_OUTPUT_ENABLE false

```

```

/* Configure GCLK generator 5 */
#define CONF_CLOCK_GCLK_5_ENABLE false
#define CONF_CLOCK_GCLK_5_RUN_IN_STANDBY false
#define CONF_CLOCK_GCLK_5_CLOCK_SOURCE SYSTEM_CLOCK_SOURCE_OSC8M
#define CONF_CLOCK_GCLK_5_PRESCALER 1
#define CONF_CLOCK_GCLK_5_OUTPUT_ENABLE false

/* Configure GCLK generator 6 */
#define CONF_CLOCK_GCLK_6_ENABLE false
#define CONF_CLOCK_GCLK_6_RUN_IN_STANDBY false
#define CONF_CLOCK_GCLK_6_CLOCK_SOURCE SYSTEM_CLOCK_SOURCE_OSC8M
#define CONF_CLOCK_GCLK_6_PRESCALER 1
#define CONF_CLOCK_GCLK_6_OUTPUT_ENABLE false

/* Configure GCLK generator 7 */
#define CONF_CLOCK_GCLK_7_ENABLE false
#define CONF_CLOCK_GCLK_7_RUN_IN_STANDBY false
#define CONF_CLOCK_GCLK_7_CLOCK_SOURCE SYSTEM_CLOCK_SOURCE_OSC8M
#define CONF_CLOCK_GCLK_7_PRESCALER 1
#define CONF_CLOCK_GCLK_7_OUTPUT_ENABLE false

/* Configure GCLK generator 8 */
#define CONF_CLOCK_GCLK_8_ENABLE false
#define CONF_CLOCK_GCLK_8_RUN_IN_STANDBY false
#define CONF_CLOCK_GCLK_8_CLOCK_SOURCE SYSTEM_CLOCK_SOURCE_OSC8M
#define CONF_CLOCK_GCLK_8_PRESCALER 1
#define CONF_CLOCK_GCLK_8_OUTPUT_ENABLE false

#endif /* CONF_CLOCKS_H_INCLUDED */

```

4.4. conf_board.h

4.4.1. AT32UC3A0, AT32UC3A1, AT32UC3B Devices (USBB)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
*/
#ifndef CONF_BOARD_H_INCLUDED
#define CONF_BOARD_H_INCLUDED

// Enable UART Port
#define CONF_BOARD_COM_PORT

#endif /* CONF_BOARD_H_INCLUDED */

```

4.4.2. AT32UC3A3 and AT32UC3A4 Devices (USBB with High Speed Support)

```

/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
*/
#ifndef CONF_BOARD_H_INCLUDED
#define CONF_BOARD_H_INCLUDED

// Enable UART Port
#define CONF_BOARD_COM_PORT

```

```
#endif /* CONF_BOARD_H_INCLUDED */
```

4.4.3. AT32UC3C, ATUCXXD, ATUCXXL3U, ATUCXXL4U Devices (USBC)

```
/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
*/
#ifndef CONF_BOARD_H_INCLUDED
#define CONF_BOARD_H_INCLUDED

// Enable UART Port
#define CONF_BOARD_COM_PORT

#endif /* CONF_BOARD_H_INCLUDED */
```

4.4.4. SAM3X and SAM3A Devices (UOTGHS: USB OTG High Speed)

```
/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
*/
#ifndef CONF_BOARD_H_INCLUDED
#define CONF_BOARD_H_INCLUDED

// UART module is used
#define CONF_BOARD_UART_CONSOLE
#define CONF_BOARD_USB_PORT

#endif /* CONF_BOARD_H_INCLUDED */
```

4.4.5. SAM D21 Device (USB)

```
/*
 * Support and FAQ: visit <a href="http://www.atmel.com/design-support/">Atmel
Support</a>
*/
#ifndef CONF_BOARD_H_INCLUDED
#define CONF_BOARD_H_INCLUDED

/* Enable USB VBUS detect */
#define CONF_BOARD_USB_VBUS_DETECT

#endif /* CONF_BOARD_H_INCLUDED */
```

5. USB Device Basic Setup

5.1. Custom Configuration

The following USB Device configuration must be included in the conf_usb.h file of the application:

1. USB_DEVICE_VENDOR_ID (Word).

Vendor ID provided by USB org (Atmel 0x03EB).

2. USB_DEVICE_PRODUCT_ID (Word).

Product ID (Referenced in usb_atmel.h).

3. USB_DEVICE_MAJOR_VERSION (Byte).

Major version of the device.

4. USB_DEVICE_MINOR_VERSION (Byte).

Minor version of the device.

5. USB_DEVICE_MANUFACTURE_NAME (string).

ASCII name for the manufacture.

6. USB_DEVICE_PRODUCT_NAME (string).

ASCII name for the product.

7. USB_DEVICE_SERIAL_NAME (string).

ASCII name to enable and set a serial number.

8. USB_DEVICE_POWER (Numeric).

(unit mA) Maximum device power.

9. USB_DEVICE_ATTR (Byte).

USB attributes available:

- **USB_CONFIG_ATTR_SELF_POWERED**
- **USB_CONFIG_ATTR_REMOTE_WAKEUP**

Note: If remote wake is enabled, this defines remotewakeup callbacks.

10. USB_DEVICE_LOW_SPEED (Only defined).

Force the USB Device to run in low speed.

11. USB_DEVICE_HS_SUPPORT (Only defined).

Authorize the USB Device to run in high speed.

12. USB_DEVICE_MAX_EP (Byte).

Define the maximum endpoint number used by the USB Device.

This one is already defined in the UDI default configuration. E.g.:

- When endpoint control 0x00, endpoint 0x01, and endpoint 0x82 is used, then **USB_DEVICE_MAX_EP=2**
- When only endpoint control 0x00 is used, then **USB_DEVICE_MAX_EP=0**

- When endpoint 0x01 and endpoint 0x81 is used, then USB_DEVICE_MAX_EP=1 (configuration not possible on USBB interface)

5.2. VBUS Monitoring

The VBUS monitoring is used only for USB SELF Power application.

- By default the USB device is automatically attached when VBUS is high or when USB starts for devices without internal VBUS monitoring. conf_usb.h file does not contain definition USB_DEVICE_ATTACH_AUTO_DISABLE.

```
//#define USB_DEVICE_ATTACH_AUTO_DISABLE
```

- Add custom VBUS monitoring. conf_usb.h file contains define USB_DEVICE_ATTACH_AUTO_DISABLE:

```
#define USB_DEVICE_ATTACH_AUTO_DISABLE
```

User C-file contains:

```
// Authorize VBUS monitoring
if (!udc_include_vbus_monitoring()) {
    // Implement custom VBUS monitoring via GPIO or other
}
Event_VBUS_present() // VBUS interrupt or GPIO interrupt or other
{
    // Attach USB Device
    udc_attach();
}
```

- Case of battery charging. conf_usb.h file contains define USB_DEVICE_ATTACH_AUTO_DISABLE:

```
#define USB_DEVICE_ATTACH_AUTO_DISABLE
```

User C-file contains:

```
Event VBUS present() // VBUS interrupt or GPIO interrupt or ...
{
    // Authorize battery charging, but wait key press to start USB.
}
Event Key press()
{
    // Stop batteries charging
    // Start USB
    udc_attach();
}
```

5.3. USB Device Basic Setup

5.3.1. USB Device Controller (UDC) - Prerequisites

Common prerequisites for all USB devices.

This module is based on USB device stack full interrupt driven, and supporting sleepmgr. For AVR® and Atmel® | SMART ARM®-based SAM3/4 devices the clock services is supported. For SAM D21 devices the clock driver is supported.

The following procedure must be executed to set up the project correctly:

- Specify the clock configuration:
 - XMEGA® USB devices need 48MHz clock input. XMEGA USB devices need CPU frequency higher than 12MHz. You can use either an internal RC 48MHz auto calibrated by Start of Frames or an external OSC.
 - UC3 and SAM3/4 devices without USB high speed support need 48MHz clock input. You must use a PLL and an external OSC.
 - UC3 and SAM3/4 devices with USB high speed support need 12MHz clock input. You must use an external OSC.
 - UC3 devices with USBC hardware need CPU frequency higher than 25MHz
 - SAM D21 devices without USB high speed support need 48MHz clock input. You should use DFLL with USBCRM.
- In conf_board.h, the define CONF_BOARD_USB_PORT must be added to enable USB lines. (Not mandatory for all boards).
- Enable interrupts
- Initialize the clock service

The usage of sleep manager service is optional, but recommended to reduce power consumption:

- Initialize the sleep manager service
- Activate sleep mode when the application is in IDLE state

For AVR and SAM3/4 devices, add to the initialization code:

```
sysclk_init();
irq_initialize_vectors();
cpu_irq_enable();
board_init();
sleepmgr_init(); // Optional
```

For SAM D21 devices, add to the initialization code:

```
system_init();
irq_initialize_vectors();
cpu_irq_enable();
sleepmgr_init(); // Optional
```

Add to the main IDLE loop:

```
sleepmgr_enter_sleep(); // Optional
```

5.3.2. USB Device Controller (UDC) - Example Code

Common example code for all USB devices.

Content of conf_usb.h:

```
#define USB_DEVICE_VENDOR_ID 0x03EB
#define USB_DEVICE_PRODUCT_ID 0xFFFF
#define USB_DEVICE_MAJOR_VERSION 1
#define USB_DEVICE_MINOR_VERSION 0
#define USB_DEVICE_POWER 100
#define USB_DEVICE_ATTR_USB_CONFIG_ATTR_BUS_POWERED
```

Add to application C-file:

```
void usb_init(void)
{
```

```

    udc_start();
}

```

5.3.3. USB Device Controller (UDC) - Workflow

Common workflow for all USB devices.

1. Ensure that `conf_usb.h` is available and contains the following configuration, which is the main USB device configuration:

```

// Vendor ID provided by USB org (Atmel 0x03EB)
#define USB_DEVICE_VENDOR_ID 0x03EB // Type Word
// Product ID (Atmel PID referenced in usb_atmel.h)
#define USB_DEVICE_PRODUCT_ID 0xFFFF // Type Word
// Major version of the device
#define USB_DEVICE_MAJOR_VERSION 1 // Type Byte
// Minor version of the device
#define USB_DEVICE_MINOR_VERSION 0 // Type Byte
// Maximum device power (mA)
#define USB_DEVICE_POWER 100 // Type 9-bits
// USB attributes to enable features
#define USB_DEVICE_ATTR_USB_CONFIG_ATTR_BUS_POWERED // Flags

```

2. Call the USB device stack start function to enable stack and start USB:

```

udc_start();

```

Note: In case of USB dual roles (Device and Host) managed through USB OTG connector (USB ID pin), the call of `udc_start()` must be removed and replaced by `uhc_start()`. Refer to section "Dual roles" for further information in the application note: [Atmel AVR4950: ASF - USB Host Stack](#)

5.4. conf_clock.h Examples

Content of XMEGA `conf_clock.h`:

```

// Configuration based on internal RC:
// USB clock need of 48MHz
#define CONFIG_USBCLK_SOURCE          USBCLK_SRC_RCOSC
#define CONFIG_OSC_RC32_CAL           48000000UL
#define CONFIG_OSC_AUTOCAL_RC32MHZ_REF_OSC  OSC_ID_USBSOF
// CPU clock need of clock > 12MHz to run with USB (Here 24MHz)
#define CONFIG_SYSCLK_SOURCE          SYSCLK_SRC_RC32MHZ
#define CONFIG_SYSCLK_PSADIV          SYSCLK_PSADIV_2
#define CONFIG_SYSCLK_PSBCDIV         SYSCLK_PSBCDIV_1_1

```

Content of `conf_clock.h` for AT32UC3A0, AT32UC3A1, and AT32UC3B devices (USBB):

```

// Configuration based on 12MHz external OSC:
#define CONFIG_PLL1_SOURCE            PLL_SRC_OSC0
#define CONFIG_PLL1_MUL               8
#define CONFIG_PLL1_DIV               2
#define CONFIG_USBCLK_SOURCE          USBCLK_SRC_PLL1
#define CONFIG_USBCLK_DIV             1 // Fusb = Fsys/(2 ^ USB_div)

```

Content of `conf_clock.h` for AT32UC3A3 and AT32UC3A4 devices (USBB with high speed support):

```

// Configuration based on 12MHz external OSC:
#define CONFIG_USBCLK_SOURCE          USBCLK_SRC_OSC0
#define CONFIG_USBCLK_DIV              1 // Fusb = Fsys/(2 ^ USB_div)

```

Content of conf_clock.h for AT32UC3C, ATUCXXD, ATUCXXL3U, and ATUCXXL4U devices (USBC):

```
// Configuration based on 12MHz external OSC:  
#define CONFIG_PLL1_SOURCE          PLL_SRC_OSC0  
#define CONFIG_PLL1_MUL             8  
#define CONFIG_PLL1_DIV             2  
#define CONFIG_USBCLK_SOURCE        USBCLK_SRC_PLL1  
#define CONFIG_USBCLK_DIV           1 // Fusb = Fsys/(2 ^ USB_div)  
// CPU clock need of clock > 25MHz to run with USBC  
#define CONFIG_SYSCLK_SOURCE        SYSCLK_SRC_PLL1
```

Content of conf_clock.h for SAM3S, SAM3SD, and SAM4S devices (UPD: USB Peripheral Device):

```
// PLL (B) Options (Fpll = (Fclk * PLL_mul) / PLL_div)  
#define CONFIG_PLL1_SOURCE          PLL_SRC_MAINCK_XTAL  
#define CONFIG_PLL1_MUL             16  
#define CONFIG_PLL1_DIV             2  
// USB Clock Source Options (Fusb = FpllX / USB_div)  
#define CONFIG_USBCLK_SOURCE        USBCLK_SRC_PLL1  
#define CONFIG_USBCLK_DIV           2
```

Content of conf_clock.h for SAM3U device (UPDHS: USB Peripheral Device High Speed):

```
// USB Clock Source fixed at UPLL.
```

Content of conf_clock.h for SAM3X and SAM3A devices (UOTGHS: USB OTG High Speed):

```
// USB Clock Source fixed at UPLL.  
#define CONFIG_USBCLK_SOURCE        USBCLK_SRC_UPLL  
#define CONFIG_USBCLK_DIV           1
```

Content of conf_clocks.h for SAM D21 devices (USB):

```
// System clock bus configuration  
# define CONF_CLOCK_FLASH_WAIT_STATES          2  
  
// USB Clock Source fixed at DFLL.  
// SYSTEM_CLOCK_SOURCE_DFLL configuration - Digital Frequency Locked Loop  
# define CONF_CLOCK_DFLL_ENABLE                 true  
# define CONF_CLOCK_DFLL_LOOP_MODE              SYSTEM_CLOCK_DFLL_LOOP_MODE_USB_RECOVERY  
# define CONF_CLOCK_DFLL_ON_DEMAND              true  
  
// Set this to true to configure the GCLK when running clocks_init.  
// If set to false, none of the GCLK generators will be configured in clocks_init().  
# define CONF_CLOCK_CONFIGURE_GCLK              true  
  
// Configure GCLK generator 0 (Main Clock)  
# define CONF_CLOCK_GCLK_0_ENABLE                true  
# define CONF_CLOCK_GCLK_0_RUN_IN_STANDBY       true  
# define CONF_CLOCK_GCLK_0_CLOCK_SOURCE          SYSTEM_CLOCK_SOURCE_DFLL  
# define CONF_CLOCK_GCLK_0_PRESCALER             1  
# define CONF_CLOCK_GCLK_0_OUTPUT_ENABLE         false
```

6. Document Revision History

Doc. Rev.	Date	Comments
42337B	12/2015	Fixed typos
42337A	12/2014	Initial release



Atmel® | Enabling Unlimited Possibilities®



Atmel Corporation 1600 Technology Drive, San Jose, CA 95110 USA T: (+1)(408) 441.0311 F: (+1)(408) 436.4200 | www.atmel.com

© 2015 Atmel Corporation. / Rev.: Atmel-42337B-USB-Device-Interface-UDI-for-Communication-Class-Device-CDC_AT09332_Application Note-12/2015

Atmel®, Atmel logo and combinations thereof, Enabling Unlimited Possibilities®, AVR®, XMEGA®, and others are registered trademarks or trademarks of Atmel Corporation in U.S. and other countries. ARM®, ARM Connected® logo, and others are registered trademarks of ARM Ltd. Other terms and product names may be trademarks of others.

DISCLAIMER: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN THE ATTEL TERMS AND CONDITIONS OF SALES LOCATED ON THE ATTEL WEBSITE, ATTEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATTEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS AND PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATTEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and products descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

SAFETY-CRITICAL, MILITARY, AND AUTOMOTIVE APPLICATIONS DISCLAIMER: Atmel products are not designed for and will not be used in connection with any applications where the failure of such products would reasonably be expected to result in significant personal injury or death ("Safety-Critical Applications") without an Atmel officer's specific written consent. Safety-Critical Applications include, without limitation, life support devices and systems, equipment or systems for the operation of nuclear facilities and weapons systems. Atmel products are not designed nor intended for use in military or aerospace applications or environments unless specifically designated by Atmel as military-grade. Atmel products are not designed nor intended for use in automotive applications unless specifically designated by Atmel as automotive-grade.