# TU0546 Tutorial SoftConsole v4.0 and Libero SoC v11.7





Power Matters.\*

Microsemi Corporate Headquarters
One Enterprise, Aliso Viejo,
CA 92656 USA
Within the USA: +1 (800) 713-4113
Outside the USA: +1 (949) 380-6100
Fax: +1 (949) 215-4996
Email: sales.support@microsemi.com
www.microsemi.com

© 2017 Microsemi Corporation. All rights reserved. Microsemi and the Microsemi logo are trademarks of Microsemi Corporation. All other trademarks and service marks are the property of their respective owners.

Microsemi makes no warranty, representation, or guarantee regarding the information contained herein or the suitability of its products and services for any particular purpose, nor does Microsemi assume any liability whatsoever arising out of the application or use of any product or circuit. The products sold hereunder and any other products sold by Microsemi have been subject to limited testing and should not be used in conjunction with mission-critical equipment or applications. Any performance specifications are believed to be reliable but are not verified, and Buyer must conduct and complete all performance and other testing of the products, alone and together with, or installed in, any end-products. Buyer shall not rely on any data and performance specifications or parameters provided by Microsemi. It is the Buyer's responsibility to independently determine suitability of any products and to test and verify the same. The information provided by Microsemi hereunder is provided "as is, where is" and with all faults, and the entire risk associated with such information is entirely with the Buyer. Microsemi does not grant, explicitly or implicitly, to any party any patent rights, licenses, or any other IP rights, whether with regard to such information itself or anything described by such information. Information provided in this document is proprietary to Microsemi, and Microsemi reserves the right to make any changes to the information in this document or to any products and services at any time without notice.

#### **About Microsemi**

Microsemi Corporation (Nasdaq: MSCC) offers a comprehensive portfolio of semiconductor and system solutions for aerospace & defense, communications, data center and industrial markets. Products include high-performance and radiation-hardened analog mixed-signal integrated circuits, FPGAs, SoCs and ASICs; power management products; timing and synchronization devices and precise time solutions, setting the world's standard for time; voice processing devices; RF solutions; discrete components; enterprise storage and communication solutions, security technologies and scalable anti-tamper products; Ethernet solutions; Power-over-Ethernet ICs and midspans; as well as custom design capabilities and services. Microsemi is headquartered in Aliso Viejo, California, and has approximately 4,800 employees globally. Learn more at www.microsemi.com.



# **Contents**

| 1 | Revis | ion History   | . 1 |
|---|-------|---|-----|
|   | 1.1   | Revision 6.0  | . 1 |
|   | 1.2   | Revision 5.0  | . 1 |
|   | 1.3   | Revision 4.0  | . 1 |
|   | 1.4   | Revision 3.0  | . 1 |
|   | 1.5   | Revision 2.0  | . 1 |
|   | 1.6   | Revision 1.0  | . 1 |
| 2 | SoftC | onsole v4.0 and Libero SoC v11.7                                    | . 2 |
|   | 2.1   | Introduction  |     |
|   | 2.2   | Design Requirements   |     |
|   |       | 2.2.1 Associated Project Files                                      |     |
|   | 2.3   | Design Overview   | . 3 |
|   | 2.4   | Step 1: Creating a Libero SoC Project                               |     |
|   |       | 2.4.1 Launching Libero SoC  |     |
|   |       | 2.4.2 Connecting Components in LED_Blink SmartDesign                |     |
|   | 2.5   | Step 2: Generating the Program File                                 |     |
|   | 2.6   | Step 3: Programming the SmartFusion2 Board Using FlashPro           |     |
|   | 2.7   | Step 4: Creating Software Project using SoftConsole 4.0             |     |
|   |       | 2.7.1     Export Firmware       2.7.2     Download Firmware Drivers |     |
|   |       | 2.7.3 Building Software Application using SoftConsole 4.0           |     |
|   |       | 2.7.4 Debugging the Application Project using SoftConsole v4.0      |     |
|   | 2.8   | Conclusion  |     |
| 3 | Apper | ndix: Board Setup for SmartFusion2 Security Evaluation Kit          | 31  |
| 4 | Apper | ndix: Board Setup for SmartFusion2 Advanced Development Kit         | 33  |
| 5 | Apper | ndix: Board Setup for SmartFusion2 Starter Kit                      | 35  |



# **Figures**

| Figure 1  | Design Files Top-Level Structure                      | . 3 |
|-----------|---|-----|
| Figure 2  | Libero SoC Project Manager                            |     |
| Figure 3  | Project Details Window                                |     |
| Figure 4  | Device Selection Window                               |     |
| Figure 5  | Device Settings                                       |     |
| Figure 6  | Design Template Window                                |     |
| Figure 7  | New Project Information Window                        |     |
| Figure 8  | System Builder Dialog Box                             |     |
| Figure 9  | System Builder – Device Features Page                 |     |
| Figure 10 | System Builder Configurator – Select Peripherals Page |     |
| Figure 11 | MSS_GPIO Configurator                                 |     |
| •         | System Builder Configurator – Clock Settings Page     |     |
| Figure 12 |   |     |
| Figure 13 | System Builder Generated System                       |     |
| Figure 14 | LED_Blink Design                                      |     |
| Figure 15 | Generate Component                                    |     |
| Figure 16 | Log Window  |     |
| Figure 17 | Design Flow Window                                    |     |
| Figure 18 | Manage Constraints                                    |     |
| Figure 19 | I/O Attributes  |     |
| Figure 20 | I/O Editor  |     |
| Figure 21 | Generate Bitstream                                    |     |
| Figure 22 | Run Programming Action                                | 14  |
| Figure 23 | Export Firmware                                       | 15  |
| Figure 24 | Export Firmware Dialog Box                            | 15  |
| Figure 25 | Firmware Export Successful                            | 15  |
| Figure 26 | Firmware Catalog                                      | 16  |
| Figure 27 | Firmware Catalog                                      |     |
| Figure 28 | Generate Options                                      | 17  |
| Figure 29 | Warning Message                                       |     |
| Figure 30 | Software Tool Chain                                   |     |
| Figure 31 | Workspace Launcher                                    |     |
| Figure 32 | SoftConsole Window                                    |     |
| Figure 33 | Creating New C Project                                |     |
| Figure 34 | C Project Window                                      |     |
| Figure 35 | C Project - Select Configuration                      |     |
| Figure 36 | C Project - Cross GNU ARM Tool Chain                  |     |
| Figure 37 | Project Explorer - Import                             |     |
| Figure 38 | Import Window   |     |
| Figure 39 | Import - File System                                  |     |
| Figure 40 | Project Explorer                                      |     |
| •         |   |     |
| Figure 41 | Project Explorer window - Properties                  |     |
| Figure 42 | Properties for LED_Blink                              |     |
| Figure 43 | Properties for LED_Blink - Miscellaneous              |     |
| Figure 44 | Properties for LED_Blink - General                    |     |
| Figure 45 | Properties for LED_Blink - Miscellaneous              |     |
| Figure 46 | Project - Build All                                   |     |
| Figure 47 | Problems Window                                       |     |
| Figure 48 | Run - Debug Configurations                            |     |
| Figure 49 | Debug Configurations                                  |     |
| Figure 50 | Debug Tab   |     |
| Figure 51 | Confirm Perspective Switch                            |     |
| Figure 52 | Debugger Perspective Window                           |     |
| Figure 53 | Debug Configurations Option                           |     |
| Figure 54 | Values of Cortex-M3 Internal Registers                | 29  |



| Figure 55 | Values of the Variables in the Source Code                   | 29 |
|-----------|--|----|
| Figure 56 | Assembly Level Instructions                                  | 29 |
| Figure 57 | SmartFusion2 Security Evaluation Kit Setup                   | 31 |
| Figure 58 | SmartFusion2 Security Evaluation Kit Board Jumper Locations  |    |
| Figure 59 | SmartFusion2 Advanced Development Kit Setup                  |    |
| Figure 60 | SmartFusion2 Advanced Development Kit Board Jumper Locations | 34 |
| •         | SmartFusion2 Starter Kit Setup                               |    |



# **Tables**

| Table 1 | Design Requirements                                   | 2  |
|---------|---|----|
| Table 2 | SmartFusion2 Devices Selection                        |    |
| Table 3 | SmartFusion2 GPIO Configuration                       |    |
| Table 4 | Port to Pin Mapping                                   |    |
| Table 5 | LED Target Board                                      |    |
| Table 6 | SmartFusion2 Security Evaluation Kit Jumper Settings  | 31 |
| Table 7 | SmartFusion2 Advanced Development Kit Jumper Settings | 33 |
| Table 8 | SmartFusion2 Starter Kit Jumper Settings              |    |



# 1 Revision History

The revision history describes the changes that were implemented in the document. The changes are listed by revision, starting with the current publication.

#### 1.1 **Revision 6.0**

The following changes are made in revision 6.0 of this document:

- A note about FlashPro5 Programmer is added in Debugging the Application Project using SoftConsole v4.0, page 25
- Three notes are added in Appendix: Board Setup for SmartFusion2 Security Evaluation Kit, page 31 to describe about J5 FlashPro connector and J18 FTDI programmer interface

### 1.2 **Revision 5.0**

In revision 5.0, this document is updated for Libero SoC v11.7 software release.

#### 1.3 **Revision 4.0**

In revision 4.0, this document is updated for Libero SoC v11.6 and SoftConsole v4.0 software release.

### **1.4** Revision **3.0**

In revision 3.0, this document is updated for Libero SoC v11.5 software release.

#### 1.5 **Revision 2.0**

In revision 2.0, this document is updated for Libero SoC v11.4 software release.

#### 1.6 **Revision 1.0**

Revision 1.0 was the first publication of this document.



# 2 SoftConsole v4.0 and Libero SoC v11.7

#### 2.1 Introduction

This tutorial describes how to implement an ARM Cortex-M3 design using Libero<sup>®</sup> System-on-Chip (SoC) v11.7 and build a simple LED blink application using SoftConsole v4.0.

After completing this tutorial, you will be able to perform the following tasks:

- Create a Libero SoC project using System Builder
- Generate the programming file to program the SmartFusion<sup>®</sup>2 SoC field programmable gate array (FPGA) device
- Create a SoftConsole v4.0 project
- · Compile application code
- Debug and run code using SoftConsole

### 2.2 Design Requirements

Table 1 • Design Requirements

| Design Requirements   | Description                                  |  |  |
|---|--|--|--|
| Hardware Requirements   |  |  |  |
| SmartFusion2 Security Evaluation Kit:   | Rev D or later                               |  |  |
| SmartFusion2 Advanced Development Kit:  | Rev B or later                               |  |  |
| SmartFusion2 Starter Kit:  • FlashPro4 or FlashPro5 programmer  • USB A to Mini-B cable | SmartFusion2-484-Starter-Kit (M2S010-FGG484) |  |  |
| Host PC or Laptop   | Any 64-bit Windows Operating System          |  |  |
| Software Requirements   |  |  |  |
| Libero SoC  | v11.7  |  |  |
| SoftConsole   | v4.0   |  |  |
| FlashPro programming software   | v11.7  |  |  |

Note: This tutorial is applicable for any one of the SmartFusion2 boards listed in the preceding table.

# 2.2.1 Associated Project Files

Download design files for this tutorial from the Microsemi website: http://soc.microsemi.com/download/rsc/?f=m2s\_tu0546\_liberov11p7\_df


The demo design files include:

- Libero Project
- Sourcefiles
- · Readme file

The following figure shows the top-level structure of the design files. See the Readme.txt file provided in the design files directory for the complete directory structure.



Figure 1 • Design Files Top-Level Structure



### 2.3 Design Overview

This tutorial demonstrates a simple LED blinking application for SmartFusion2 device. Microcontroller subsystem (MSS) general-purpose input/output (GPIOs) are configured as outputs and connected to LEDs using fabric I/Os. This tutorial is applicable on one of the following SmartFusion2 boards:

- SmartFusion2 Security Evaluation Kit
- SmartFusion2 Advanced Development Kit
- SmartFusion2 Starter Kit (M2S010-FGG484)

# 2.4 Step 1: Creating a Libero SoC Project

The following steps describe how to create a Libero SoC project:

#### 2.4.1 Launching Libero SoC

- Click Start > Programs > Microsemi > Libero SoC v11.7 or double-click the shortcut on desktop to open the Libero SoC v11.7 Project Manager.
- 2. Create a new project by selecting **New** on the **Start Page** tab (highlighted in the following figure) or by clicking **Project > New Project** from the Libero SoC menu.

Figure 2 • Libero SoC Project Manager




- 3. In the **Project Details** window, enter the following information as shown in Figure 3, page 4.
- Project Name: LED\_Blink
- Project Location: Select an appropriate location (for example, D:/Microsemi\_pri)
- Preferred HDL type: Verilog or VHDL



#### • Enable Block Creation: Unchecked

Figure 3 • Project Details Window




- 4. Click **Next**. In the **Device Selection** window, select the information as displayed in Figure 4, page 5. In the Part Filter, select the values using the drop-down lists, as shown in the following table.
- **Family**: SmartFusion2

Table 2 • SmartFusion2 Devices Selection

| Board                                    | Die      | Package  | Speed | Core Voltage | Range | PLL Supply<br>Voltage |
|--|----------|----------|-------|--------------|-------|-----------------------|
| SmartFusion2 Security<br>Evaluation Kit  | M2S090TS | 484 FBGA | -1    | 1.2          | COM   | 3.3                   |
| SmartFusion2 Advanced<br>Development Kit | M2S150T  | 1152 FC  | -1    | 1.2          | COM   | 3.3                   |
| SmartFusion2 Starter Kit                 | M2S010   | 484 FBGA | STD   | 1.2          | COM   | 2.5                   |




Figure 4 • Device Selection Window



Click Next., the Device settings window is displayed. Select PLL Supply Voltage (V), as shown in the following figure.

Figure 5 • Device Settings




See Table 2, page 4 for specific board values.

Click Next. In the Design Template page, select Create a system builder based design check box under the Design Templates and Creators as shown in the following figure.




Figure 6 • Design Template Window



- 7. Click Finish. a New Project Information window is displayed, as shown in the following figure.
- 3. Click Use Enhanced Constraint Flow, as shown in the following figure.

Figure 7 • New Project Information Window




A System Builder dialog box is displayed, as shown in Figure 8, page 7.



System builder is a graphical design wizard. It creates a design based on high-level design specifications by taking the user through a set of high-level questions that define the intended system.


9. Enter a name for your system as LED\_Blink and then click OK, as shown in the following figure.

#### Figure 8 • System Builder Dialog Box



System Builder - Device Features page is displayed, as shown in the following figure.


Figure 9 • System Builder – Device Features Page



 Retain the default values. Click Next, the System Builder – Peripherals page is displayed. Under the MSS Peripherals section, uncheck all the check boxes except MSS\_GPIO, as shown in the following figure.



Figure 10 • System Builder Configurator – Select Peripherals Page




- Double-click the wrench symbol for the MSS\_GPIO peripheral to open the MSS\_GPIO Configurator.
- 12. This design requires configuring GPIOs to drive LEDs on the board, configure the GPIOs as shown below:
- Set/Reset Definition accept default settings
- Configure GPIO as shown in the following table

Table 3 • SmartFusion2 GPIO Configuration

| Board                                    | Die      | GPIO ID          | Direction | Package Pin | Connectivity |
|--|----------|------------------|-----------|-------------|--------------|
| SmartFusion2 Security Evaluation Kit     | M2S090TS | GPIO_0 to GPIO_7 | Output    | NA          | FABRIC_A     |
| SmartFusion2 Advanced<br>Development Kit | M2S150T  | GPIO_0 to GPIO_7 | Output    | NA          | FABRIC_A     |
| SmartFusion2 Starter Kit                 | M2S010   | GPIO_0 to GPIO_1 | Output    | NA          | FABRIC_A     |




Figure 11 • MSS\_GPIO Configurator



Click Next, the System Builder – Clocks Settings page is displayed, as shown in Figure 12, page 10. Select System Clock source as On-chip 25/50 MHz RC Oscillator.
The M3\_CLK is configured to 100 MHz by default.



Figure 12 • System Builder Configurator - Clock Settings Page




- 14. Click Next, the System Builder Microcontroller Options page is displayed.
- Retain the default values.
- 15. Click Next, the System Builder SECDED Options page is displayed.
- Retain the default values.
- 16. Click **Next**, the **System Builder Security Options** page is displayed.
- · Retain the default values.
- 17. Click **Next**, the **System Builder Interrupts Options** page is displayed.
- Retain the default values.
- 18. Click **Next**, the **System Builder Memory Map Options** page is displayed.
- Retain the default values.
- 19. Click Finish.

System Builder generates the system based on the selected options.

System Builder block is created and added to the Libero SoC project, as shown in the following figure.

Figure 13 • System Builder Generated System



### 2.4.2 Connecting Components in LED\_Blink SmartDesign


The following steps describe how to connect the components in LED\_Blink SmartDesign:

- Connect the pins as follows:
- Tie the FAB\_RESET\_N to high by right-clicking and selecting Tie High.
- Mark the output port POWER\_ON\_RESET\_N as unused by right-clicking and selecting Mark Unused.



- Mark the output port MSS\_READY as unused by right-clicking and selecting Mark Unused.
- Expand INIT\_PINS, right-click INIT\_DONE and select Mark Unused.
- Expand FAB\_CCC\_PINS, right-click FAB\_CCC\_GL0 and select Mark Unused.
- Right-click FAB\_CCC\_LOCK and select Mark Unused.
- Right-click GPIO\_FABRIC and select Promote to Top Level.
- 2. Click **File** > **Save**. The LED\_Blink design is displayed, as shown in the following figure.

Figure 14 • LED\_Blink Design



 Generate the LED\_Blink SmartDesign by clicking SmartDesign > Generate Component or by clicking Generate Component on the SmartDesign toolbar.

Figure 15 • Generate Component



After successful generation of the system, the message' **info: LED\_Blink' was successfully generated** is displayed on the Libero SoC **Log** window, as shown in the following figure.


Figure 16 • Log Window



# 2.5 Step 2: Generating the Program File

Double-click Synthesize in the Design Flow window, as shown in the following figure to complete
the synthesis.


Figure 17 • Design Flow Window





2. Double-click Manage Constraints in the Design Flow window, as shown in the following figure.

Figure 18 • Manage Constraints



3. Click **Edit with I/O Editor** under **I/O Attributes**, as shown in the following figure. The I/O Editor window is displayed, as shown in Figure 20, page 13.

Figure 19 • I/O Attributes



4. Make the pin assignments, as shown in the following table. After the pins are assigned, the I/O Editor is displayed, as shown in Figure 20, page 13.

Table 4 • Port to Pin Mapping


| Port Name                            | Pin Number |  |  |  |  |
|--------------------------------------|------------|--|--|--|--|
| SmartFusion2 Security Evaluation Kit |            |  |  |  |  |
| GPIO_0_M2F                           | H5         |  |  |  |  |
| GPIO_1_M2F                           | H6         |  |  |  |  |
| GPIO_2_M2F                           | J6         |  |  |  |  |
| GPIO_3_M2F                           | H7         |  |  |  |  |
| GPIO_4_M2F                           | G7         |  |  |  |  |
| GPIO_5_M2F                           | F3         |  |  |  |  |
| GPIO_6_M2F                           | F4         |  |  |  |  |



Table 4 • Port to Pin Mapping

| GPIO_7_M2F                            | E1   |  |  |  |
|---------------------------------------|------|--|--|--|
| SmartFusion2 Advanced Development Kit |      |  |  |  |
| GPIO_0_M2F                            | D26  |  |  |  |
| GPIO_1_M2F                            | F26  |  |  |  |
| GPIO_2_M2F                            | A27  |  |  |  |
| GPIO_3_M2F                            | C26  |  |  |  |
| GPIO_4_M2F                            | C28  |  |  |  |
| GPIO_5_M2F                            | B27  |  |  |  |
| GPIO_6_M2F                            | C27  |  |  |  |
| GPIO_7_M2F                            | E26  |  |  |  |
| SmartFusion2 Starter Kit              |      |  |  |  |
| GPIO_0_M2F                            | AB18 |  |  |  |
| GPIO_1_M2F                            | P1   |  |  |  |


Figure 20 • I/O Editor



- 5. After updating the I/O editor, click **Commit and Check**.
- 6. Close the I/O Editor.
- 7. Click **Generate Bitstream** in **Design flow** window, as shown in the following figure, to generate the programming file.



Figure 21 • Generate Bitstream




# 2.6 Step 3: Programming the SmartFusion2 Board Using FlashPro

Jumper settings for the supported target boards and board setup for running the tutorial are given in the following chapters:

- Appendix: Board Setup for SmartFusion2 Security Evaluation Kit, page 31.
- Appendix: Board Setup for SmartFusion2 Advanced Development Kit, page 33.
- Appendix: Board Setup for SmartFusion2 Starter Kit, page 35.
- 1. To program the SmartFusion2 device, double-click **Run PROGRAM Action** in the **Design Flow** window, as shown in the following figure.

Figure 22 • Run Programming Action






# 2.7 Step 4: Creating Software Project using SoftConsole 4.0

The following steps show how to create a software project using SoftConsole 4.0.

### 2.7.1 Export Firmware

 Double-click Export Firmware in Handoff design for Production in the Design Flow window, as shown in the following figure.


Figure 23 • Export Firmware



**Export Firmware** dialog box is displayed as shown in the following figure.


2. Select **Export hardware configuration (Software IDE independent)**, as shown in the following figure.

Figure 24 • Export Firmware Dialog Box



3. Click **OK**, a notification window appears saying **Firmware project was successfully exported to <a href="mailto:drive:\>Microsemi\_prj\LED\_Blink">LED\_Blink</a>, as shown in the following figure.** 

Figure 25 • Firmware Export Successful



4. Click OK.



#### 2.7.2 Download Firmware Drivers

The following drivers are used in this tutorial:


- CMSIS
- GPIO

To generate the required drivers:

Open the Microsemi SoC Firmware catalog from: Start > Programs > Microsemi> Libero SoC v11.7>Firmware Catalog> Firmware Catalog.

A message, **New cores are available for download** is displayed at the bottom of the Firmware Catalog, as shown in the following figure.


Figure 26 • Firmware Catalog



- 2. Click **Download them now,** to download most recent drivers for peripherals.
- 3. In **Firmware catalog** window, right-click **SmartFusion2 CMSIS Hardware Abstraction Layer** and then click **Generate**, as shown in the following figure.




Figure 27 • Firmware Catalog




 In Generate Options window, browse Project folder at <a href="mailto:drive:\>Microsemi\_prj\LED\_Blink\firmware">drive:\>Microsemi\_prj\LED\_Blink\firmware</a> and then click OK.

Figure 28 • Generate Options




5. A warning message is displayed, as shown in the following figure. Click Yes.

Figure 29 • Warning Message



6. **Configuring SmartFusion2\_CMSIS\_TOP\_0** window is displayed, as shown in the following figure. Select **SoftConsole** from the Software Tool Chain drop-down list and click **OK**.

Figure 30 • Software Tool Chain




7. Repeat steps 3 to 7 to download SmartFusion2 MSS GPIO driver.



### 2.7.3 Building Software Application using SoftConsole 4.0


- Click Start > Programs > Microsemi SoftConsole v4.0 > Microsemi SoftConsole v4.0 to open the SoftConsole IDE. The SoftConsole Workspace Launcher window is displayed.
- Browse to the location to select D:\Microsemi\_prj\LED\_Blink\SoftConsole, as shown in the following figure.

Figure 31 • Workspace Launcher



The SoftConsole workspace is displayed, as shown in the following figure.


Figure 32 • SoftConsole Window



3. Click File >New >C project as shown in the following figure.




Figure 33 • Creating New C Project



4. Enter Project name as LED\_Blink, as shown in the following figure.


Figure 34 • C Project Window



5. Click **Next**, **Select Configurations** window is displayed, as shown in the following figure.




Figure 35 • C Project - Select Configuration




- Do not change default settings. Click Next.
- 7. Cross GNU ARM Tool chain window is displayed, as shown in the following figure.

Figure 36 • C Project - Cross GNU ARM Tool Chain



- 8. Click Finish.
- 9. Right-click LED\_Blink and click Import as shown in the following figure.

Figure 37 • Project Explorer - Import




10. Import window is displayed, as shown the following figure.




11. Click File System and then click Next.

Figure 38 • Import Window



12. Browse to **D:\Microsemi\_prj\LED\_Blink\firmware** and check **firmware** check box, as shown in the following figure.

Figure 39 • Import - File System



#### 13. Click Finish.


**Note:** If any changes are made to the Libero SoC project, firmware needs to be exported from Libero and new firmware must be imported to **LED\_Blink**.

- 14. Using Windows explorer, browse to the main.c file location in the respective design files folder as follows:
- For SmartFusion2 Security Evaluation Kit:
   <download\_folder>\SF2\_LED\_Blink\_SC\_Tutorial\_DF\Sourcefiles\SF2\_Security\_Kit.




- For SmartFusion2 Advanced Development Kit:
   <download\_folder>\SF2\_LED\_Blink\_SC\_Tutorial\_DF\Sourcefiles\SF2\_Adv\_Dev\_Kit.
- 15. Copy the main.c file to the **LED\_Blink** project in the SoftConsole workspace, as shown in the following figure.

Figure 40 • Project Explorer



16. Right-click **LED\_Blink** and click **Properties**, as shown in the following figure.


Figure 41 • Project Explorer window - Properties



17. Click **Settings** under the **C/C++ Build** tab, as shown in the following figure.




Figure 42 • Properties for LED\_Blink



18. Under Cross ARM C compiler, click Miscellaneous and enter
--specs=cmsis.specs, in Other compiler flags text box as shown in the following figure.


Figure 43 • Properties for LED\_Blink - Miscellaneous



- 19. Under Cross ARM C Linker, click General as shown in Figure 44, page 24.
- 20. Click add button and add following linker Script path: 
  "\${workspace\_loc:/\${ProjName}/CMSIS/startup\_gcc/debug-in-microsemi-smartfusion2esram.ld}"
- 21. After adding Linker Script, **Properties for LED\_Blink**, window is displayed, as shown in the following figure.




Figure 44 • Properties for LED\_Blink - General



- 22. Under Cross ARM C Linker, click Miscellaneous.
- 23. Check Use newlib-nano(--specs=nano.specs) option, as shown in the following figure.


Figure 45 • Properties for LED\_Blink - Miscellaneous



- 24. Click **OK**.
- 25. Click Project and click Build All, as shown in the following figure.




Figure 46 • Project - Build All



26. Ensure that the Problems tab in the displayed window must not have any errors, as shown in the following figure.

Figure 47 • Problems Window




### 2.7.4 Debugging the Application Project using SoftConsole v4.0

The following steps describe how to debug the application project using SoftConsole v4.0:

1. Click **Debug Configurations** in the **Run** menu of the SoftConsole, as shown in the following figure. The **Debug Configurations** window is displayed, as shown in Figure 49, page 26.


Figure 48 • Run - Debug Configurations



Double-click GDB OpenOCD Debugging to view the configurations, as shown in the following figure.




Figure 49 • Debug Configurations



- 3. Ensure that the following values are filled in the corresponding fields:
  - Name: LED\_Blink Debug
  - Project: LED\_Blink
  - C/C++ Application: Debug\LED\_Blink.elf
- Select the Debugger tab in the Debug Configurations dialog box. --command "set DEVICE M2S090" specifies the target device, as shown in Figure 50, page 27. This command needs to be modified based on the target silicon.
  - SmartFusion2 Security Evaluation Kit set DEVICE M2S090
  - SmartFusion2 Advanced Development Kit set DEVICE M2S150
  - SmartFusion2 Starter Kit set DEVICE M2S010




Figure 50 • Debug Tab



- Click Debug.
- 6. On the Confirm Perspective Switch window, click Yes as shown in the following figure.


Figure 51 • Confirm Perspective Switch



The **SoftConsole Debugger Perspective** window is displayed, as shown in the following figure.



Figure 52 • Debugger Perspective Window




Click Run > Resume to run the application. LEDs start blinking on the SmartFusion2 target boards.
 The following table shows which LEDs blink for the different SmartFusion2 target boards.

Table 5 • LED Target Board

| Target Board                          | LEDs                                       |
|---------------------------------------|--|
| SmartFusion2 Security Evaluation Kit  | H5, H6, J6, H7, G7, F3, F4, and E1         |
| SmartFusion2 Advanced Development Kit | DS0, DS1, DS2, DS3, DS4, DS5, DS6, and DS7 |
| SmartFusion2 Starter Kit              | DS4, DS3                                   |

- 8. Launch the debug session:
- By selecting Debug Configurations from the Run menu of SoftConsole.
- By selecting the Debug Configurations using the Debug button as shown in the following figure.


Figure 53 • Debug Configurations Option



9. Click the **Registers** tab to view the values of the Cortex-M3 processor internal registers, as shown in the following figure.




Figure 54 • Values of Cortex-M3 Internal Registers



10. Click the **Variables** tab to view the values of variables in the source code, as shown in the following figure.

Figure 55 • Values of the Variables in the Source Code



11. In the **Debug** window, click **Window > Show View > Disassembly** to display the assembly level instructions. The **Disassembly** window with assembly instructions is displayed on the right-side of the Debug perspective window, as shown the following figure.

Figure 56 • Assembly Level Instructions

```
🔡 Outline 🍱 Disassembly 🏻
 20000724:
              push {r7, 1r}
              sub sp, #8
add r7, sp, #0
MSS_GPIO_init();
 20000726:
 20000728:
=24
              bl 0x20000584 <MSS_GPIO_init>

⇒ 2000072a:

 29
                MSS_GPIO_config( MSS_GPIO_0 , MSS_GPIO_OUTPUT_MODE );
 2000072e:
              movs r0, #0
 20000730:
              movs r1, #5
              bl 0x200005fc <MSS_GPIO_config>
 20000732:
                MSS_GPIO_config( MSS_GPIO_1 , MSS_GPIO_OUTPUT_MODE );
 20000736:
              movs r0, #1
 20000738:
              movs r1, #5
              bl 0x200005fc <MSS_GPIO_config>
 2000073a:
 31
               MSS_GPIO_config( MSS_GPIO_2 , MSS_GPIO_OUTPUT_MODE );
 2000073e:
              movs r0, #2
 20000740:
              movs r1, #5
              bl 0x200005fc <MSS_GPIO_config>
 20000742:
 32
                MSS_GPIO_config( MSS_GPIO_3 , MSS_GPIO_OUTPUT_MODE );
 20000746:
              movs r0, #3
 20000748:
              movs r1, #5
 2000074a:
              bl 0x200005fc <MSS_GPIO_config>
                MSS_GPIO_config( MSS_GPIO_4 , MSS_GPIO_OUTPUT_MODE );
 33
 2000074e:
              movs r0, #4
 20000750:
 20000752:
              bl 0x200005fc <MSS GPIO config>
```

- 12. Source code can be single-stepped by choosing Run > Step Into or Run > Step Over. Observe the changes in the source code window and disassembly view. Performing a Step Over provides an option for stepping over functions. The entire function is run but there is no need to single-step through each instruction contained in the function.
- 13. Click **Instruction Stepping** ( → ) and perform **Step Into** operations. Observe that **Step Into** executes a single line of assembly code.
- 14. Click **Instruction Stepping** to exit the instruction stepping mode. Single-step through the application and observe the instruction sequence in the source code window of the Debug perspective, and the values of the variables and registers.
- 15. Add breakpoints in the application to force the code to halt, single-step, and observe the instruction sequence.



- 16. When debug process is finished, terminate execution of the code by choosing **Run > Terminate**.
- 17. Close Debug Perspective by selecting **Close Perspective** from the **Window** menu.
- 18. Close SoftConsole using File > Exit.
- 19. Close the HyperTerminal using File > Exit.

**Note:** By default SoftConsole debugs using the first FlashPro5 programmer that it detects. If there is no FlashPro5 connected then it will use the first FlashPro3/4 that it detects

#### 2.8 Conclusion


This tutorial provides steps to create a Libero SoC design using System Builder. It describes the procedure to build, debug, and run a SoftConsole application. It also provides a simple design to blink LEDs.



# 3 Appendix: Board Setup for SmartFusion2 Security Evaluation Kit

The following figure shows the board setup for running the tutorial on the SmartFusion2 Security Evaluation kit board.

Figure 57 • SmartFusion2 Security Evaluation Kit Setup



1. Connect the jumpers on the SmartFusion2 Security Evaluation kit board as listed in the following table. For more information on jumper locations, see Figure 58, page 32 for SmartFusion2 Security Evaluation kit board jumper locations.

**CAUTION:** While making the jumper connections, the **SW7** power supply switch on the board must be in **OFF** position.

Table 6 • SmartFusion2 Security Evaluation Kit Jumper Settings

| Jumper               | Pin (From) | Pin (To) | Comments  |
|----------------------|------------|----------|---|
| J22, J23, J8, and J3 | 1          | 2        | These are the default jumper settings of the SmartFusion2 Security Evaluation Kit board. Ensure that these jumpers are set accordingly. |

 Connect the FlashPro4 or FlashPro5 programmer to the J5 connector of the SmartFusion2 Security Evaluation kit.

**Note:** J5 - FlashPro connector is normally used for FlashPro programming of the FPGA and SoftConsole debugging.




**Note:** J18 - FTDI programmer interface, used to program the external serial peripheral interface (SPI) flash cannot be used for SoftConsole debugging.

**Note:** If both J5 and J18 are connected to the host computer on which SoftConsole is running then SoftConsole must be configured to use J5 for debugging.

- 3. Connect the power supply to the **J6** connector.
- 4. Switch **ON** the **SW7** power supply switch.

The following figure shows the jumper locations on the SmartFusion2 Security Evaluation kit board.

Figure 58 • SmartFusion2 Security Evaluation Kit Board Jumper Locations



Note: Jumpers highlighted in red are set by default.


**Note:** The locations of the jumpers in the preceding figure are searchable.



# 4 Appendix: Board Setup for SmartFusion2 Advanced Development Kit

The following figure shows the board setup for running the demo on the SmartFusion2 Advanced Development kit board.

Figure 59 • SmartFusion2 Advanced Development Kit Setup



1. Connect the jumpers on the SmartFusion2 Advanced Development kit board as listed in the following table. For more information on jumper locations, see Figure 60, page 34 of SmartFusion2 Advanced Development kit board Jumper Locations.

**CAUTION:** While making the jumper connections, the **SW7** power supply switch on the board must be in **OFF** position.

Table 7 • SmartFusion2 Advanced Development Kit Jumper Settings

| Jumper                    | Pin (from) | Pin (to) | Comments  |
|---------------------------|------------|----------|---|
| J116, J353, J354, and J54 | 1          | 2        | These are the default jumper settings of the  |
| J123                      | 2          | 3        | SmartFusion2 advanced development kit board. Ensure that these jumpers are set accordingly. |
| J124, J121, and J32       | 2          | 3        | JTAG programming via FTDI   |


- Connect the FlashPro4 or FlashPro5 programmer to the J37 connector of the SmartFusion2 Advanced Development kit.
- 3. Connect the power supply to the **J42** connector.



4. Switch **ON** the **SW7** power supply switch.

The following figure shows the jumper locations on the SmartFusion2 Advanced Development kit board.

Figure 60 • SmartFusion2 Advanced Development Kit Board Jumper Locations



#### Notes:


- Jumpers highlighted in red are set by default.
- Jumpers highlighted in green must be set manually.
- The locations of the jumpers in the preceding figure are searchable.



# 5 Appendix: Board Setup for SmartFusion2 Starter Kit

The following figure shows the board setup for running the demo on the SmartFusion2 starter kit board.

Figure 61 • SmartFusion2 Starter Kit Setup



1. Connect the jumpers on the SmartFusion2 Starter kit board as listed in Table 8, page 35.

Table 8 • SmartFusion2 Starter Kit Jumper Settings

| Jumper | Pin (From) | Pin (To) | Comments  |
|--------|------------|----------|---|
| JP1    | 1          | 2        | These are the default jumper settings of SmartFusion2  Starter kit board. Ensure that these jumpers are set  accordingly. |
| JP2    | 3          | 4        |   |
| JP3    | 2          | 4        |   |

- 2. Connect the FlashPro4 or FlashPro5 programmer to the **P5** connector of the SmartFusion2 Starter kit
- Connect the host PC USB port to the P1 Mini USB connector on the SmartFusion2 Starter kit board using the USB Mini-B cable. As soon as the connection to the PC is made, the on-board LED DS2 will illuminate, indicating that the board has power.