


Silicon Switching Diodes

- High-speed, high-voltage switching applications



Type	Marking	Pin Configuration			Package
BAS19	JPs	1 = A	2 = n.c.	3 = C	SOT23
BAS20	JRs	1 = A	2 = n.c.	3 = C	SOT23
BAS21	JSS	1 = A	2 = n.c.	3 = C	SOT23

Maximum Ratings

Parameter	Symbol	Value	Unit
Diode reverse voltage BAS19	V_R	100	V
BAS20		150	
BAS21		200	
Peak reverse voltage- BAS19	V_{RM}	120	
BAS20		200	
BAS21		250	
Forward current	I_F	250	mA
Peak forward current	I_{FM}	625	
Total power dissipation $T_S = 70 \text{ }^\circ\text{C}$	P_{tot}	350	mW
Junction temperature	T_j	150	$^\circ\text{C}$
Storage temperature	T_{stg}	-65 ... 150	


Thermal Resistance

Parameter	Symbol	Value	Unit
Junction - soldering point ¹⁾	R_{thJS}	≤ 230	K/W

¹For calculation of R_{thJA} please refer to Application Note Thermal Resistance

Electrical Characteristics at $T_A = 25^\circ\text{C}$, unless otherwise specified

Parameter	Symbol	Values			Unit
		min.	typ.	max.	
DC Characteristics					
Breakdown voltage $I_{(\text{BR})} = 100 \mu\text{A}$, BAS19	$V_{(\text{BR})}$	120	-	-	V
$I_{(\text{BR})} = 100 \mu\text{A}$, BAS20		200	-	-	
$I_{(\text{BR})} = 100 \mu\text{A}$, BAS21		250	-	-	
Reverse current $V_R = V_{R\text{max}}$ $V_R = V_{R\text{max}}, T_A = 150^\circ\text{C}$	I_R	-	-	0.1	μA
Forward voltage $I_F = 100 \text{ mA}$ $I_F = 200 \text{ mA}$	V_F	-	-	1 1.25	V
AC Characteristics					
Diode capacitance- $V_R = 0 \text{ V}, f = 1 \text{ MHz}$	C_T	-	-	5	pF
Reverse recovery time $I_F = 30 \text{ mA}, I_R = 30 \text{ mA}$, measured at $I_R = 3 \text{ mA}$, $R_L = 100 \Omega$	t_{rr}	-	-	50	ns


Test circuit for reverse recovery time


Pulse generator: $t_p = 1 \mu\text{s}$, $D = 0.05$,
 $t_r = 0.6 \text{ ns}$, $R_i = 50 \Omega$

Oscilloscope: $R = 50\Omega$, $t_f = 0.35 \text{ ns}$, $C \leq 1 \text{ pF}$


Reverse current $I_R = f (T_A)$

V_F = Parameter




Forward current $I_F = f (V_F)$

$T_A = 25 \text{ }^{\circ}\text{C}$




Forward Voltage $V_F = f (T_A)$

I_F = Parameter




Peak forward current $I_{FM} = f (t_p)$

$T_A = 25 \text{ }^{\circ}\text{C}$




Reverse voltage $V_R = f (T_A)$



Permissible Pulse Load

$$I_{F\max}/I_{FDC} = f (t_p)$$



Permissible Puls Load $R_{thJS} = f (t_p)$

