

# RAD-ISM-900-HOP-US

Order No.: 2867539



<http://eshop.phoenixcontact.de/phoenix/treeViewClick.do?UID=2867539>

The HOPKEY contains information such as the transmission frequencies used and the hop sequence. This information is required e.g. when installing an additional receiver / repeater in an existing system.



Commercial data

Note	Made-to-order
sales group	H172
Pack	1 pcs.
Customs tariff	85423261
Catalog page information	Page 438 (IF-2005)

<http://www.download.phoenixcontact.com>  
Please note that the data given here has been taken from the online catalog. For comprehensive information and data, please refer to the user documentation. The General Terms and Conditions of Use apply to Internet downloads.

## Product description

When the supply voltage is switched on, the information is transmitted to a non-volatile memory in the module from a plugged in HOPKEY. Then this HOPKEY can be used to "train" other receivers. In the last receiver, the HOPKEY can be preserved. If no HOPKEY is plugged in, the information in the module is used.

## Configuration options

Design	Point to Point Master [PPM] Point to Point Slave [PPS] Point to Multipoint Master [PMM] Point to Multipoint Slave [PMS] Multipoint to Point Master [MPM] Multipoint to Point Slave [MPS] Repeater [REP]
--------	---

**Address**

PHOENIX CONTACT Inc., USA  
586 Fulling Mill Road  
Middletown, PA 17057, USA  
Phone (800) 888-7388  
Fax (717) 944-1625  
<http://www.phoenixcon.com>



© 2011 Phoenix Contact  
Technical modifications reserved;