

ENT-AN1026
Application Note
Layout and Assembly Considerations for TQFP Packages
with Inner Leads

2016

Contents

1	Revision History	1
1.1	Revision 1.0	1
2	Layout and Assembly Considerations for TQFP Packages with Inner Leads	2
3	PCB Design	3
4	Surface Mount Guidelines	5

1 **Revision History**

The revision history describes the changes that were implemented in the document. The changes are listed by revision, starting with the most current publication.

1.1 **Revision 1.0**

Revision 1.0 was the first publication of this document.

2 **Layout and Assembly Considerations for TQFP Packages with Inner Leads**

The purpose of this document is to provide PCB design reference information and surface mount guidelines relating to the novel integration of inner leads in TQFP packages used for Microsemi products, including VSC7420/VSC7421/VSC7422 SparX-III Ethernet switches and VSC8522 12-port 10/100/1000BASE-T PHY. The Microsemi VSC5609EV reference board, featuring the VSC7422 and VSC8522, is used as the primary reference for this application note.

The PCB Design section includes detailed PCB land pattern information, recommended escape routing, and center exposed pad layout guidelines. The Surface Mount Guidelines section provides stencil information and rework procedures.

For further reference, please consult the VSC7420, VSC7421, VSC7422, and VSC8522 Datasheet; VSC7420, VSC7421, and VSC7422 Hardware Manual; and VSC8522 Design and Layout Guideline. A datasheet, application notes, and other information for the FusionQuad package can be downloaded from the Amkor website.

3 PCB Design


The following table shows the dimensions of the metal pad and solder mask opening sizes for both the inner and outer leads.

Table 1 • PCB Land Pattern Dimensions

Leads	Metal Pad	Solder Mask Opening Sizes
Inner	0.25 mm x 0.70 mm	0.35 mm x 0.80 mm
Outer	0.25 mm x 1.6 mm	0.30 mm x 1.70 mm

The following illustration shows the recommended escape routing from the inner leads.


Figure 1 • Escape Routing



Do not align the vias, as this may result in plane breakage.


The following illustration shows heat dispersion.

Figure 2 • Thermal Vias Placed on Center Exposed Pad



The recommended thermal via type that should be placed on the center exposed pad is 0.3 mm in diameter through the hole without solder mask. In the case of the Microsemi VSC5609EV reference board, there are a total of 117 thermal vias placed on each VSC7422 and VSC8522 center exposed pad. The center exposed pad is the main path for heat dispersion from the die, through which thermal vias translate heat from the PCB top layer to copper planes located either internal to or on the bottom surface of the board. For a typical 2-layer PCB design, power planes are created on the top layer surrounding the center exposed pad (in the previous illustration, yellow denotes the 2V5 power plane and pink denotes the 1V0 power plane), with the bottom layer serving as the only layer that provides a copper plane for heat dispersion. Thus, it is strongly recommended to make as many thermal via connections as possible from the center exposed pad area to the copper plane on the bottom side. An inadequate thermal path here could cause device junction temperature increases of 10 °C or more. The following illustration demonstrates a good example extracted from the Microsemi VSC5609EV reference board layout file.

Figure 3 • Maximizing Copper Connections to Facilitate Heat Dispersion




4 Surface Mount Guidelines

The following is stencil information:

- Thickness: 100 to 125 μm
- Outer leads aperture: same size as outer land pattern on board
- Inner leads aperture: same size as inner land pattern on board

Figure 4 • Example Stencil Design for Center Exposed Pad



In order to avoid solder from wicking through the vias, the apertures should not be placed above thermal vias on the PCB.

For an effective rework procedure, the following steps are recommended.

1. Remove the package.
2. Clean the board site.
3. On the replacement package, paste print on the inner leads and center exposed pad. The following illustration shows an example stencil.

Figure 5 • Example Stencil for Inner Leads Paste Printing



4. Flip package on the board.
5. Reflow.

6. Hand solder the outer leads.

**Microsemi Headquarters**

One Enterprise, Aliso Viejo,
CA 92656 USA
Within the USA: +1 (800) 713-4113
Outside the USA: +1 (949) 380-6100
Sales: +1 (949) 380-6136
Fax: +1 (949) 215-4996
Email: sales.support@microsemi.com
www.microsemi.com

© Microsemi. All rights reserved. Microsemi and the Microsemi logo are trademarks of Microsemi Corporation. All other trademarks and service marks are the property of their respective owners.

Microsemi makes no warranty, representation, or guarantee regarding the information contained herein or the suitability of its products and services for any particular purpose, nor does Microsemi assume any liability whatsoever arising out of the application or use of any product or circuit. The products sold hereunder and any other products sold by Microsemi have been subject to limited testing and should not be used in conjunction with mission-critical equipment or applications. Any performance specifications are believed to be reliable but are not verified, and Buyer must conduct and complete all performance and other testing of the products, alone and together with, or installed in, any end-products. Buyer shall not rely on any data and performance specifications or parameters provided by Microsemi. It is the Buyer's responsibility to independently determine suitability of any products and to test and verify the same. The information provided by Microsemi hereunder is provided "as is, where is" and with all faults, and the entire risk associated with such information is entirely with the Buyer. Microsemi does not grant, explicitly or implicitly, to any party any patent rights, licenses, or any other IP rights, whether with regard to such information itself or anything described by such information. Information provided in this document is proprietary to Microsemi, and Microsemi reserves the right to make any changes to the information in this document or to any products and services at any time without notice.

Microsemi, a wholly owned subsidiary of Microchip Technology Inc. (Nasdaq: MCHP), offers a comprehensive portfolio of semiconductor and system solutions for aerospace & defense, communications, data center and industrial markets. Products include high-performance and radiation-hardened analog mixed-signal integrated circuits, FPGAs, SoCs and ASICs; power management products; timing and synchronization devices and precise time solutions; setting the world's standard for time; voice processing devices; RF solutions; discrete components; enterprise storage and communication solutions; security technologies and scalable anti-tamper products; Ethernet solutions; Power-over-Ethernet ICs and midspans; as well as custom design capabilities and services. Microsemi is headquartered in Aliso Viejo, California, and has approximately 4,800 employees globally. Learn more at www.microsemi.com.

VPPD-02781